

## TYPE CODE

- Throughout this manual, the following abbreviations are used to identify individual model.

CODE	AREA TYPE
E	U.K., Ireland
F	France
ED	EUROPEAN DIRECT SALES (Belgium, Denmark, Germany, Greece, Italy, Luxemburg, Austria, Portugal, Finland, Sweden, Switzerland, Czech, Slovakia, Norway, Iceland, Russia, Poland, Slovenia, Croatia, Latvia, Macedonia, Romania, Bulgaria, Ukraine, Israel, Spain, Hungary)
U	Australia, New Zealand

## **A Few Words About Safety**

### **Service Information**

The service and repair information contained in this manual is intended for use by qualified, professional technicians. Attempting service or repairs without the proper training, tools, and equipment could cause injury to you or others. It could also damage the vehicle or create an unsafe condition.

This manual describes the proper methods and procedures for performing service, maintenance, and repairs. Some procedures require the use of specially designed tools and dedicated equipment. Any person who intends to use a replacement part, service procedure or a tool that is not recommended by Honda, must determine the risks to their personal safety and the safe operation of the vehicle.

If you need to replace a part, use genuine Honda parts with the correct part number or an equivalent part. We strongly recommend that you do not use replacement parts of inferior quality.

### **For Your Customer's Safety**

Proper service and maintenance are essential to the customer's safety and the reliability of the vehicle. Any error or oversight while servicing a vehicle can result in faulty operation, damage to the vehicle, or injury to others.

### **For Your Safety**

Because this manual is intended for the professional service technician, we do not provide warnings about many basic shop safety practices (e.g., Hot parts—wear gloves). If you have not received shop safety training or do not feel confident about your knowledge of safe servicing practice, we recommended that you do not attempt to perform the procedures described in this manual.

Some of the most important general service safety precautions are given below. However, we cannot warn you of every conceivable hazard that can arise in performing service and repair procedures. Only you can decide whether or not you should perform a given task.

### **Important Safety Precautions**

Make sure you have a clear understanding of all basic shop safety practices and that you are wearing appropriate clothing and using safety equipment. When performing any service task, be especially careful of the following:

- Read all of the instructions before you begin, and make sure you have the tools, the replacement or repair parts, and the skills required to perform the tasks safely and completely.
- Protect your eyes by using proper safety glasses, goggles or face shields any time you hammer, drill, grind, pry or work around pressurized air or liquids, and springs or other stored-energy components. If there is any doubt, put on eye protection.
- Use other protective wear when necessary, for example gloves or safety shoes. Handling hot or sharp parts can cause severe burns or cuts. Before you grab something that looks like it can hurt you, stop and put on gloves.
- Protect yourself and others whenever you have the vehicle up in the air. Any time you lift the vehicle, either with a hoist or a jack, make sure that it is always securely supported. Use jack stands.

Make sure the engine is off before you begin any servicing procedures, unless the instruction tells you to do otherwise. This will help eliminate several potential hazards:

- Carbon monoxide poisoning from engine exhaust. Be sure there is adequate ventilation whenever you run the engine.
- Burns from hot parts or coolant. Let the engine and exhaust system cool before working in those areas.
- Injury from moving parts. If the instruction tells you to run the engine, be sure your hands, fingers and clothing are out of the way.

Gasoline vapors and hydrogen gases from batteries are explosive. To reduce the possibility of a fire or explosion, be careful when working around gasoline or batteries.

- Use only a nonflammable solvent, not gasoline, to clean parts.
- Never drain or store gasoline in an open container.
- Keep all cigarettes, sparks and flames away from the battery and all fuel-related parts.

#### **⚠ WARNING**

Improper service or repairs can create an unsafe condition that can cause your customer or others to be seriously hurt or killed.

Follow the procedures and precautions in this manual and other service materials carefully.

#### **⚠ WARNING**

Failure to properly follow instructions and precautions can cause you to be seriously hurt or killed.

Follow the procedures and precautions in this manual carefully.

# HOW TO USE THIS MANUAL

This service manual describes the service procedures for the CB1000R/RA.

Follow the Maintenance Schedule (Section 3) recommendations to ensure that the vehicle is in peak operating condition.

Performing the first scheduled maintenance is very important. It compensates for the initial wear that occurs during the break-in period.


Sections 1, 2 and 3 apply to the whole motorcycle. Section 2 illustrates procedures for removal/installation of components that may be required to perform service described in the following sections. Section 4 through 21 describe parts of the motorcycle, grouped according to location.

Find the section you want on this page, then turn to the table of contents on the first page of the section.

Most sections start with an assembly or system illustration, service information and troubleshooting for the section. The subsequent pages give detailed procedure.

If you don't know the source of the trouble, go to section 23 Troubleshooting.

Your safety, and the safety of others, is very important. To help you make informed decisions we have provided safety messages and other information throughout this manual. Of course, it is not practical or possible to warn you about all the hazards associated with servicing this vehicle. You must use your own good judgement. You will find important safety information in a variety of forms including:

- Safety Labels – on the vehicle
- Safety Messages – preceded by a safety alert symbol  and one of three signal words, DANGER, WARNING, or CAUTION.

These signal words mean:

**DANGER** You WILL be KILLED or SERIOUSLY HURT if you don't follow instructions.

**WARNING** You CAN be KILLED or SERIOUSLY HURT if you don't follow instructions.

**CAUTION** You CAN be HURT if you don't follow instructions.

- Instructions – how to service this vehicle correctly and safely.

As you read this manual, you will find information that is preceded by a **NOTICE** symbol. The purpose of this message is to help prevent damage to your vehicle, other property, or the environment.

**ALL INFORMATION, ILLUSTRATIONS, DIRECTIONS AND SPECIFICATIONS INCLUDED IN THIS PUBLICATION ARE BASED ON THE LATEST PRODUCT INFORMATION AVAILABLE AT THE TIME OF APPROVAL FOR PRINTING. HONDA MOTOR CO., LTD. RESERVES THE RIGHT TO MAKE CHANGES AT ANY TIME WITHOUT NOTICE AND WITHOUT INCURRING ANY OBLIGATION WHATSOEVER. NO PART OF THIS PUBLICATION MAY BE REPRODUCED WITHOUT WRITTEN PERMISSION. THIS MANUAL IS WRITTEN FOR PERSONS WHO HAVE ACQUIRED BASIC KNOWLEDGE OF MAINTENANCE ON HONDA MOTORCYCLES, MOTOR SCOOTERS OR ATVS.**












Honda Motor Co., Ltd.  
SERVICE PUBLICATION OFFICE

# CONTENTS

	GENERAL INFORMATION	1
	FRAME/BODY PANELS/EXHAUST SYSTEM	2
	MAINTENANCE	3
ENGINE AND DRIVE TRAIN	LUBRICATION SYSTEM	4
	FUEL SYSTEM (PGM-FI)	5
	COOLING SYSTEM	6
	ENGINE REMOVAL/INSTALLATION	7
	CYLINDER HEAD/VALVES	8
	CLUTCH/STARTER CLUTCH/ GEARSHIFT LINKAGE	9
	ALTERNATOR	10
	CRANKCASE/TRANSMISSION	11
	CRANKSHAFT/PISTON/CYLINDER	12
CHASSIS	FRONT WHEEL/SUSPENSION/ STEERING	13
	REAR WHEEL/SUSPENSION	14
	HYDRAULIC BRAKE	15
	ANTI-LOCK BRAKE SYSTEM (ABS/CBS; CB1000RA)	16
ELECTRICAL	BATTERY/CHARGING SYSTEM	17
	IGNITION SYSTEM	18
	ELECTRIC STARTER	19
	LIGHTS/METER/SWITCHES	20
	IMMOBILIZER SYSTEM (HISS)	21
	WIRING DIAGRAMS	22
	TROUBLESHOOTING	23
	INDEX	24

# SYMBOLS

The symbols used throughout this manual show specific service procedures. If supplementary information is required pertaining to these symbols, it would be explained specifically in the text without the use of the symbols.

	<p>Replace the part(s) with new one(s) before assembly.</p>
	<p>Use recommended engine oil, unless otherwise specified.</p>
	<p>Use molybdenum oil solution (mixture of the engine oil and molybdenum grease in a ratio of 1: 1).</p>
	<p>Use multi-purpose grease (Lithium based multi-purpose grease NLGI #2 or equivalent).</p>
	<p>Use molybdenum disulfide grease (containing more than 3% molybdenum disulfide, NLGI #2 or equivalent).            Example: Molykote® BR-2 plus manufactured by Dow Corning U.S.A.            Multi-purpose M-2 manufactured by Mitsubishi Oil, Japan</p>
	<p>Use molybdenum disulfide paste (containing more than 40% molybdenum disulfide, NLGI #2 or equivalent).            Example: Molykote® G-n Paste manufactured by Dow Corning U.S.A.            Honda Moly 60 (U.S.A. only)            Rocol ASP manufactured by Rocol Limited, U.K.            Rocol Paste manufactured by Sumico Lubricant, Japan</p>
	<p>Use silicone grease.</p>
	<p>Apply a locking agent. Use a middle strength locking agent unless otherwise specified.</p>
	<p>Apply sealant.</p>
	<p>Use DOT 4 brake fluid. Use the recommended brake fluid unless otherwise specified.</p>
	<p>Use Fork or Suspension Fluid.</p>

# 1. GENERAL INFORMATION

---

SERVICE RULES .....	1-2	FRONT WHEEL/SUSPENSION/STEERING SPECIFICATIONS .....	1-9
MODEL IDENTIFICATION.....	1-3	REAR WHEEL/SUSPENSION SPECIFICATIONS .....	1-9
GENERAL SPECIFICATIONS.....	1-5	HYDRAULIC BRAKE SPECIFICATIONS... ..	1-10
LUBRICATION SYSTEM SPECIFICATIONS.....	1-6	BATTERY/CHARGING SYSTEM SPECIFICATIONS .....	1-10
FUEL SYSTEM (PGM-FI) SPECIFICATIONS.....	1-6	IGNITION SYSTEM SPECIFICATIONS... ..	1-10
COOLING SYSTEM SPECIFICATIONS .....	1-6	ELECTRIC STARTER SPECIFICATION... ..	1-11
CYLINDER HEAD/VALVES SPECIFICATIONS.....	1-7	LIGHTS/METERS/SWITCHES SPECIFICATIONS .....	1-11
CLUTCH/STARTER CLUTCH SPECIFICATIONS.....	1-7	STANDARD TORQUE VALUES.....	1-12
TRANSMISSION/GEARSHIFT LINKAGE SPECIFICATIONS.....	1-8	ENGINE & FRAME TORQUE VALUES... ..	1-12
CRANKCASE/CRANKSHAFT/BALANCER/PISTON/CYLINDER SPECIFICATIONS .....	1-8	LUBRICATION & SEAL POINTS .....	1-19
		CABLE & HARNESS ROUTING .....	1-22
		EMISSION CONTROL SYSTEMS .....	1-41

## GENERAL INFORMATION

---

### SERVICE RULES

1. Use genuine Honda or Honda-recommended parts and lubricants or their equivalents. Parts that don't meet Honda's design specifications may cause damage to the motorcycle.
2. Use the special tools designed for this product to avoid damage and incorrect assembly.
3. Use only metric tools when servicing the motorcycle. Metric bolts, nuts and screws are not interchangeable with English fasteners.
4. Install new gaskets, O-rings, cotter pins, and lock plates when reassembling.
5. When tightening bolts or nuts, begin with the larger diameter or inner bolt first. Then tighten to the specified torque diagonally in incremental steps unless a particular sequence is specified.
6. Clean parts in cleaning solvent upon disassembly. Lubricate any sliding surfaces before reassembly.
7. After reassembly, check all parts for proper installation and operation.
8. Route all electrical wires as shown in the Cable and Harness Routing (page 1-22).


### ABBREVIATION

Throughout this manual, the following abbreviations are used to identify the respective parts or systems.

Abbrev. term	Full term
ABS	Anti-lock Brake System
CKP sensor	Crankshaft Position sensor
DLC	Data Link Connector
DTC	Diagnostic Trouble Code
ECM	Engine Control Module
ECT sensor	Engine Coolant Temperature sensor
EEPROM	Electrically Erasable Programmable Read Only Memory
EOP switch	Engine Oil Pressure switch
HDS	Honda Diagnostic System
HISS	Honda Ignition Security System
IACV	Idle Air Control Valve
IAT sensor	Intake Air Temperature sensor
IDC solenoid valve	Intake Duct Control solenoid valve
MAP sensor	Manifold Absolute Pressure sensor
MIL	Malfunction Indicator Lamp
PAIR	Pulsed Secondary Air Injection
PCV	Proportional Control Valve
PGM-FI	Programmed Fuel Injection
SCS connector	Service Check Short connector
TP sensor	Throttle Position sensor
VS sensor	Vehicle Speed sensor


# MODEL IDENTIFICATION

CB1000RA Shown:



## SERIAL NUMBERS


The Vehicle Identification Number (V.I.N) is stamped on the right side of the steering head.



The registered number plate (except U type) is located on left side of the frame tube.


The compliance plate (U type only) is located on left side of the frame tube.

REGISTERED NUMBER PLATE (except U type)  
or COMPLIANCE PLATE (U type only)




## GENERAL INFORMATION

The engine serial number is stamped on the right side of the upper crankcase.




The throttle body identification number is stamped on the left and right side of the throttle body.



## LABEL

The color label is attached on the frame under the seat. When ordering color-coded parts, always specify the designated color code.





**GENERAL SPECIFICATIONS**

	ITEM	SPECIFICATIONS
DIMENSIONS	Overall length	Except U type: U type:
	Overall width	
	Overall height	
	Wheelbase	
	Seat height	
	Ground clearance	
	Curb weight	CB1000R: CB1000RA:
	Maximum weight capacity	
FRAME	Frame type	
	Front suspension	
	Front axle travel	
	Rear suspension	
	Rear axle travel	
	Front tire size	
	Rear tire size	
	Front tire brand	Bridgestone
	Rear tire brand	Bridgestone
	Front brake	
	Rear brake	
	Caster angle	
	Trail length	
	Fuel tank capacity	
ENGINE	Cylinder arrangement	
	Bore and stroke	
	Displacement	
	Compression ratio	
	Valve train	
	Intake valve opens:	at 1 mm (0.04 in) lift
	Intake valve closes:	at 1 mm (0.04 in) lift
	Exhaust valve opens:	at 1 mm (0.04 in) lift
	Exhaust valve closes:	at 1 mm (0.04 in) lift
	Lubrication system	
	Oil pump type	
	Cooling system	
	Air filtration	
Engine dry weight		
	Firing order	
FUEL DELIVERY SYSTEM	Type	
	Throttle bore	
DRIVE TRAIN	Clutch system	
	Clutch operation system	
	Transmission	
	Primary reduction	
	Final reduction	
	Gear ratio	1st
		2nd
		3rd
	4th	
	5th	
	6th	
	Gearshift pattern	
ELECTRICAL	Ignition system	
	Starting system	
	Charging system	
	Regulator/rectifier	
	Lighting system	

## GENERAL INFORMATION

### LUBRICATION SYSTEM SPECIFICATIONS

Unit: mm (in)

ITEM		STANDARD	SERVICE LIMIT
Engine oil capacity	After draining	2.7 liter (2.9 US qt, 2.4 Imp qt)	-
	After oil filter change	3.0 liter (3.2 US qt, 2.6 Imp qt)	-
	After disassembly	3.6 liter (3.8 US qt, 3.2 Imp qt)	-
Engine oil	Suggested oil: Honda "4-stroke motorcycle oil" or an equivalent Oil recommendation: API classification: SG or higher (except oils labeled as energy conserving on the circular API service label) Viscosity: SAE 10W-30 JASO T 903 standard: MA		-
Oil pressure at EOP switch	510 kPa (5.2 kgf/cm <sup>2</sup> , 74 psi) at 6,000 min <sup>-1</sup> (rpm)/(80°C/176°F)		-
Oil pump	Tip clearance	0.15 (0.006)	0.20 (0.008)
	Body clearance	0.15 – 0.21 (0.006 – 0.008)	0.35 (0.014)
	Side clearance	0.04 – 0.09 (0.002 – 0.004)	0.17 (0.007)

### FUEL SYSTEM (PGM-FI) SPECIFICATIONS

ITEM	SPECIFICATIONS
Throttle body identification number	GQ3EA
Idle speed	1,200 ± 100 min <sup>-1</sup> (rpm)
Throttle grip free play	2 – 6 mm (1/16 – 1/4 in)
IAT sensor resistance (at 20°C/68°F)	1 – 4 kΩ
ECT sensor resistance (at 20°C/68°F)	2.3 – 2.6 kΩ
Fuel injector resistance (at 20°C /68°F)	11.1–12.3 Ω
PAIR control solenoid valve resistance (at 20°C/68°F)	23 – 27 Ω
Intake duct control (IDC) solenoid valve resistance (at 20°C/68°F)	28 – 32 Ω
CKP sensor peak voltage (at 20°C/68°F)	0.7 V minimum
Fuel pressure at idle	343 kPa (3.5 kgf/cm <sup>2</sup> , 50 psi)
Fuel pump flow (at 12 V)	189 cm <sup>3</sup> (6.4 US oz, 6.7 Imp oz) minimum/10 seconds

### COOLING SYSTEM SPECIFICATIONS

ITEM	SPECIFICATIONS	
Coolant capacity	Radiator and engine	3.0 liter (3.2 US qt, 2.6 Imp qt)
	Reserve tank	0.35 liter (0.37 US qt, 0.31 Imp qt)
Radiator cap relief pressure	108 – 137 kPa (1.1 – 1.4 kgf/cm <sup>2</sup> , 16 – 20 psi)	
Thermostat	Begin to open	80.5 – 83.5 °C (176.9 – 182.3 °F)
	Fully open	95 °C (203 °F)
	Valve lift	8 mm (0.3 in) minimum
Recommended antifreeze	High quality ethylene glycol antifreeze containing silicate-free corrosion protection inhibitors	
Standard coolant concentration	1:1 mixture with distilled water	

**CYLINDER HEAD/VALVES SPECIFICATIONS**

Unit: mm (in)

ITEM		STANDARD	SERVICE LIMIT
Cylinder compression		1,500 kPa (15.3 kgf/cm <sup>2</sup> , 218 psi) at 300 min <sup>-1</sup> (rpm)	-
Valve clearance	IN	0.16 ± 0.03 (0.006 ± 0.001)	-
	EX	0.32 ± 0.03 (0.013 ± 0.001)	-
Camshaft	Cam lobe height	IN	36.02 - 36.10 (1.418 - 1.421)
		EX	36.08 - 36.16 (1.420 - 1.424)
	Runout		-
	Oil clearance		0.020 - 0.062 (0.0008 - 0.0024)
Valve lifter	Valve lifter O.D.		25.978 - 25.993 (1.0228 - 1.0233)
	Valve lifter bore I.D.		26.010 - 26.026 (1.0240 - 1.0246)
Valve, valve guide	Valve stem O.D.	IN	4.475 - 4.490 (0.1762 - 0.1768)
		EX	4.465 - 4.480 (0.1758 - 0.1764)
	Valve guide I.D.		4.500 - 4.512 (0.1772 - 0.1776)
	Stem-to-guide clearance	IN	0.010 - 0.037 (0.0004 - 0.0015)
		EX	0.020 - 0.047 (0.0008 - 0.0019)
	Valve guide projection above cylinder head	IN	16.0 - 16.3 (0.63 - 0.64)
		EX	16.0 - 16.3 (0.63 - 0.64)
Valve seat width		0.90 - 1.10 (0.035 - 0.043)	
Valve spring free length	IN	39.5 (1.56)	
	EX	39.5 (1.56)	
Cylinder head warpage		-	
			0.10 (0.004)

**CLUTCH/STARTER CLUTCH SPECIFICATIONS**

Unit: mm (in)

ITEM		STANDARD	SERVICE LIMIT
Specified clutch fluid		DOT 4 brake fluid	-
Clutch master cylinder	Master cylinder I.D.	12.700 - 12.743 (0.5000 - 0.5017)	12.755 (0.5022)
	Master piston O.D.	12.657 - 12.684 (0.4983 - 0.4994)	12.645 (0.4978)
Clutch	Spring free length		58.2 (2.29)
	Disc A thickness		3.72 - 3.88 (0.146 - 0.153)
	Disc B thickness		3.22 - 3.38 (0.127 - 0.133)
	Plate warpage		-
Clutch outer guide A (Without ID mark)	I.D.	27.993 - 28.003 (1.1021 - 1.1025)	28.012 (1.1028)
	O.D.	35.004 - 35.012 (1.3781 - 1.3784)	34.994 (1.3777)
Clutch outer guide B (With ID mark)	I.D.	27.993 - 28.003 (1.1021 - 1.1025)	28.012 (1.1028)
	O.D.	34.996 - 35.004 (1.3778 - 1.3781)	34.986 (1.3774)
Primary driven gear I.D.	A	41.008 - 41.016 (1.6145 - 1.6148)	41.026 (1.6152)
	B	41.000 - 41.008 (1.6142 - 1.6145)	41.018 (1.6149)
Oil pump drive sprocket guide	I.D.	28.000 - 28.021 (1.1024 - 1.1032)	28.030 (1.1035)
	O.D.	34.975 - 34.991 (1.3770 - 1.3776)	34.965 (1.3766)
Oil pump drive sprocket I.D.		35.025 - 35.145 (1.3789 - 1.3837)	35.155 (1.3841)
Mainshaft O.D. at clutch outer guide		27.980 - 27.990 (1.1016 - 1.1020)	27.96 (1.101)
Mainshaft O.D. at oil pump drive sprocket guide		27.980 - 27.990 (1.1016 - 1.1020)	27.96 (1.101)
Starter idle gear	Gear I.D.	10.013 - 10.035 (0.3942 - 0.3951)	10.05 (0.396)
	Shaft O.D.	9.991 - 10.000 (0.3933 - 0.3937)	9.98 (0.393)
Starter driven gear boss O.D.		45.657 - 45.673 (1.7975 - 1.7981)	45.642 (1.7969)

## GENERAL INFORMATION

# TRANSMISSION/GEARSHIFT LINKAGE SPECIFICATIONS

Unit: mm (in)

ITEM		STANDARD	SERVICE LIMIT
Shift fork	I.D.	12.000 – 12.018 (0.4724 – 0.4731)	12.03 (0.474)
	Claw thickness	5.93 – 6.00 (0.233 – 0.236)	5.9 (0.23)
Shift fork shaft O.D.		11.957 – 11.968 (0.4707 – 0.4712)	11.95 (0.470)
Transmission	Gear I.D.	M5, M6	31.000 – 31.025 (1.2205 – 1.2215)
		C1	28.000 – 28.021 (1.1024 – 1.1032)
		C2, C3, C4	33.000 – 33.025 (1.2992 – 1.3002)
	Gear busing O.D.	M5, M6	30.955 – 30.980 (1.2187 – 1.2197)
		C2	32.955 – 32.980 (1.2974 – 1.2984)
		C3, C4	32.950 – 32.975 (1.2972 – 1.2982)
	Gear-to-bushing clearance	M5, M6	0.020 – 0.070 (0.0008 – 0.0028)
		C2	0.020 – 0.070 (0.0008 – 0.0028)
		C3, C4	0.025 – 0.075 (0.0010 – 0.0030)
	Gear bushing I.D.	M5	27.985 – 28.006 (1.1018 – 1.1026)
		C2	29.985 – 30.006 (1.1018 – 1.1026)
	Mainshaft O.D.	at M5	27.967 – 27.980 (1.1011 – 1.1016)
	Countershaft O.D.	at C2	29.967 – 29.980 (1.1798 – 1.1803)
Bushing-to-shaft clearance	M5	0.005 – 0.039 (0.0002 – 0.0015)	
	C2	0.005 – 0.039 (0.0002 – 0.0015)	

# CRANKCASE/CRANKSHAFT/BALANCER/PISTON/CYLINDER SPECIFICATIONS

Unit: mm (in)

ITEM		STANDARD	SERVICE LIMIT	
Crankshaft	Connecting rod side clearance	0.05 – 0.20 (0.002 – 0.008)	0.25 (0.098)	
	Crankpin bearing oil clearance	0.030 – 0.052 (0.0012 – 0.0020)	0.06 (0.002)	
	Main journal bearing oil clearance	0.019 – 0.037 (0.0007 – 0.0015)	0.05 (0.002)	
	Runout	–	0.05 (0.002)	
Piston, piston rings	Piston O.D. at 9.0 (0.35) from bottom	74.960 – 74.980 (2.9512 – 2.9520)	74.895 (2.9486)	
	Piston pin bore I.D.	17.002 – 17.008 (0.6694 – 0.6696)	17.030 (0.6705)	
	Piston pin O.D.	16.994 – 17.000 (0.6690 – 0.6693)	16.980 (0.6685)	
	Piston-to-piston pin clearance	0.002 – 0.014 (0.0001 – 0.0006)	0.04 (0.002)	
	Piston ring end gap	Top	0.17 – 0.27 (0.0067 – 0.0106)	0.52 (0.020)
		Second	0.48 – 0.63 (0.019 – 0.025)	0.82 (0.032)
		Oil (side rail)	0.2 – 0.7 (0.01 – 0.03)	1.0 (0.04)
Piston ring-to-ring groove clearance	Top	0.050 – 0.085 (0.0020 – 0.0033)	0.125 (0.0049)	
	Second	0.015 – 0.045 (0.0006 – 0.0018)	0.075 (0.0030)	
Cylinder	I.D.	75.000 – 75.015 (2.9528 – 2.9533)	75.15 (2.959)	
	Out of round	–	0.10 (0.004)	
	Taper	–	0.10 (0.004)	
	Warpage	–	0.10 (0.004)	
Cylinder-to-piston clearance		0.020 – 0.055 (0.0008 – 0.0022)	0.10 (0.004)	
Connecting rod small end I.D.		17.030 – 17.042 (0.6705 – 0.6709)	17.048 (0.6712)	
Connecting rod-to-piston pin clearance		0.030 – 0.046 (0.0012 – 0.0018)	0.07 (0.003)	

**FRONT WHEEL/SUSPENSION/STEERING SPECIFICATIONS**

Unit: mm (in)

ITEM		STANDARD	SERVICE LIMIT	
Minimum tire tread depth		-	1.5 (0.06)	
Cold tire pressure	Driver only	250 kPa (2.50 kgf/cm <sup>2</sup> , 36 psi)	-	
	Driver and passenger	250 kPa (2.50 kgf/cm <sup>2</sup> , 36 psi)	-	
Axle runout		-	0.2 (0.01)	
Wheel rim runout	Radial	-	2.0 (0.08)	
	Axial	-	2.0 (0.08)	
Wheel balance weight		-	60 g (2.1 oz) max.	
Fork	Spring free length		249.7 (9.83)	
	Fork tube runout		-	
	Recommended fork fluid		Honda ULTRA CUSHION OIL 10W or equivalent	
	Fluid level	CB1000R	91 (3.6)	-
		CB1000RA	67 (2.6)	-
	Fluid capacity	CB1000R	511 ± 2.5 cm <sup>3</sup> (17.3 ± 0.08 US oz, 18.0 ± 0.09 Imp oz)	-
		CB1000RA	542 ± 2.5 cm <sup>3</sup> (18.4 ± 0.08 US oz, 19.1 ± 0.09 Imp oz)	-
	Pre-load adjuster initial setting		8 turns from minimum	-
Rebound damping adjuster initial setting		2 turns out from full hard	-	
Compression damping adjuster initial setting		2 turns out from full hard	-	
Steering head bearing pre-load		9.8 – 12.5 N (1.0 – 1.3 kgf, 2.2 – 2.9 lbf)	-	

**REAR WHEEL/SUSPENSION SPECIFICATIONS**

Unit: mm (in)

ITEM		STANDARD	SERVICE LIMIT
Minimum tire tread depth		-	2.0 (0.08)
Cold tire pressure	Driver only	290 kPa (2.90 kgf/cm <sup>2</sup> , 42 psi)	-
	Driver and passenger	290 kPa (2.90 kgf/cm <sup>2</sup> , 42 psi)	-
Axle runout		-	0.2 (0.01)
Wheel rim runout	Radial	-	2.0 (0.08)
	Axial	-	2.0 (0.08)
Wheel balance weight		-	60 g (2.1 oz) max.
Drive chain	Size/link	DID	-
	Slack	DID50VA8-116YB 25 – 35 (1 – 1-3/8)	-
Shock absorber	spring pre-load adjuster standard position	Position 3	-
	Rebound adjuster initial setting	1-1/2 turns out from full hard	-

## GENERAL INFORMATION

# HYDRAULIC BRAKE SPECIFICATIONS

Unit: mm (in)

ITEM		STANDARD	SERVICE LIMIT	
Front	Specified brake fluid	DOT 4 brake fluid	-	
	Brake disc thickness	4.5 (0.18)	3.5 (0.14)	
	Brake disc runout	-	0.30 (0.012)	
	Master cylinder I.D.	CB1000R	19.050 - 19.093 (0.7500 - 0.7517)	19.105 (0.7522)
		CB1000RA	17.460 - 17.503 (0.6874 - 0.6891)	17.515 (0.6896)
	Master piston O.D.	CB1000R	19.018 - 19.043 (0.7487 - 0.7497)	19.006 (0.7483)
		CB1000RA	17.321 - 17.367 (0.6819 - 0.6837)	17.309 (0.6815)
	Caliper cylinder I.D. (CB1000R)	Upper	32.080 - 32.130 (1.2630 - 1.2650)	32.140 (1.2654)
		Lower	30.280 - 30.330 (1.1921 - 1.1941)	30.340 (1.1945)
	Left caliper cylinder I.D. (CB1000RA)	Upper	25.400 - 25.450 (1.0000 - 1.0020)	25.460 (1.0024)
		Middle	22.650 - 22.700 (0.8917 - 0.8937)	22.712 (0.8942)
		Lower	25.400 - 25.450 (1.0000 - 1.0020)	25.460 (1.0024)
	Right caliper cylinder I.D. (CB1000RA)	Upper	27.000 - 27.050 (1.0630 - 1.0650)	27.062 (1.0654)
		Middle	22.650 - 22.700 (0.8917 - 0.8937)	22.712 (0.8942)
		Lower	27.000 - 27.050 (1.0630 - 1.0650)	27.062 (1.0654)
	Caliper piston O.D. (CB1000R)	Upper	31.967 - 32.000 (1.2585 - 1.2598)	31.957 (1.2581)
		Lower	30.167 - 30.200 (1.1877 - 1.1890)	30.157 (1.1873)
	Left caliper piston O.D. (CB1000RA)	Upper	25.318 - 25.368 (0.9968 - 0.9987)	25.310 (0.9965)
		Middle	22.585 - 22.618 (0.8892 - 0.8905)	22.560 (0.8882)
Lower		25.318 - 25.368 (0.9968 - 0.9987)	25.310 (0.9965)	
Right caliper piston O.D. (CB1000RA)	Upper	26.935 - 26.968 (1.0604 - 1.0617)	26.923 (1.0600)	
	Middle	22.585 - 22.618 (0.8892 - 0.8905)	22.560 (0.8882)	
	Lower	26.935 - 26.968 (1.0604 - 1.0617)	26.923 (1.0600)	
Rear	Specified brake fluid	DOT 4 brake fluid	-	
	Brake disk thickness	5.0 (0.20)	4.0 (0.16)	
	Brake disc runout	-	0.30 (0.012)	
	Master cylinder I.D.	CB1000R	15.870 - 15.913 (0.6248 - 0.6265)	15.925 (0.6270)
		CB1000RA	17.460 - 17.503 (0.6874 - 0.6891)	17.515 (0.6896)
	Master piston O.D.	CB1000R	15.827 - 15.854 (0.6231 - 0.6242)	15.815 (0.6226)
		CB1000RA	17.321 - 17.367 (0.6819 - 0.6837)	17.309 (0.6815)
	Caliper cylinder I.D.	27.000 - 27.050 (1.0630 - 1.0650)	27.060 (1.0654)	
	Caliper piston O.D.	26.918 - 26.968 (1.0598 - 1.0617)	26.910 (1.0594)	

## BATTERY/CHARGING SYSTEM SPECIFICATIONS

ITEM		SPECIFICATIONS	
Battery	Capacity	12 V - 8.6 Ah	
	Current leakage	2.0 mA max.	
	Voltage (20°C/68°F)	Fully charged	13.0 - 13.2 V
		Needs charging	Below 12.3 V
	Charging current	Normal	0.9 A/5 - 10 h
Quick		4.5 A/1 h	
Alternator	Capacity	0.350 kW/5,000 min <sup>-1</sup> (rpm)	
	Charging coil resistance (20°C/68°F)	0.1 - 1.0 Ω	

## IGNITION SYSTEM SPECIFICATIONS

ITEM		SPECIFICATIONS
Spark plug	NGK	IMR9E-9HES
	DENSO	VUH27ES
Spark plug gap		0.80 - 0.90 mm (0.031 - 0.035 in)
Ignition coil peak voltage		100 V minimum
CKP sensor peak voltage		0.7 V minimum
Ignition timing ("F" mark)		5° BTDC at idle

**ELECTRIC STARTER SPECIFICATION**

Unit: mm (in)

ITEM	STANDARD	SERVICE LIMIT
Starter motor brush length	12.0 (0.47)	6.5 (0.26)

**LIGHTS/METERS/SWITCHES SPECIFICATIONS**

ITEM		SPECIFICATIONS	
Bulbs	Headlight	Hi	12 V – 60 W
		Lo	12 V – 55 W
	Position light	LED	
	Brake/tail light	LED	
	License light	12 V – 5 W	
	Turn signal light	12 V – 21 W x 4	
	Instrument light	LED	
	Turn signal indicator	LED	
	High beam indicator	LED	
	Neutral indicator	LED	
	MIL	LED	
	Engine oil pressure indicator	LED	
	Engine coolant temperature indicator	LED	
	Immobilizer system (HISS) indicator	LED	
	ABS indicator (CB1000RA)	LED	
Fuse	Main fuse	30 A	
	PGM-FI/IGN fuse	20 A	
	Sub fuse	10 A x 5, 20 A x 1	
	ABS main fuse (CB1000RA)	10 A	
	ABS fail-safe relay fuse (CB1000RA)	30 A	
	ABS motor fuse (CB1000RA)	30 A	
Tachometer peak voltage		10.5 V minimum	
ECT sensor resistance	80 °C (176 °F)	2.1 – 2.6 kΩ	
	120 °C (248 °F)	0.65 – 0.73 kΩ	

## GENERAL INFORMATION

# STANDARD TORQUE VALUES

FASTENER TYPE	TORQUE		FASTENER TYPE	TORQUE	
	N·m (kgf·m, lbf·ft)			N·m (kgf·m, lbf·ft)	
5 mm hex bolt and nut	5.2 (0.5, 3.8)		5 mm screw	4.2 (0.4, 3.1)	
6 mm hex bolt and nut	10 (1.0, 7)		6 mm screw	9.0 (0.9, 6.6)	
8 mm hex bolt and nut	22 (2.2, 16)		6 mm flange bolt (8 mm head, small flange)	10 (1.0, 7)	
10 mm hex bolt and nut	34 (3.5, 25)		6 mm flange bolt (8 mm head, large flange)	12 (1.2, 9)	
12 mm hex bolt and nut	54 (5.5, 40)		6 mm flange bolt (10 mm head) and nut	12 (1.2, 9)	
			8 mm flange bolt and nut	27 (2.8, 20)	
			10 mm flange bolt and nut	39 (4.0, 29)	

## ENGINE & FRAME TORQUE VALUES

- Torque specifications listed below are for important fasteners.
- Others should be tightened to standard torque values listed above.

### ENGINE

#### MAINTENANCE

ITEM	Q'TY	THREAD DIA. (mm)	TORQUE N·m (kgf·m, lbf·ft)	REMARKS
Spark plug	4	10	16 (1.6, 12)	Apply grease to the threads. Apply engine oil to the threads and O-ring. Apply a locking agent to the threads.
Timing hole cap	1	45	18 (1.8, 13)	
Engine oil filter cartridge	1	20	26 (2.7, 19)	
Oil filter boss	1	20	See page 3-16	
Engine oil drain bolt	1	12	30 (3.1, 22)	

#### LUBRICATION SYSTEM

ITEM	Q'TY	THREAD DIA. (mm)	TORQUE N·m (kgf·m, lbf·ft)	REMARKS
Oil pump assembly bolt	3	6	8.0 (0.8, 6)	CT bolt
Oil pump driven sprocket bolt	1	6	15 (1.5, 11)	Apply a locking agent to the threads.

#### FUEL SYSTEM (PGM-FI)

ITEM	Q'TY	THREAD DIA. (mm)	TORQUE N·m (kgf·m, lbf·ft)	REMARKS
Insulator band screw (Throttle body side)	4	5	See page 5-88	
Insulator band screw (Cylinder head side)	4	5	See page 5-77	
Fuel rail mounting bolt	4	5	5.1 (0.5, 3.8)	
IACV setting plate screw	2	4	2.1 (0.2, 1.5)	
IACV joint screw	1	4	2.1 (0.2, 1.5)	

#### COOLING SYSTEM

ITEM	Q'TY	THREAD DIA. (mm)	TORQUE N·m (kgf·m, lbf·ft)	REMARKS
Water pump assembly bolt	2	6	12 (1.2, 9)	CT bolt

#### ENGINE REMOVAL/INSTALLATION

ITEM	Q'TY	THREAD DIA. (mm)	TORQUE N·m (kgf·m, lbf·ft)	REMARKS
Drive sprocket bolt	1	10	54 (5.5, 40)	



**CYLINDER HEAD/VALVES**

ITEM	Q'TY	THREAD DIA. (mm)	TORQUE N-m (kgf-m, lbf-ft)	REMARKS
Cylinder head mounting bolt	10	9	51 (5.2, 38)	Apply molybdenum oil solution to the threads and seating surface.
Camshaft holder flange bolt	20	6	12 (1.2, 9)	
Cylinder head sealing bolt	2	18	28 (2.9, 21)	Apply a locking agent to the threads.
Cylinder head cover bolt	4	6	10 (1.0, 7)	Apply a locking agent to the threads.
PAIR read valve cover bolt	4	6	12 (1.2, 9)	
Cam sprocket flange knock bolt	4	7	20 (2.0, 15)	Apply a locking agent to the threads.
Cam chain tensioner pivot bolt	1	6	10 (1.0, 7)	Apply a locking agent to the threads.
Cam chain guide torx bolt	1	6	12 (1.2, 9)	Apply a locking agent to the threads.
Exhaust pipe stud bolt	8	8	See page 2-23	

**CLUTCH/STARTER CLUTCH**

ITEM	Q'TY	THREAD DIA. (mm)	TORQUE N-m (kgf-m, lbf-ft)	REMARKS
Clutch center lock nut	1	25	128 (13.1, 94)	Apply engine oil to the threads and seating surface. Stake.
Clutch spring bolt	5	6	12 (1.2, 9)	Apply a locking agent to the threads. CT bolt
Clutch hose oil bolt	2	10	34 (3.5, 25)	
Right crankcase cover rubber damper set plate bolt	1	6	12 (1.2, 9)	
Starter clutch outer mounting bolt	1	10	83 (8.5, 61)	

**ALTERNATOR**

ITEM	Q'TY	THREAD DIA. (mm)	TORQUE N-m (kgf-m, lbf-ft)	REMARKS
Flywheel flange bolt	1	10	103 (10.5, 76)	Apply engine oil to the threads and seating surface.
Stator mounting socket bolt	4	6	12 (1.2, 9)	

**TRANSMISSION/GEARSHIFT LINKAGE**

ITEM	Q'TY	THREAD DIA. (mm)	TORQUE N-m (kgf-m, lbf-ft)	REMARKS
Transmission holder mounting bolt	6	8	29 (3.0, 21)	Apply a locking agent to the threads.
Countershaft bearing set plate bolt	1	6	12 (1.2, 9)	
Mainshaft bearing set plate bolt	3	6	12 (1.2, 9)	Apply a locking agent to the threads.
Shift drum center socket bolt	1	8	23 (2.3, 17)	Apply a locking agent to the threads.
Shift drum stopper arm pivot bolt	1	6	12 (1.2, 9)	Apply a locking agent to the threads.
Gearshift spindle return spring pin	1	8	23 (2.3, 17)	
Shift drum bearing setting bolt	2	6	12 (1.2, 9)	Apply a locking agent to the threads.
Gearshift cam bolt	1	6	12 (1.2, 9)	Apply a locking agent to the threads.

## GENERAL INFORMATION

### CRANKCASE/CRANKSHAFT/BALANCER/PISTON

ITEM	Q'TY	THREAD DIA. (mm)	TORQUE N·m (kgf·m, lbf·ft)	REMARKS
Crankcase 7mm bolt	12	7	18 (1.8, 13)	
8mm bolt	6	8	24 (2.4, 18)	
9mm bolt (main journal bolt)	10	9	See page 12-27	
Lower crankcase sealing bolt	1	22	59 (6.0, 44)	Apply a locking agent to the threads.
Lower crankcase socket bolt	1	10	12 (1.2, 9)	Apply a locking agent to the threads.
Lower crankcase sealing bolt	1	20	30 (3.1, 22)	Apply a locking agent to the threads.
Lower crankcase socket bolt	1	8	23 (2.3, 17)	Apply a locking agent to the threads.
Connecting rod bolt (new bolt)	8	8	See page 12-27	Apply engine oil to the threads and seating surface.
Connecting rod bolt (retightening)	8	8	See page 12-14	Apply engine oil to the threads and seating surface.

### ELECTRIC STARTER

ITEM	Q'TY	THREAD DIA. (mm)	TORQUE N·m (kgf·m, lbf·ft)	REMARKS
Starter motor terminal nut	1	6	12 (1.2, 9)	

### LIGHTS/METERS/SWITCHES

ITEM	Q'TY	THREAD DIA. (mm)	TORQUE N·m (kgf·m, lbf·ft)	REMARKS
EOP switch	1	PT 1/8	12 (1.2, 9)	Apply sealant to the threads.
EOP switch wire terminal bolt	1	4	2.0 (0.2, 1.5)	
Neutral switch	1	10	12 (1.2, 9)	

**FRAME**

**FRAME/BODY PANELS/EXHAUST SYSTEM**

ITEM	Q'TY	THREAD DIA. (mm)	TORQUE N·m (kgf·m, lbf·ft)	REMARKS
Exhaust pipe joint nut	8	7	12 (1.2, 9)	
Exhaust pipe mounting bolt	1	8	22 (2.2, 16)	
Muffler front/rear mounting bolt/ nut	1/1	8	22 (2.2, 16)	
Exhaust pipe/muffler protector socket bolt	6	6	12 (1.2, 9)	
Muffler band bolt	1	8	22 (2.2, 16)	
Exhaust pipe band bolt	2	8	22 (2.2, 16)	
Front fender mounting bolt	4	6	12 (1.2, 9)	
Seat rail upper mounting nut	1	10	39 (4.0, 29)	
Seat rail lower mounting bolt	2	10	39 (4.0, 29)	
Pivot bracket upper nut	1	12	69 (7.0, 51)	
Pivot bracket lower nut	1	12	69 (7.0, 51)	
Rear fender A screw	5	5	3.0 (0.3, 2.2)	
Reflector mounting nut (U type only)	2	6	1.8 (0.2, 1.3)	

**MAINTENANCE**

ITEM	Q'TY	THREAD DIA. (mm)	TORQUE N·m (kgf·m, lbf·ft)	REMARKS
Lower throttle cable adjuster lock nut	1	6	5.5 (0.6, 4.0)	
Air cleaner duct mounting screw	3	5	1.1 (0.1, 0.8)	

**FUEL SYSTEM (PGM-FI)**

ITEM	Q'TY	THREAD DIA. (mm)	TORQUE N·m (kgf·m, lbf·ft)	REMARKS
Fuel tank rear mounting nut	1	6	12 (1.2, 9)	
Fuel filler cap mounting bolt	3	4	1.8 (0.2, 1.3)	
Fuel pump mounting nut	7	6	12 (1.2, 9)	See page 5-59
ECT sensor	1	12	23 (2.3, 17)	
O <sub>2</sub> sensor	1	12	24.5 (2.5, 18)	
Right resonator air duct screw	1	4	0.8 (0.1, 0.6)	
Right front resonator screw	1	5	1.1 (0.1, 0.8)	
Right air cleaner duct screw	3	5	1.1 (0.1, 0.8)	
Upper air cleaner housing screw	9	5	1.1 (0.1, 0.8)	
Air cleaner housing mounting bolt	1	6	3.5 (0.4, 2.6)	

**COOLING SYSTEM**

ITEM	Q'TY	THREAD DIA. (mm)	TORQUE N·m (kgf·m, lbf·ft)	REMARKS
Radiator upper mounting bolt	2	6	3.5 (0.4, 2.6)	
Thermostat housing stay bolt	1	6	3.5 (0.4, 2.6)	
Fan motor mounting bolt	3	5	5.0 (0.5, 3.7)	
Cooling fan mounting nut	1	5	2.7 (0.3, 2.0)	
Fan motor shroud mounting bolt	4	6	4.4 (0.4, 3.0)	

**ENGINE REMOVAL/INSTALLATION**

ITEM	Q'TY	THREAD DIA. (mm)	TORQUE N·m (kgf·m, lbf·ft)	REMARKS
Front engine hanger nut	4	10	49 (5.0, 36)	
Front engine hanger bolt	2	12	59 (6.0, 44)	
Rear engine hanger nut	2	10	49 (5.0, 36)	
Rear engine mounting nut	2	12	59 (6.0, 44)	

## GENERAL INFORMATION

### CLUTCH/STARTER CLUTCH

ITEM	Q'TY	THREAD DIA. (mm)	TORQUE N·m (kgf·m, lbf·ft)	REMARKS
Clutch lever pivot bolt	1	6	1.0 (0.1, 0.7)	Apply silicone grease to the sliding surface.  Apply a locking agent to the threads.
Clutch lever pivot nut	1	6	5.9 (0.6, 4.4)	
Clutch master cylinder oil cup mounting screw	1	4	1.5 (0.15, 1.1)	
Clutch master cylinder reservoir cap stopper plate screw	1	4	1.2 (0.1, 0.9)	
Clutch master cylinder holder bolt	2	6	12 (1.2, 9)	
Clutch master cylinder oil cup stopper plate screw	1	4	1.2 (0.1, 0.9)	
Clutch switch mounting screw	1	4	1.2 (0.1, 0.9)	

### FRONT WHEEL/SUSPENSION/STEERING

ITEM	Q'TY	THREAD DIA. (mm)	TORQUE N·m (kgf·m, lbf·ft)	REMARKS
Handlebar holder bolt	4	8	27 (2.8, 20)	Apply engine oil to the threads.  Apply a locking agent to the threads.  ALOC bolt; replace with a new one. ALOC bolt; replace with a new one.
Right handlebar switch screw	2	4	0.9 (0.1, 1.0)	
Left handlebar switch screw	2	5	2.7 (0.3, 2.0)	
Steering stem adjusting lock nut	1	26	See page 13-41	
Steering stem adjusting nut	1	26	26 (2.7, 19)	
Steering stem nut	1	24	103 (10.5, 76)	
Bottom bridge pinch bolt	4	8	27 (2.8, 20)	
Top bridge pinch bolt	2	8	22 (2.2, 16)	
Fork bolt	2	46	34 (3.5, 25)	
Fork socket bolt	2	10	34 (3.5, 25)	
Fork bolt lock nut	2	8	20 (2.0, 15)	
Front axle pinch bolt	2	8	22 (2.2, 16)	
Front axle bolt	1	14	59 (6.0, 44)	
Front brake disc mounting bolt	12	6	20 (2.0, 15)	
Front pulser ring mounting bolt (CB1000RA)	3	5	7.0 (0.7, 5.2)	

### REAR WHEEL/SUSPENSION

ITEM	Q'TY	THREAD DIA. (mm)	TORQUE N·m (kgf·m, lbf·ft)	REMARKS
Rear axle nut	1	35	201 (20.5, 148)	Stake
Rear wheel nut	4	12	108 (11.0, 80)	U-nut
Rear brake disc nut	4	8	34 (3.5, 25)	
Driven sprocket nut	6	10	64 (6.5, 47)	U-nut
Shock absorber mounting nut	2	10	42 (4.3, 31)	
Swingarm pivot nut	1	18	98 (10.0, 72)	U-nut
Footpeg holder mounting bolt	4	8	37 (3.8, 27)	Aloc bolt; replace with a new one. Aloc bolt; replace with a new one. Aloc bolt; replace with a new one.
Axle bearing holder pinch bolt	1	16	74 (7.5, 54)	
Drive chain slider socket bolt	4	5	4.2 (0.4, 3.0)	
Drive chain guide socket bolt	2	5	4.2 (0.4, 3.0)	
Drive chain case A mounting bolt	3	5	4.2 (0.4, 3.0)	
Air guide mounting bolt	2	5	4.2 (0.4, 3.0)	
Drive chain case B mounting bolt	1	5	1.7 (0.2, 1.0)	

HYDRAULIC BRAKE

ITEM	Q'TY	THREAD DIA. (mm)	TORQUE N·m (kgf·m, lbf·ft)	REMARKS
Brake hose oil bolt				
CB1000R:	5	10	34 (3.5, 25)	
CB1000RA:	6	10	34 (3.5, 25)	
Front brake caliper mounting bolt				
CB1000R:	4	10	45 (4.6, 33)	ALOC bolt; replace with a new one.
CB1000RA:	4	8	30 (3.1, 22)	
Front caliper bleed valve				
CB1000R:	2	8	7.9 (0.8, 6.0)	
Front and rear caliper bleed valve				
CB1000RA:	4	8	5.4 (0.6, 4.0)	
Rear caliper bleed valve	1	8	5.4 (0.6, 4.0)	
Front brake pad pin				
CB1000R:	4	10	15.2 (1.5, 11)	
Front brake pad pin				
CB1000RA:	2	10	17 (1.7, 13)	
Rear brake pad pin	1	10	17 (1.7, 13)	
Rear brake caliper pin bolt	1	12	27 (2.8, 20)	
Rear brake caliper mounting bolt	2	8	30 (3.1, 22)	ALOC bolt; replace with a new one.
Front master cylinder holder bolt	2	6	12 (1.2, 9)	
Brake lever pivot bolt	1	6	1.0 (0.1, 0.7)	Apply silicone grease to the sliding surface.
Brake lever pivot nut	1	6	5.9 (0.6, 4.4)	
Front brake light switch screw	1	4	1.2 (0.1, 0.9)	
Rear master cylinder mounting bolt	2	6	12 (1.2, 9)	
Rear master cylinder reservoir hose joint screw	1	4	1.5 (0.2, 1.1)	Apply a locking agent to the threads.
Rear master cylinder push rod joint nut	1	8	17 (1.7, 13)	
Front master cylinder reservoir cap stopper plate screw	1	4	1.2 (0.1, 0.9)	
Front master cylinder oil cup mounting screw	1	4	1.5 (0.2, 1.1)	Apply a locking agent to the threads.
Rear master cylinder reservoir mounting bolt	1	6	10 (1.0, 7)	
Rear master cylinder reservoir cap stopper plate screw	1	4	1.2 (0.1, 0.9)	
Front brake hose clamp bolt/nut				
CB1000R:	1/2	6	12 (1.2, 9)	ALOC bolt; replace with a new one.
CB1000RA:	3	6	10 (1.0, 7)	

ABS (Anti-lock Brake System): CB1000RA

ITEM	Q'TY	THREAD DIA. (mm)	TORQUE N·m (kgf·m, lbf·ft)	REMARKS
Brake pipe joint nut	16	10	14 (1.4, 10)	Apply brake fluid to the threads.
PCV mounting bolt	2	6	12 (1.2, 9)	
Delay valve mounting bolt	2	6	12 (1.2, 9)	

## GENERAL INFORMATION

### LIGHTS/METERS/SWITCHES

ITEM	Q'TY	THREAD DIA. (mm)	TORQUE N·m (kgf·m, lbf·ft)	REMARKS
Ignition switch mounting bolt	2	8	25 (2.5, 18)	One-way bolt
License light mounting nut	2	5	1.7 (0.2, 1.3)	
Sidestand switch bolt	1	6	10 (1.0, 7)	
Clutch switch mounting screw	1	4	1.2 (0.1, 0.9)	

### OTHERS

ITEM	Q'TY	THREAD DIA. (mm)	TORQUE N·m (kgf·m, lbf·ft)	REMARKS
Sidestand pivot bolt	1	10	See page 2-27	ALOC bolt; replace with a new one.
Sidestand pivot nut	1	10	39 (4.0, 29)	
Sidestand bracket socket bolt	2	10	55 (5.6, 41)	
Gearshift pedal pivot bolt	1	8	27 (2.8, 20)	
Gearshift arm pinch bolt	1	6	20 (2.0, 15)	
Ignition coil stay mounting bolt	4	6	3.5 (0.4, 2.6)	

**LUBRICATION & SEAL POINTS****ENGINE**

MATERIAL	LOCATION	REMARKS
Liquid sealant (Three Bond 1207B or equivalent)	Crankcase mating surface Oil pan mating surface Right crankcase cover mating surface Alternator cover mating surface EOP switch threads Gearshift linkage cover Alternator cover wire grommet	See page 12-24 See page 4-7 See page 9-34 See page 10-5 See page 4-5
Liquid sealant (Three Bond 5211C or equivalent)	Cylinder head semi-circular cut-out	See page 8-31
Molybdenum disulfide oil (a mixture of 1/2 engine oil and 1/2 molybdenum disulfide grease)	Main journal bearing surface Piston pin sliding surface Connecting rod bearing surface Connecting rod small end inner surface Crankshaft thrust surface Camshaft lobes, journals and thrust surface  Valve stem (valve guide sliding surface) Valve lifter outer sliding surface Clutch outer/primary driven gear sliding surface Clutch outer guide sliding surface Oil pump drive sprocket and collar sliding surface M3/4, C5, C6 shifter gear (shift fork grooves) Starter reduction gear shaft sliding surface Starter idle gear shaft sliding surface Water pump shaft thrust washer sliding surface Cylinder head mounting bolt threads and seating surface	Do not apply mating surface of the camshaft holder
Engine oil	Piston and piston ring sliding surface Oil strainer packing whole surface Clutch lifter piece sliding surface Clutch lifter rod outer surface Clutch disc whole surface Starter one-way clutch sliding surface Flywheel bolt threads and seating surface Clutch center lock nut threads and seating surface Oil filter cartridge threads and O-ring surface Camshaft holder bolt threads and seating surface Starter clutch mounting bolt threads and seating surface Connecting rod bolt threads and seating surface Each gear teeth and rotating surface Each bearing rolling surface Each O-ring whole surface Other rotating area and sliding surface	
Multi-purpose grease	Timing hole cap threads Balancer damper rubber fitting area Each oil seal lips	

## GENERAL INFORMATION

MATERIAL	LOCATION	REMARKS
Locking agent	Gearshift linkage cover bolt threads Lower crankcase 22 mm sealing bolt threads Lower crankcase 20 mm sealing bolt threads Lower crankcase 10 mm sealing bolt threads Lower crankcase 8 mm sealing bolt threads Cam chain guide A pivot bolt threads Cylinder head cover breather joint threads Oil pump driven sprocket bolt threads Shift drum bearing setting bolt threads Oil filter boss threads (stud side) Right crankcase cover damper rubber plate bolt threads Mainshaft/countershaft bearing set plate bolt threads Cam sprocket bolt threads Shift drum center bolt threads Cam chain tensioner pivot bolt threads Gearshift cam bolt threads Orifice bolt	See page 11-9      Coating width: $6.5 \pm 1$ mm Coating width: $6.5 \pm 1$ mm Coating width: $6.5 \pm 1$ mm Coating width: $6.5 \pm 1$ mm  Coating width: $6.5 \pm 1$ mm  Coating width: $6.5 \pm 1$ mm Coating width: $6.5 \pm 1$ mm Coating width: $6.5 \pm 1$ mm Coating width: $6.5 \pm 1$ mm Coating width: $6.5 \pm 1$ mm




FRAME


MATERIAL	LOCATION	REMARKS
Multi-purpose grease	Sidestand pivot sliding area Throttle cable end Driven sprocket hub bearing dust seal lips Driver footpeg sliding area Passenger footpeg sliding area Gearshift pedal link tie-rod ball joints Gearshift pedal pivot sliding area Rear brake pedal pivot sliding area Front wheel dust seal lips Seat lock cable end	
Molybdenum disulfide grease	Swingarm pivot dust seal lips Swingarm pivot needle bearings Driven flange O-ring Bearing holder dust seal lip	
Grease (REPSOL MP2)	Shock absorber pivot dust seal lips Shock absorber needle bearings	
Urea based multi-purpose grease with extreme pressure agent (example: EXCELITE EP2 manufactured by KYODO YUSHI, Japan), Shell Stamina EP2 or equivalent	Upper and lower steering head bearing Steering head dust seal lips	Apply 3 – 5 g each
Molybdenum paste	Shock absorber spring adjuster cam sliding area	
Engine oil	Steering head bearing adjusting nut threads	
Cable lubricant	Throttle cable A, B casing inside	
Honda bond A or equivalent	Handlebar grip rubber inside	
Silicone grease	Brake caliper main and sub slide pin sliding surfaces Brake pad pin stopper ring Front brake lever pivot/adjuster/push rod sliding area Front brake lever pivot Front brake lever-to-master piston contact area Rear master cylinder push rod-to-master piston contact area Clutch master piston contact area Clutch lever pivot Clutch lever joint piece-to-push rod contact area Rear master cylinder push rod boot inside Brake caliper dust seals	Apply 0.4 g each  Apply 0.1 g Apply 0.1 g Apply 0.1 g  Apply 0.1 g Apply 0.1 g Apply 0.1 g
DOT 4 brake fluid	Master cylinder inside Brake master pistons and cups Brake caliper pistons and piston seals Brake pipe threads	
Fork fluid	Fork cap O-ring Fork dust seal and oil seal lips	
Locking agent	Brake caliper sub slider pin threads Rear master cylinder connector screw Fork socket bolt threads Caliper bracket retainer Clutch master cylinder oil cup mounting screw Front master cylinder oil cup mounting screw	

# CABLE & HARNESS ROUTING


CB1000R:




CB1000RA:





CB1000R:




CB1000RA:




# GENERAL INFORMATION



CB1000R:




CB1000RA:





# GENERAL INFORMATION

CB1000R:




CB1000RA:






# GENERAL INFORMATION



CB1000R:




CB1000RA:







# GENERAL INFORMATION



INTAKE AIR DUCT VACUUM HOSE  
(To intake air duct diaphragm)

INTAKE AIR DUCT CONTROL  
VALVE 2P (Gray) CONNECTOR

TP SENSOR 3P (Black)  
CONNECTOR

SIDESTAND SWITCH  
2P (Black) CONNECTOR

ALTERNATOR WIRE

LOWER RADIATOR HOSE

RADIATOR  
BYPASS HOSE

SIDESTAND  
SWITCH WIRE

RADIATOR RESERVE TANK OVERFLOW HOSE

**GUIDE:**


- FUEL TANK DRAIN HOSE
- RADIATOR RESERVE TANK OVERFLOW HOSE
- INTAKE AIR DUCT VACUUM HOSE (To intake air duct diaphragm)
- INTAKE AIR DUCT VACUUM HOSE (To vacuum chamber)
- ALTERNATOR WIRE

IAT SENSOR 2P (Gray)  
CONNECTOR


ENGINE SUB-  
HARNESS 6P (Black)  
CONNECTOR

FUEL TANK DRAIN  
HOSE


SIDESTAND SWITCH




# GENERAL INFORMATION





CB1000R:




CB1000RA:




**GENERAL INFORMATION**






# GENERAL INFORMATION

CB1000RA only:






CB1000R:




CB1000RA:






# GENERAL INFORMATION


CB1000R:



CB1000RA:







## EMISSION CONTROL SYSTEMS


### SOURCE OF EMISSIONS

The combustion process produces carbon monoxide (CO), oxides of nitrogen (NOx) and hydrocarbons (HC). Control of carbon monoxide, oxides of nitrogen and hydrocarbons is very important because, under certain conditions, they react to form photochemical smog when subject to sunlight. Carbon monoxide does not react in the same way, but it is toxic.

Honda Motor Co., Ltd. utilizes various systems to reduce carbon monoxide, oxides of nitrogen and hydrocarbons.

### CRANKCASE EMISSION CONTROL SYSTEM

The engine is equipped with a closed crankcase system to prevent discharging crankcase emissions into the atmosphere. Blow-by gas is returned to the combustion chamber through the air cleaner and throttle body.



## GENERAL INFORMATION

### EXHAUST EMISSION CONTROL SYSTEM

The exhaust emission control system is composed of a pulse secondary air supply system, a three-way catalytic converter and PGM-FI system.

No adjustment should be made for the exhaust emission control system. The exhaust emission control system is separate from the crankcase emission control system.


#### SECONDARY AIR SUPPLY SYSTEM

The pulse secondary air supply system introduces filtered air into the exhaust gases in the exhaust port. Fresh air is drawn into the exhaust port by the function of the PAIR control valve.

This charge of fresh air promotes burning of the unburned exhaust gases and changes a considerable amount of hydrocarbons and carbon monoxide into relatively harmless carbon dioxide and water vapor.

The reed valve prevents reverse air flow through the system. The PAIR control valve is operated by the solenoid valve. The solenoid valve is controlled by the PGM-FI unit, and the fresh air passage is opened/closed according the running condition.

No adjustments to the secondary air supply system should be made, although periodic inspection of the components is recommended.



#### THREE-WAY CATALYTIC CONVERTER

This motorcycle is equipped with a three-way catalytic converter.

The three-way catalytic converter is in the exhaust system. Through chemical reactions, they convert HC, CO and NOx in the engine's exhaust to carbon dioxide (CO<sub>2</sub>), nitrogen (N<sub>2</sub>) and water vapor.

No adjustment to these systems should be made although periodic inspection of the components is recommended.

---

**NOISE EMISSION CONTROL SYSTEM**

TAMPERING WITH THE NOISE CONTROL SYSTEM IS PROHIBITED: Local law may prohibit the following acts or the causing there of: (1) The removal or rendering inoperative by any person, other than for purposes of maintenance, repair or replacement, of any device or element of design incorporated into any new vehicle for the purpose of noise control prior to its sale or delivery to the ultimate purchaser or while it is in use; (2) the use of the vehicle after such device or element of design has been removed or rendered inoperative by any person.

AMONG THOSE ACTS PRESUMED TO CONSTITUTE TAMPERING ARE THE ACTS LISTED BELOW:

1. Removal of, or puncturing of the muffler, baffles, header pipes or any other component which conducts exhaust gases.
2. Removal of, or puncturing of any part of the intake system.
3. Lack of proper maintenance.
4. Replacing any moving parts of the vehicle, or parts of the exhaust or intake system, with parts other than those specified by the manufacturer.

---

**MEMO**

---




# 2. FRAME/BODY PANELS/EXHAUST SYSTEM

---

BODY PANEL LOCATIONS .....	2-2	METER VISOR .....	2-8
SERVICE INFORMATION .....	2-3	REAR COWL .....	2-9
TROUBLESHOOTING .....	2-3	REAR FENDER A/REAR FENDER STAY....	2-9
SEAT .....	2-4	REAR FENDER A/REAR FENDER STAY/ MUD GUARD (U type) .....	2-11
PROTECTION GRILL .....	2-4	FRONT FENDER .....	2-13
SIDE COVER.....	2-5	SEAT RAIL/REAR FENDER B.....	2-14
SEAT RAIL COVER .....	2-6	EXHAUST SYSTEM .....	2-19
RADIATOR SHROUD .....	2-7	SIDESTAND .....	2-27

# BODY PANEL LOCATIONS

CB1000RA shown:



## SERVICE INFORMATION

### GENERAL

- Work in a well ventilated area. Smoking or allowing flames or sparks in the work area or where gasoline is stored can cause a fire or explosion.
- This section covers removal and installation of the body panels and exhaust system.
- Route the wires and cables properly (page 1-22).
- Serious burns may result if the exhaust system is not allowed to cool before components are removed or serviced.
- Always replace the exhaust pipe gaskets after removing the exhaust pipe from the engine.
- When installing the exhaust system, loosely install all of the exhaust pipe fasteners. Always tighten the exhaust clamps first, then tighten the mounting fasteners. If you tighten the mounting fasteners first, the exhaust pipe may not seat properly.
- Always inspect the exhaust system for leaks after installation.

### TORQUE VALUES

Exhaust pipe joint nut	12 N·m (1.2 kgf·m, 9 lbf·ft)
Exhaust pipe mounting bolt	22 N·m (2.2 kgf·m, 16 lbf·ft)
Muffler front/ rear mounting bolt/nut	22 N·m (2.2 kgf·m, 16 lbf·ft)
Exhaust pipe/muffler protector socket bolt	12 N·m (1.2 kgf·m, 9 lbf·ft)
Muffler band bolt	22 N·m (2.2 kgf·m, 16 lbf·ft)
Exhaust pipe band bolt	22 N·m (2.2 kgf·m, 16 lbf·ft)
Front fender mounting bolt	12 N·m (1.2 kgf·m, 9 lbf·ft)
Seat rail upper mounting nut	39 N·m (4.0 kgf·m, 29 lbf·ft)
Seat rail lower mounting bolt	39 N·m (4.0 kgf·m, 29 lbf·ft)
Pivot bracket upper nut	69 N·m (7.0 kgf·m, 51 lbf·ft)
Pivot bracket lower nut	69 N·m (7.0 kgf·m, 51 lbf·ft)
Reflector mounting nut (U type only)	1.8 N·m (0.2 kgf·m, 1.3 lbf·ft)
Rear fender A screw	3.0 N·m (0.3 kgf·m, 2.2 lbf·ft)
Brake pipe joint nut	14 N·m (1.4 kgf·m, 10 lbf·ft)
Sidestand pivot bolt	See page 2-27
Sidestand pivot nut	39 N·m (4.0 kgf·m, 29 lbf·ft)

Apply brake fluid to the threads.

### TROUBLESHOOTING

#### Excessive exhaust noise

- Broken exhaust system
- Exhaust gas leak

#### Poor performance

- Deformed exhaust system
- Exhaust gas leak
- Clogged muffler

## SEAT

### REMOVAL/INSTALLATION


#### PILLION SEAT

Unlock the pillion seat with the ignition key.

Remove the pillion seat backward while releasing the seat hooks and catch.

Install the pillion seat with inserting the two seat hooks into the frame.

Push the pillion seat forward, then push down to lock it.



#### RIDER SEAT


Remove the pillion seat (page 2-4).

Remove the rider seat mounting bolt and the collar. Remove the rider seat backward while releasing the seat hooks.

Install the rider seat with inserting the two hooks into the frame.

Install the collar and the rider seat mounting bolt. Tighten the rider seat mounting bolt securely.

After installation, make sure that the rider and pillion seats are installed properly by moving the seats.




## PROTECTION GRILL

### REMOVAL/INSTALLATION

Remove the trim clips and protection grill.

Installation is in the reverse order of removal.



## SIDE COVER

### RIGHT SIDE COVER

#### REMOVAL/INSTALLATION

*Be careful not to damage the tab and boss.*

Remove the seat (page 2-4).

Remove the side cover socket bolt.

Release the boss on the right side cover from the grommet on the pivot bracket, then release the tab on the right side cover from the grommet on the fuel tank.

Release the tab on the side cover from the groove on the seat rail cover.


Remove the right side cover.

Install the right side cover aligning its tab and boss with the grommets on the pivot bracket and fuel tank.

Align the tab on the side cover with the groove on the seat rail cover.

Install and tighten the side cover socket bolt securely.

Install the seat (page 2-4).



### LEFT SIDE COVER

#### REMOVAL/INSTALLATION

*Be careful not to damage the tabs.*

Remove the seat (page 2-4).

Remove the side cover socket bolt.

Release the tabs on the left side cover from the grommets on the pivot bracket and fuel tank.

Release the tab on the side cover from the groove on the seat rail cover.


Remove the left side cover.

Install the left side cover aligning its tabs with the grommets on the pivot bracket and fuel tank.

Align the tab on the side cover with the groove on the seat rail cover.

Install and tighten the side cover socket bolt securely.

Install the seat (page 2-4).




#### DISASSEMBLY/ASSEMBLY

Remove the left side cover (page 2-5).

Remove the mat and rubber mounts.

Remove the screws and the sub-left side cover from the left side cover.

Assembly is in the reverse order of disassembly.



## SEAT RAIL COVER

### REMOVAL/INSTALLATION

*Be careful not to damage the tab and hook.*

Remove the seat (page 2-4).

Remove the side cover socket bolt.

Release the groove on the seat rail cover from the tab on the side cover.

Remove the tab on the seat rail cover from the grommet on the seat rail.


Remove the hook on the seat rail cover from the groove on the rear cowl while swinging the seat rail cover front part.

Remove the seat rail cover.

Installation is in the reverse order of removal.

Install and tighten the side cover socket bolt securely.

Install the seat (page 2-4).



# RADIATOR SHROUD


## REMOVAL/INSTALLATION

*Be careful not to damage the bosses and hooks.*

Remove the mounting socket bolts and washers.  
 Remove the guide on the radiator shroud from the fuel tank.  
 Remove the bosses from the grommets on the fuel tank.  
 Remove the hooks on the radiator shroud from the tabs on the radiator, then remove the radiator shroud.  
 Remove the collars from the radiator shroud.

Installation is in the reverse order of removal.

- At installation, align the tabs on the radiator grill with the protection cover.
- Route the radiator siphon hose properly.




## FRAME/BODY PANELS/EXHAUST SYSTEM

### DISASSEMBLY/ASSEMBLY

Remove the screws (Black x2, Silver x5).  
Disassemble the right radiator shroud, radiator grill,  
left radiator shroud and radiator reserve tank protector.

Assembly is in the reverse order of disassembly.



## METER VISOR


### REMOVAL/INSTALLATION

*Be careful not to damage the tabs.*

Remove the clips.

Carefully release the tabs of the meter visor from the headlight unit, then remove the meter visor.

Installation is in the reverse order of removal.





## REAR COWL

### REMOVAL/INSTALLATION

*Be careful not to damage the tabs and hook.*

Remove the socket bolts (front: short x2/rear: long x1).


Remove the grommets on the rear cowl from the tabs on the frame.

Carefully release the tabs on the rear cowl from the grooves on the rear fender B.

Carefully release the grooves on the rear cowl from the tabs on the rear fender B while pulling the rear cowl backward.

Release the hook of the rear cowl from the rear brake/taillight unit, then remove the rear cowl.

Installation is in the reverse order of removal.



## REAR FENDER A/REAR FENDER STAY

### REMOVAL/INSTALLATION

Remove the rear cowl (page 2-9).

Remove the mounting screw.


Release the tabs on the rear fender A from the rear fender stay.

Disconnect the following connector:

- Rear right turn signal 2P (Light blue)
- Rear left turn signal 2P (Orange)
- License light 2P (Natural)

Remove the socket bolts, special nuts and the rear fender stay assembly.

Installation is in the reverse order of removal.



## FRAME/BODY PANELS/EXHAUST SYSTEM

### DISASSEMBLY/ASSEMBLY

Remove the screws and the rear fender A from the rear fender stay.

Remove the mounting nuts, collars and the license light unit from the rear fender stay.


Remove the mounting nuts, setting plates and the rear right/left turn signal light units from the rear fender stay.

Assembly is in the reverse order of disassembly.

#### TORQUE:

Rear fender A screw:

3.0 N·m (0.3 kgf·m, 2.2 lbf·ft)



## REAR FENDER A/REAR FENDER STAY/ MUD GUARD (U type)

### REMOVAL/INSTALLATION

Remove the rear cowl (page 2-9).

Remove the mounting screw.


Release the tabs on the mud guard plate from the rear fender stay, then remove the mud guard plate.

Disconnect the following connector:

- Rear right turn signal 2P (Light blue)
- Rear left turn signal 2P (Orange)
- License light 2P (Natural)

Remove the socket bolts, special nuts, mud guard/rear fender stay assembly.

Installation is in the reverse order of removal.



# FRAME/BODY PANELS/EXHAUST SYSTEM

## DISASSEMBLY/ASSEMBLY

Remove the screws and the rear fender A and mud guard from the rear fender stay.

Remove the mounting nuts and reflectors from the mud guard.

Remove the mounting nuts, collars and the license light unit from the rear fender stay.

Remove the mounting nuts, setting plates and the rear right/left turn signal light units from the rear fender stay.

Assembly is in the reverse order of disassembly.


### TORQUE:

**Reflector mounting nut:**

**1.8 N·m (0.2 kgf·m, 1.3 lbf·ft)**

**Rear fender A screw:**



**3.0 N·m (0.3 kgf·m, 2.2 lbf·ft)**




# FRONT FENDER

## REMOVAL/INSTALLATION

Remove the front brake hose clamp cap nuts.  
Remove the mounting bolts and the washers.




*CB1000RA only:* Remove the front wheel speed sensor guide from the front fender grommet.



*Be careful not to scratch the front fender when removing it between the front forks.*

Remove the front fender forward.  
Remove the collars from the front fender.  
Install the removed parts in the reverse order of removal.  
Tighten the front fender mounting bolts to the specified torque.

**TORQUE: 12 N·m (1.2 kgf·m, 9 lbf·ft)**



SEAT RAIL/REAR FENDER B

REMOVAL/INSTALLATION


Drain the brake fluid from the hydraulic system

- CB1000R (page 15-7).
- CB1000RA (page 15-10).

Remove the following:


- Battery (page 17-6)
- Rear fender A/rear fender stay (page 2-9)
- Swingarm (page 14-20)

CB1000RA shown:




- Brake/taillight 3P (Natural) connector

3P (Natural) CONNECTOR




- Regulator/rectifier (page 17-8)
- Regulator/rectifier wire band

CB1000RA shown:




Remove the rear shock absorber upper mounting nut, bolt and rear shock absorber.


CB1000RA shown:




*CB1000RA:* Remove the delay valve stay mounting bolt.




*CB1000RA:* Remove the brake pipe clamp bolt.



*CB1000RA:* Remove the brake pipe joint nuts from the ABS modulator.




*CB1000RA:* Remove the oil bolt and sealing washers.




## FRAME/BODY PANELS/EXHAUST SYSTEM


CB1000RA: Remove the brake pipe joint nut from the PCV.




CB1000RA: Remove the ABS modulator (page 16-25).



Remove the rear fender B wire guide cover.



Release the main wire harness from the wire guide on the rear fender B.






Remove the following:


- Turn signal relay (page 20-33)
- Bank angle sensor (page 5-97)
- Starter relay switch (page 19-13)
- Fuse/relay box

CB1000RA shown:



*CB1000RA:* Remove the rear wheel speed sensor wire clamp from the rear fender B.


REAR WHEEL SPEED SENSOR WIRE CLAMP



Remove the main wire harness clamps from the seat rail and the rear fender B.  
Remove the alternator wire clamp from the rear fender B.

CB1000RA shown:


MAIN WIRE HARNESS WIRE CLAMPS



Remove the mounting bolts and right/left pillion steps.

CB1000RA shown:

MOUNTING BOLTS



## FRAME/BODY PANELS/EXHAUST SYSTEM

Remove the pivot bracket upper/lower nuts, washers and the bolts.

Remove the right/left pivot brackets.

Release the O<sub>2</sub> sensor wire and IDC hoses from the guides on the right pivot bracket.

Remove the seat rail upper mounting nut and bolt.  
Remove the seat rail lower mounting bolts.  
Remove the seat rail/rear fender B.

Installation is in the reverse order of removal.

Apply brake fluid to the brake pipe joint nut threads.

### TORQUE:

Brake pipe joint nut:

14 N·m (1.4 kgf·m, 10 lbf·ft)

Seat rail upper mounting nut:

39 N·m (4.0 kgf·m, 29 lbf·ft)

Seat rail lower mounting bolt:

39 N·m (4.0 kgf·m, 29 lbf·ft)




Pivot bracket upper nut:

69 N·m (7.0 kgf·m, 51 lbf·ft)

Pivot bracket lower nut:

69 N·m (7.0 kgf·m, 51 lbf·ft)

CB1000RA shown:



*Route the wire harness properly (page 1-22).*

**DISASSEMBLY/ASSEMBLY**

Remove the seat rail/rear fender B (page 2-14).


Remove the brake/tail light unit (page 20-12).

Remove the bolts, special bolts and the center cross pipe.

Remove the bolts and the seat catch plate.

Remove the bolts and nut, then disassemble the right/left seat rail plate, collar and rear fender B

Assembly is in the reverse order of disassembly.




**EXHAUST SYSTEM**

**REMOVAL**

**MUFFLER**

Loosen the muffler band bolt.




## FRAME/BODY PANELS/EXHAUST SYSTEM


Remove the muffler rear mounting nut/bolt, washer, collar and mounting rubbers.



Remove the muffler front mounting bolt, washer, collar and mounting rubbers.




Remove the muffler and gasket.



### EXHAUST PIPE


Remove the muffler (page 2-19).

Remove the O<sub>2</sub> sensor 4P (Black) connector from the stay and disconnect it.




## FRAME/BODY PANELS/EXHAUST SYSTEM


Remove the socket bolts, washers, collars and exhaust pipe protector.



Remove the exhaust pipe mounting bolt, washer, collar and mounting rubbers.



Remove the exhaust pipe joint nuts.  
Remove the exhaust pipe and gaskets.



## DISASSEMBLY

### MUFFLER


Remove the socket bolts, collars and the muffler protector.

Assembly is in the reverse order of disassembly.

### TORQUE:

**Muffler protector socket bolt:** 12 N·m (1.2 kgf·m, 9 lbf·ft)


SOCKET BOLTS/COLLARS



MUFFLER PROTECTOR

### EXHAUST PIPE

Loosen the exhaust pipe band bolts.  
Remove the right and left exhaust pipes from the chamber.  
Remove the gaskets.




Remove the socket bolts, collars and the left exhaust pipe protector.

Assembly is in the reverse order of disassembly.

### TORQUE:

**Exhaust pipe protector socket bolt:** 12 N·m (1.2 kgf·m, 9 lbf·ft)




EXHAUST PIPE PROTECTOR


## ASSEMBLY

Assembly is in the reverse order of disassembly.


### NOTE:

- Do not tighten the exhaust pipe band bolts yet.
- Replace the gaskets with new ones and install them to the exhaust pipes.





**INSTALLATION**




# FRAME/BODY PANELS/EXHAUST SYSTEM

## EXHAUST PIPE

Check that the exhaust pipe stud bolt protrusion from the exhaust port is specified length as shown.

**SPECIFIED LENGTH: 39.0 – 40.0 mm (1.54 – 1.57 in)**




*Always replace the gaskets with new ones.*


Install new gaskets to the exhaust ports.

Install the exhaust pipe/chamber to the cylinder head.

Temporarily install the exhaust pipe joint nuts.




Temporarily install the mounting rubbers, collar, washer and the exhaust pipe mounting bolt.



Tighten the exhaust pipe joint nuts to the specified torque.


**TORQUE: 12 N·m (1.2 kgf·m, 9 lbf·ft)**






Tighten the exhaust pipe mounting bolt to the specified torque.

**TORQUE: 22 N·m (2.2 kgf·m, 16 lbf·ft)**




Tighten the exhaust pipe band bolts to the specified torque.

**TORQUE: 22 N·m (2.2 kgf·m, 16 lbf·ft)**




Install the exhaust pipe protector, collars and washers, then tighten the socket bolts to the specified torque.

**TORQUE: 12 N·m (1.2 kgf·m, 9 lbf·ft)**



Connect the O<sub>2</sub> sensor 4P (Black) connector and install it to the stay.


Install the muffler (page 2-26).




## FRAME/BODY PANELS/EXHAUST SYSTEM

### MUFFLER

- Install a new gasket onto the exhaust pipe.
- Install the muffler to the exhaust pipe.




Temporarily install the mounting rubbers, collar, washer and the muffler front mounting bolt.



Temporarily install the mounting rubbers, collar, washer, muffler rear mounting bolt and nut.


Tighten the muffler rear mounting nut to the specified torque.

**TORQUE: 22 N·m (2.2 kgf·m, 16 lbf·ft)**




Tighten the muffler front mounting bolt to the specified torque.

**TORQUE: 22 N·m (2.2 kgf·m, 16 lbf·ft)**



Tighten the muffler band bolt to the specified torque.

**TORQUE: 22 N·m (2.2 kgf·m, 16 lbf·ft)**



## SIDESTAND

### REMOVAL/INSTALLATION

Remove the sidestand switch (page 20-30).

Support the motorcycle securely using a hoist or equivalent.

Remove the sidestand return spring.

Remove the sidestand pivot nut and bolt, then remove the sidestand.

Install the sidestand.

Apply grease to the sidestand pivot bolt sliding surface.

Install and tighten the sidestand pivot bolt to the specified torque.


**TORQUE: 10 N·m (1.0 kgf·m, 7 lbf·ft)**

After tighten the pivot bolt, return the pivot bolt 45° to 90°.

Install and tighten the sidestand pivot nut to the specified torque while holding the sidestand pivot bolt.

**TORQUE: 39 N·m (4.0 kgf·m, 29 lbf·ft)**

Install the sidestand switch (page 20-30).



---

**MEMO**

---

SERVICE INFORMATION .....	3-2	DRIVE CHAIN SLIDER AND DRIVE CHAIN GUIDE .....	3-26
MAINTENANCE SCHEDULE .....	3-4	BRAKE FLUID .....	3-27
FUEL LINE .....	3-5	BRAKE PAD WEAR .....	3-28
THROTTLE OPERATION .....	3-6	BRAKE SYSTEM .....	3-29
AIR CLEANER .....	3-7	BRAKE LIGHT SWITCH .....	3-30
CRANKCASE BREATHER .....	3-8	HEADLIGHT AIM .....	3-30
SPARK PLUG .....	3-8	CLUTCH SYSTEM .....	3-30
VALVE CLEARANCE .....	3-11	CLUTCH FLUID .....	3-31
ENGINE OIL/OIL FILTER .....	3-16	SIDESTAND .....	3-31
RADIATOR COOLANT .....	3-19	SUSPENSION .....	3-32
COOLING SYSTEM .....	3-19	NUTS, BOLTS, FASTENERS .....	3-35
SECONDARY AIR SUPPLY SYSTEM .....	3-20	WHEELS/TIRES .....	3-35
DRIVE CHAIN .....	3-21	STEERING HEAD BEARINGS .....	3-36

## MAINTENANCE

# SERVICE INFORMATION

## GENERAL

- Place the motorcycle on level ground before starting any work.
- Gasoline is extremely flammable and is explosive under certain conditions.
- Work in a well ventilated area. Smoking or allowing flames or sparks in the work area or where the gasoline is stored can cause a fire or explosion.
- The exhaust contains poisonous carbon monoxide gas that may cause loss of consciousness and may lead to death. Run the engine in an open area or with an exhaust evacuation system in and enclosed area.

## SPECIFICATIONS

ITEM		SPECIFICATIONS	
Throttle grip freeplay		2 – 6 mm (1/16 – 1/4 in)	
Spark plug	NGK	IMR9E-9HES	
	DENSO	VUH27ES	
Spark plug gap		0.80 – 0.90 mm (0.031 – 0.035 in)	
Valve clearance	IN	0.16 ± 0.03 mm (0.006 ± 0.001 in)	
	EX	0.32 ± 0.03 mm (0.013 ± 0.001 in)	
Engine oil capacity	After draining	2.7 liter (2.9 US qt, 2.4 Imp qt)	
	After oil filter change	3.0 liter (3.2 US qt, 2.6 Imp qt)	
Engine oil		Suggested oil: Honda "4-stroke motorcycle oil" or an equivalent Oil recommendation: API classification: SG or higher (except oils labeled as energy conserving on the circular API service label) Viscosity: SAE 10W-30 JASO T 903 standard: MA	
Recommended antifreeze		High quality ethylene glycol antifreeze containing silicate-free corrosion protection inhibitors	
Engine idle speed		1,200 ± 100 min <sup>-1</sup> (rpm)	
Drive chain	Size/link	DID	DID50VA8-116YB
	Drive chain slack		25 – 35 mm (1 – 1-3/8 in)
Recommended brake fluid		DOT 4 brake fluid	
Tire size	Front		120/70ZR17M/C (58W)
	Rear		180/55ZR17M/C (73W)
Fork	Pre-load adjuster standard position		8 turns from minimum
	Rebound damping adjuster standard position		2 turns out from full hard
	Compression damping adjuster standard position		2 turns out from full hard
Rear suspension	Spring pre-load adjuster standard position		Position 3
	Rebound adjuster standard position		1-1/2 turns out from full hard
Tire brand	Bridgestone	Front	BT015F RADIAL L
		Rear	BT015R RADIAL L
Tire air pressure	Driver only	Front	250 kPa (2.50 kgf/cm <sup>2</sup> , 36 psi)
		Rear	290 kPa (2.90 kgf/cm <sup>2</sup> , 42 psi)
	Driver and passenger	Front	250 kPa (2.50 kgf/cm <sup>2</sup> , 36 psi)
		Rear	290 kPa (2.90 kgf/cm <sup>2</sup> , 42 psi)
Minimum tire tread depth	Front		1.5 mm (0.06 in)
	Rear		2.0 mm (0.08 in)




**TORQUE VALUES**

Lower throttle cable adjuster lock nut	5.5 N·m (0.6 kgf·m, 0.4 lbf·ft)
Air cleaner duct mounting screw	1.1 N·m (0.1 kgf·m, 0.8 lbf·ft)
Spark plug	16 N·m (1.6 kgf·m, 12 lbf·ft)
Timing hole cap	18 N·m (1.8 kgf·m, 13 lbf·ft)
Engine oil drain bolt	30 N·m (3.1 kgf·m, 22 lbf·ft)
Engine oil filter cartridge	26 N·m (2.7 kgf·m, 19 lbf·ft)
Rear axle bearing holder pinch bolt	74 N·m (7.5 kgf·m, 54 lbf·ft)
Drive sprocket bolt	54 N·m (5.5 kgf·m, 40 lbf·ft)
Driven sprocket nut	64 N·m (6.5 kgf·m, 47 lbf·ft)
Rear master cylinder push rod joint nut	17 N·m (1.7 kgf·m, 13 lbf·ft)
Ignition coil stay mounting bolt	3.5 N·m (0.4 kgf·m, 2.6 lbf·ft)

Apply grease to the threads.

Apply engine oil to the threads and O-ring.

**TOOLS**

<p>Tensioner stopper 070MG-0010100</p> 	<p>Oil filter wrench 07HAA-PJ70101</p> 	<p>Drive chain tool set 07HMH-MR10103</p> 
---	---	--

# MAINTENANCE

## MAINTENANCE SCHEDULE

Perform the Pre-ride inspection in the Owner's Manual at each scheduled maintenance period.

I: Inspect and Clean, Adjust, Lubricate or Replace if necessary. C: Clean. R: Replace. A: Adjust. L: Lubricate.

The following items require some mechanical knowledge. Certain items (particularly those marked \* and \*\*) may require more technical information and tools. Consult your Honda dealer.

ITEMS	FREQUENCY	WHICHEVER COMES FIRST ↓	ODOMETER READING (NOTE 1)							REFER TO PAGE	
			X1,000 km	1	6	12	18	24	30		36
			X1,000 mi	0.6	4	8	12	16	20		24
			Months		6	12	18	24	30		36
* FUEL LINE					I		I		I	3-5	
* THROTTLE OPERATION					I		I		I	3-6	
AIR CLEANER		NOTE2				I			I	3-7	
CRANKCASE BREATHER		NOTE3			C	C	C	C	C	3-8	
* SPARK PLUG					EVERY 24,000 km (16,000 mi) I, EVERY 48,000 km (32,000 mi) R					3-8	
* VALVE CLEARANCE							I			3-11	
ENGINE OIL			R		R		R		R	3-16	
ENGINE OIL FILTER			R		R		R		R	3-16	
RADIATOR COOLANT		NOTE4			I		I		R	3-19	
* COOLING SYSTEM					I		I		I	3-19	
* SECONDARY AIR SUPPLY SYSTEM					I		I		I	3-20	
DRIVE CHAIN					EVERY 1,000 km (600 mi) I, L					3-21	
DRIVE CHAIN SLIDER					I		I		I	3-26	
BRAKE FLUID		NOTE4			I	I	R	I	I	R	3-27
BRAKE PAD WEAR					I	I	I	I	I	3-28	
BRAKE SYSTEM			I		I		I		I	3-29	
* BRAKE LIGHT SWITCH					I		I		I	3-30	
* HEADLIGHT AIM					I		I		I	3-30	
CLUTCH SYSTEM					I		I		I	3-30	
CLUTCH FLUID		NOTE4			I	I	R	I	I	R	3-31
SIDESTAND					I		I		I	3-31	
* SUSPENSION					I		I		I	3-32	
* NUTS, BOLTS, FASTENERS			I		I		I		I	3-35	
** WHEELS/TIRES					I		I		I	3-35	
** STEERING HEAD BEARINGS			I		I		I		I	3-36	

\* Should be serviced by your Honda dealer, unless the owner has proper tools and service data and is mechanically qualified. Refer to the Official Honda Shop Manual.

\*\* In the interest of safety, we recommended these items be serviced only by your Honda dealer

Honda recommends that your Honda dealer should road test your motorcycle after each periodic maintenance is carried out.

### NOTES:

1. At higher odometer readings, repeat at the frequency interval established here.
2. Service more frequently when riding in unusually wet or dusty areas.
3. Service more frequently when riding in rain or at full throttle.
4. Replace every 2 years, or at indicated odometer interval, whichever comes first. Replacement requires mechanical skill.




# FUEL LINE

Remove the following:


- seat (page 2-4)
- side covers (page 2-5)
- radiator shroud

Remove the fuel tank front mounting bolts/washers.




Lift the fuel tank and install fuel tank mounting bolt and washer onto the frame.

Support fuel tank using the equipped tools (driver and handle) as shown.



**NOTE:**


- Support the fuel tank by inserting the driver to the fuel tank bracket slit and handle as shown.



Check the fuel line for deterioration, damage or leakage, replace the fuel line if necessary (page 5-62).

Check the fuel rail and injectors for damage or leakage, replace them if necessary (page 5-88).

Check the fuel pump mounting area for leakage, replace the fuel pump packing if necessary (page 5-57).




## MAINTENANCE

Remove a support tools and mounting bolt/washer, then lower the fuel tank.

### NOTICE


- Route the hoses, wires and harness properly (page 1-22).
- Be careful not to damage the harness and hoses.
- After installing the fuel tank, make sure the drain, breather and fuel hoses are not kinked or bound.
- Check the hose joint for loose or disconnection.



Install the fuel tank front mounting bolts/washers and collars.

Tighten the fuel tank mounting bolts securely.

Install the removed parts in the reverse order of removal.



## THROTTLE OPERATION


Check for smooth throttle grip full opening and automatic full closing in all steering positions.

Check the throttle cables and replace them if they are deteriorated, kinked or damaged.

Lubricate the throttle cables, if throttle operation is not smooth.

Measure a freeplay at the throttle grip flange.


**FREEPLAY: 2 – 6 mm (1/16 – 1/4 in)**



Throttle grip freeplay can be adjusted at either end of the throttle cable.

Minor adjustment is made with the upper adjuster.

Adjust the freeplay by loosening the lock nut and turning the adjuster.



Major adjustment is made with the lower adjuster.

Lift and support the fuel tank (page 3-5).

Adjust the freeplay by loosening the lock nut and turning the adjuster.


After adjustment, tighten the lock nut to the specified torque.

**TORQUE: 5.5 N·m (0.6 kgf·m, 4.0 lbf·ft)**

Remove the support tool, then install and tighten the fuel tank front mounting bolts (page 3-6).

Recheck the throttle operation.


Replace any damaged parts, if necessary.




## AIR CLEANER

Remove the left side cover (page 2-5).


Remove the air cleaner duct cover mounting screws.



Remove the air cleaner duct mounting screws.



Remove the air cleaner duct without disconnecting the vacuum hose.



## MAINTENANCE

Remove and inspect the air cleaner element in accordance with the maintenance schedule (page 3-4).


Clean the air cleaner element with compressed air from outside of the element.

*Install the air cleaner element with its opening facing out.*

Install the removed parts in the reverse order of removal.

### TORQUE:

**Air cleaner duct mounting screw:** 1.1 N·m (0.1 kg·m, 0.8 lbf·ft)



## CRANKCASE BREATHER


### NOTE:

- Service more frequently when ridden in rain, at full throttle, or after the motorcycle is washed or overturned. Service if the deposit level can be seen in the drain hose.

Remove the left side cover (page 2-5).

Remove the air cleaner duct cover (page 3-7).

Remove the crankcase breather drain hose and drain the deposits into a suitable container, then reinstall the drain hose with the hose clamp.



## SPARK PLUG


### REMOVAL

Lift and support the fuel tank (page 3-5).


Remove the radiator reserve tank mounting bolts.

*Clean around the spark plug bases with compressed air before removing, and be sure that no debris is allowed to enter the combustion chamber.*

Disconnect the No.1 and No.2 spark plug caps from the spark plugs.




Remove the ignition coil stay mounting bolts.




*Clean around the spark plug bases with compressed air before removing, and be sure that no debris is allowed to enter the combustion chamber.*

Disconnect the No.3 and No.4 spark plug caps from the spark plugs.



Remove the spark plugs.

Inspect or replace as described in a maintenance schedule (page 3-4).




**INSPECTION**

Check the following and replace if necessary (recommended spark plug: page 3-8)

- Insulator for damage
- Electrodes for wear
- Burning condition, coloration

*This motorcycle's spark plug is equipped with an iridium center electrode. Replace the spark plug if the electrodes are contaminated.*

If the electrodes are contaminated with accumulated objects or dirt, replace the spark plug.




## MAINTENANCE

Always use specified spark plugs on this motorcycle. Replace the plug if the center electrode is rounded as shown in the illustration.

### SPECIFIED SPARK PLUG:


NGK: IMR9E-9HES

DENSO: VUH27ES



To prevent damaging the iridium center electrode, use a wire type feeler gauge to check the spark plug gap. Check the spark plug gap between the center and side electrodes with a wire type feeler gauge. Make sure that the  $\phi$  1.0 mm (0.04 in) plug gauge does not insert between the gap.

Do not adjust the spark plug gap. If the gap is out of specification, replace with a new one. If the gauge can be inserted into the gap, replace the plug with a new one.



## INSTALLATION

Install and hand tighten the spark plug to the cylinder head, then tighten the spark plug to the specified torque.


**TORQUE: 16 N·m (1.6 kgf·m, 12 lbf·ft)**

Install the spark plug caps.

Install the removed parts in the reverse order.

### TORQUE:

Ignition coil stay mounting bolt **3.5 N·m (0.4 kg·m, 2.6 lbf·ft)**



# VALVE CLEARANCE

## INSPECTION


**NOTE:**

Check the engine idle speed (page 5-93) after the valve clearance inspection.

*Inspect and adjust the valve clearance while the engine is cold (below 35°C/95°F)*

Remove the cylinder head cover (page 8-6).

Remove the cam chain tensioner lifter bolt and sealing washer.




*Failure to release the cam chain tensioner will result in inaccurate valve clearance reading.*


Turn the cam chain tensioner lifter shaft fully in (clockwise) and secure it using the special tool to prevent damaging the cam chain.

**TOOL:**


**Tensioner stopper 070MG-0010100**



Remove the timing hole cap and O-ring.




Turn the crankshaft clockwise, align the "T" mark on the CKP sensor rotor with the index mark on the right crankcase cover.




## MAINTENANCE

The timing marks ("IN" and "EX") on the cam sprockets must be flush with the cylinder head surface and facing outward as shown.

If the timing marks on the cam sprocket facing inward, turn the crankshaft clockwise one full turn (360°) and realign the timing marks with the cylinder head surface so they are facing outward.



Insert the feeler gauge between the valve lifter and the cam lobe.




*Record the clearance for each valve for reference in shim selection if adjustment is required.*


Check the valve clearance for the No.1 and No.3 cylinder intake valves using a feeler gauge.

### VALVE CLEARANCE:

**IN:  $0.16 \pm 0.03$  mm ( $0.006 \pm 0.001$  in)**



Turn the crankshaft clockwise 1/2 turn (180°), align the index line on the CKP sensor rotor so that it is facing up as shown.







*Record the clearance for each valve for reference in shim selection if adjustment is required.*

Check the valve clearance for the No.2 and No.4 cylinder exhaust valves using a feeler gauge.

**VALVE CLEARANCE:**  
**EX:  $0.32 \pm 0.03$  mm ( $0.013 \pm 0.001$  in)**




Turn the crankshaft clockwise 1/2 turn (180°), align the "T" mark on the CKP sensor rotor with the index mark on the right crankcase cover.




*Record the clearance for each valve for reference in shim selection if adjustment is required.*

Check the valve clearance for the No.2 and No.4 cylinder intake valves using feeler gauge.

**VALVE CLEARANCE:**  
**IN:  $0.16 \pm 0.03$  mm ( $0.006 \pm 0.001$  in)**



Turn the crankshaft clockwise 1/2 turn (180°), align the index line on the CKP sensor rotor so that it is facing up as shown.




## MAINTENANCE

*Record the clearance for each valve for reference in shim selection if adjustment is required.*

Check the valve clearance for the No.1 and No.3 cylinder exhaust valves using a feeler gauge.

### VALVE CLEARANCE:

**EX:  $0.32 \pm 0.03$  mm ( $0.013 \pm 0.001$  in)**




## ADJUSTMENT

*It is not necessary to remove the cam sprocket from the camshaft except when replacing the camshaft and/or cam sprocket.*

Remove the camshafts (page 8-8).


Remove the valve lifters and shims.

- Shim may stick to the inside of the valve lifter. Do not allow the shims to fall into the crankcase.
- Mark all valve lifters and shims to ensure correct reassembly in their original locations.
- The valve lifter can be easily removed with a valve lapping tool or magnet.
- The shims can be easily removed with a tweezers or magnet.



Clean the valve shim contact area in the valve lifter with compressed air.


VALVE LIFTER



Measure the shim thickness and record it.

*Sixty-five different thickness shims are available from the thinnest 1.200 mm thickness shim to the thickest 2.800 mm thickness shim in intervals of 0.025 mm.*

SHIM




Calculate the new shim thickness using the equation below.

$$A = (B - C) + D$$


- A: New shim thickness
- B: Recorded valve clearance
- C: Specified valve clearance
- D: Old shim thickness

- Make sure of the correct shim thickness by measuring the shim by micrometer.
- Reface the valve seat if carbon deposit result in a calculated dimension of over 2.800 mm.



*Install the shims and valve lifters in their original locations*


- Install the newly selected shim on the valve retainer.
- Apply molybdenum disulfide oil to the valve lifters.
- Install the valve lifters into the valve lifter holes.
- Install the camshaft (page 8-25).
- Rotate the camshafts by rotating the crankshaft clockwise several times.
- Recheck the valve clearance.




*Check that the O-ring is in good condition, replace if necessary.*

- Apply engine oil to the timing hole cap O-ring.
- Apply grease to the timing hole cap threads.
- Install and tighten the timing hole cap to the specified torque.

**TORQUE: 18 N·m (1.8 kgf·m, 13 lbf·ft)**



- Remove the cam chain tensioner stopper tool.
- Install a new sealing washer and cam chain tensioner lifter bolt.
- Tighten the bolt securely.
- Install the cylinder head cover (page 8-31).



# ENGINE OIL/OIL FILTER


## OIL LEVEL INSPECTION

Place the motorcycle on the level ground with its sidestand.


Start the engine and let it idle for 3 – 5 minutes.  
Stop the engine and wait 2 – 3 minutes.  
Hold the motorcycle in an upright position.

Check the oil level through the inspection window.

If the level is below the lower level line, fill the crankcase with the recommended oil up to the upper level line as following procedures.



Remove the oil filler cap.



Fill the recommended engine oil up to the upper level line.

*Other viscosities shown in the chart may be used when the average temperature in your riding area is within the indicated range.*


### SUGGESTED OIL:

**Honda "4-stroke motorcycle oil" or an equivalent OIL RECOMMENDATION:**

**API classification: SG or higher (except oils labeled energy conserving on the circular API service label)**

**Viscosity: SAE 10W-30**

**JASO T 903 standard: MA**




Reinstall the oil filler cap.

## ENGINE OIL & FILTER CHANGE


*Change the oil with the engine warm and the motorcycle on level ground to assure complete draining*

Start the engine and let it idle for 3 – 5 minutes.  
Stop the engine and wait 2 – 3 minutes.

Stop the engine and remove the oil filler cap.




Remove the drain bolt and sealing washer, then drain the oil completely.




Remove and discard the oil filter cartridge using the special tool.

**TOOL:**  
**Oil filter wrench**                      **07HAA-PJ70101**




Replace the sealing washer with a new one. Install and tighten the drain bolt to the specified torque.

**TORQUE: 30 N·m (3.1 kgf·m, 22 lbf·ft)**




Check that the oil filter boss protrusion from the crankcase is specified length as shown.

**SPECIFIED LENGTH: 14.4 – 15.4 mm (0.57 – 0.61 in)**



## MAINTENANCE

Apply clean engine oil to new oil filter cartridge threads and O-ring.




Install the oil filter and tighten it to the specified torque.

**TOOL:**

Oil filter wrench                      07HAA-PJ70101

**TORQUE:** 26 N·m (2.7 kgf·m, 19 lbf·ft)



Fill the crankcase with recommended engine oil (page 3-16).


**OIL CAPACITY:**

2.7 liter (2.9 US qt, 2.4 Imp qt) after draining  
3.0 liter (3.2 US qt, 2.6 Imp qt) after oil filter change

Check that the O-ring on the oil filler cap is in good condition, and replace it if necessary.  
Install the oil filler cap.

Recheck the oil level (page 3-16).

Make sure there are no oil leaks.



## RADIATOR COOLANT


Check the coolant level of the reserve tank with the engine running at normal operating temperature.

The level should be between the "UPPER" and "LOWER" level lines on a level surface.

If necessary, add recommended coolant.

### RECOMMENDED ANTIFREEZE:

**High quality ethylene glycol antifreeze containing silicate-free corrosion protection inhibitors.**




Remove the protection grill (page 2-4)

Remove the reserve tank filler cap and fill to the "UPPER" level line with 50/50 mixture of distilled water and antifreeze.

Reinstall the filler cap.

Install the protection grill (page 2-4).




## COOLING SYSTEM

Check the radiator air passages for clogging or damage.


Straighten bend fins with a small, flat blade screw driver and remove insects, mud or other obstructions with compressed air or low water pressure.

Replace the radiator if the air flow is restricted over more than 20% of the radiating surface.




Inspect the radiator hoses for cracks or deterioration, and replace if necessary.

Check the tightness of all hose clamps and fasteners.



**SECONDARY AIR SUPPLY SYSTEM**

- This model is equipped built-in secondary air supply system. The PAIR system is located on the cylinder head cover.
- The PAIR system introduces filtered air into exhaust gases in the exhaust port. The secondary air is drawn into the exhaust port whenever there is negative pressure pulse in the exhaust system. This charged secondary air promotes burning of the unburned exhaust gases and changes a considerable amount of hydrocarbons and carbon monoxide into relatively harmless carbon dioxide and water.




Lift and support the fuel tank (page 3-5).

*If the hoses show any signs of heat damage, inspect the PAIR check valves for damage.*

Check the PAIR air suction hoses between the PAIR control solenoid valve and cylinder head cover for deterioration, damage or loose connections. Make sure that the hoses are not cracked.

Check the PAIR air suction hose between the air cleaner housing and PAIR control solenoid valve for deterioration, damage or loose connections. Make sure that the hoses are not kinked, pinched or cracked.





# DRIVE CHAIN

## DRIVE CHAIN SLACK INSPECTION

*Never inspect and adjust the drive chain while the engine is running.*

Turn the ignition switch OFF, place the motorcycle on its sidestand and shift the transmission into neutral.

Check the slack in the drive chain lower run midway between the sprockets.

**CHAIN SLACK: 25 – 35 mm (1 – 1-3/8 in)**



### NOTICE

*Excessive chain slack, 50 mm (2.0 in) or more, may damage the frame.*

Lubricate the drive chain with #80 – 90 gear oil or chain lubricant designed specifically for use with O-ring chains. Wipe off the excess oil or chain lubricant.


## ADJUSTMENT

Loosen the rear axle bearing holder pinch bolt.



Turn the axle bearing holder using the equipped tool until the correct drive chain slack is obtained. Tighten the rear axle bearing holder pinch bolt to the specified torque.

**TORQUE: 74 N·m (7.5 kgf·m, 54 lbf·ft)**




Recheck the drive chain slack and free wheel rotation.

Lubricate the drive chain with #80 – 90 gear oil or drive chain lubricant designed specifically for use with O-ring chains. Wipe off the excess oil or chain lubricant.

Check the drive chain wear indicator label.

If the index mark reaches red zone of the indicator label, replace the drive chain with a new one (page 3-23).



## CLEANING AND LUBRICATION

Clean the chain with non-flammable or high flash point solvent and wipe it dry.


Be sure the chain has dried completely before lubricating.

Inspect the drive chain for possible damage or wear. Replace any chain that has damaged rollers, loose fitting links, or otherwise appears unserviceable.

Installing a new chain on badly worn sprockets will cause the new chain to wear quickly.

Inspect and replace sprocket as necessary.

NON-FLAMMABLE OR HIGH FLASH POINT SOLVENT




SOFT BRUSH

WIPE AND DRY



Lubricate the drive chain with #80 - 90 gear oil or drive chain lubricant designed specifically for use with O-ring chains. Wipe off the excess oil or chain lubricant.

LUBRICATE




#80 - 90 GEAR OIL OR DRIVE CHAIN LUBRICANT

## SPROCKETS INSPECTION

Inspect the drive and driven sprocket teeth for wear or damage, replace if necessary.

Never use a new drive chain on worn sprockets.

Both chain and sprockets must be in good condition, or the new replacement chain will wear rapidly.



Remove the crankcase rear cover (page 7-4).



Check the attaching bolt and nuts on the drive and driven sprockets.

Tighten the bolt or nut to the specified torque if necessary.

**TORQUE:**

**Drive sprocket bolt:** 54 N·m (5.5 kg·m, 40 lbf·ft)

**Driven sprocket nut:** 64 N·m (6.5 kgf·m, 47 lbf·ft)



**REPLACEMENT**

This motorcycle uses a drive chain with a staked master link.


Loosen the drive chain (page 3-21).

Assemble the special tool as shown.

**TOOL:**

**Drive chain tool set** 07HMH-MR10103


*When using the special tool, follow the manufacturer's instruction.*



## MAINTENANCE

Locate the crimped pin ends of the master link from the outside of the chain, and remove the link with the drive chain tool set.

Remove the drive chain.




*Include the master link when you count the drive chain links.*

Remove the excess drive chain links from the new drive chain with the drive chain tool set.

**STANDARD LINKS: 116 LINKS**


**REPLACEMENT CHAIN**

**DID: DID50VA8-116YB**




*Never reuse the old drive chain, master link, master link plate and O-rings.*

Insert a new master link with new O-rings from the inside of the drive chain, and install the new plate and O-rings with the identification mark facing the outside.



Assemble and set the drive chain tool set.




Make sure that the master link pins are installed properly.  
Measure the master link pin length projected from the plate.

**STANDARD LENGTH:**

**DID:** 1.3 – 1.5 mm (0.05 – 0.06 in)


Stake the master link pins.



Make sure that the pins are staked properly by measuring the diameter of the staked area using a slide caliper.


**DIAMETER OF THE STAKED AREA:**

**DID:** 5.50 – 5.80 mm (0.217 – 0.228 in)



*A drive chain with a clip-type master link must not be used.*


After staking, check the staked area of the master link for cracks. If there is any cracking, replace the master link, O-rings and plate.



**DRIVE CHAIN GUIDE PLATE INSPECTION**

Remove the clutch slave cylinder without disconnecting the hose (page 9-14)


Remove the bolts, driven sprocket cover and drive chain guide plate.



## MAINTENANCE

Avoid damaging the crankcase, periodically inspect the drive chain guide plate, replace if necessary.

Check the drive chain guide plate for wear or damage. If the drive chain guide plate is excessive worn or damaged, replace it with a new one.




## DRIVE CHAIN SLIDER AND DRIVE CHAIN GUIDE

Remove the crankcase rear cover (page 11-7).


Inspect the drive chain slider for excessive wear or damage.

If it is worn to the wear indicator, replace the drive chain slider (page 14-27).



Inspect the drive chain guide excessive wear or damage.

If it is worn to the front or rear wear indicator, replace the front drive chain guide (page 14-27).



## BRAKE FLUID

### NOTICE

- Do not mix different types of fluid, as they are not compatible with each other.
- Do not allow foreign material to enter the system when filling the reservoir.
- Avoid spilling fluid on painted, plastic or rubber parts. Place a rag over these parts whenever the system is serviced.


When the fluid level is low, check the brake pads for wear (page 3-28).

A low fluid level may be due to wear of the brake pads. If the brake pads are worn, the caliper piston is pushed out, and this accounts for a low reservoir level. If the brake pads are not worn and the fluid level is low, check entire system for leaks (page 3-29).

### FRONT BRAKE

Turn the handlebar so that the reservoir is level and check the front brake fluid level.

If the level is near the lower level line, check the brake pad wear (page 3-28).




### REAR BRAKE

Place the motorcycle on a level surface, and support it in an upright position.

Check the rear brake fluid level.

If the level is near the lower level line, check the brake pad wear (page 3-28).



## BRAKE PAD WEAR


### FRONT BRAKE PADS

Check the brake pad for wear.

Replace the brake pads if either pad is worn to the bottom of wear limit groove.

Refer to brake pad replacement:

- CB1000R (page 15-17)
- CB1000RA (page 15-19)




### REAR BRAKE PADS

Check the brake pad for wear.

Replace the brake pads if either pad is worn to the bottom of wear limit groove.

Refer to brake pad replacement (page 15-20).





# BRAKE SYSTEM


## INSPECTION

Firmly apply the brake lever or pedal, and check that no air has entered the system. If the lever or pedal feels soft or spongy when operated, bleed the air from the system.

Inspect the brake hose and fittings for deterioration, cracks and signs of leakage. Tighten any loose fittings. Replace hoses and fittings as required.

Refer the procedure for brake bleeding:


- CB1000R (page 15-7)
- CB1000RA (page 15-10)



## BRAKE LEVER ADJUSTMENT

*Align the allow. mark on the brake lever with the index number on the adjuster.*

The distance between the top of the brake lever and the grip can be adjusted by turning the adjuster.




## BRAKE PEDAL HEIGHT ADJUSTMENT

Loosen the lock nut and turn the master cylinder push rod to obtain the desired pedal height.


After adjustment, hold the adjusting bolt and tighten the lock nut.

**TORQUE: 17 N·m (1.7 kgf·m, 13 lbf·ft)**



If the brake pedal is adjusted to the lower position, make sure that the clearance between the lower end of the push rod and the brake pedal does not fall below 1 mm (0.04 in).

If the brake pedal is adjusted to the higher position, make sure that the lower end of the push rod thread is visible inside the joint.




## MAINTENANCE

### BRAKE LIGHT SWITCH

*The front brake light switch does not require adjustment.* Adjust the brake light switch so that the brake light comes on just prior to the brake actually being engaged.

If the light fails to come on, adjust the switch so that the light comes on at the proper time.

Hold the switch body and turn the adjuster. Do not turn the switch body.




### HEADLIGHT AIM

Place the motorcycle on a level surface.

*Adjust the headlight aim as specified by local laws and regulations.* Adjust the headlight aim vertically by turning the vertical beam adjusting screw. A clockwise rotation moves the beam up and counterclockwise rotation moves the beam down.

Adjust the headlight aim horizontally by turning the horizontal beam adjusting screw.


A clockwise rotation moves the beam toward the right and counterclockwise rotation moves the beam toward the left.



### CLUTCH SYSTEM

#### CLUTCH LEVER ADJUSTMENT

*Align the allow mark on the clutch lever with the index number on the adjuster.* The distance between the top of the clutch lever and the grip can be adjusted by turning the adjuster.



# CLUTCH FLUID

## NOTICE


- Do not mix different types of fluid, as they are not compatible with each other.
- Do not allow foreign material to enter the system when filling the reservoir.
- Avoid spilling fluid on painted, plastic or rubber parts. Place a rag over these parts whenever the system is serviced.

*When the fluid level is low, check entire system for leaks.*

Turn the handlebar to the right so that the reservoir is level and check the clutch fluid level.


Firmly apply the clutch lever, and check that no air has entered the system.

If the lever feels soft or spongy when operated, bleed the air from the system.



Inspect the clutch hose and fittings for deterioration, cracks and signs of leakage. Tighten any loose fittings. Replace hoses and fittings as required.

Refer the procedure for clutch fluid bleeding (page 9-6)




# SIDESTAND

Support the motorcycle on a level surface.

Check the sidestand spring for damage or loss of tension.

Check the sidestand for smooth movement and lubricate the sidestand pivot if necessary.




## MAINTENANCE

Check the sidestand ignition cut-off system:

- Sit astride the motorcycle and raise the sidestand.
- Start the engine with the transmission in neutral, then shift the transmission into gear, with the clutch lever squeezed.
- Move the sidestand full down.
- The engine should stop as the sidestand is lowered.

If there is a problem with the system, check the sidestand switch (page 20-30).



SIDESTAND SWITCH

## SUSPENSION

### FRONT SUSPENSION INSPECTION

Check the action of the forks by operating the front brakes and compressing the front suspension several times.


Check the front suspension assembly for signs of leaks, damage or loose fasteners.

*Loose, worn or damaged suspension parts impair motorcycles stability and control.*

Replace damaged components which cannot be repaired.


Tighten all nuts and bolts.

Refer to the fork service (page 13-23).



Check for worn steering stem bearings by grabbing the front fork leg and attempting to move the front fork side to side.

Replace the steering head bearings if any looseness is noted (page 13-34).



### FRONT SUSPENSION ADJUSTMENT

#### SPRING PRE-LOAD ADJUSTER

Spring pre-load can be adjusted by turning the adjuster.

#### TURN CLOCKWISE:

Increase the spring pre-load

#### TURN COUNTERCLOCKWISE:


Decrease the spring pre-load

#### PRE-LOAD ADJUSTER ADJUSTABLE RANGE:

15 turns

#### PRE-LOAD ADJUSTER STANDARD POSITION:

8 turns in from minimum



PRE-LOAD ADJUSTER

**COMPRESSION AND REBOUND DAMPING ADJUSTERS**

**NOTICE**

*Do not turn the adjusters more than the given positions or the adjusters may be damaged.*

- All damping adjustments are referenced from the full hard position.

*To adjust both sides equally, set the right and left damping adjusters to the same position.*

The compression and rebound damping can be adjusted by turning the adjusters.

**DIRECTION H: Increase the damping force**  
**DIRECTION S: Decrease the damping force**


Turn the compression adjuster clockwise until it stops (full hard position), then turn the adjuster counterclockwise.

**COMPRESSION ADJUSTER ADJUSTABLE RANGE:**

**3 turns**

**COMPRESSION ADJUSTER STANDARD POSITION:**

**2 turns out from full hard**




Turn the rebound adjuster clockwise until it stops (full hard position), then turn the adjuster counterclockwise.

**REBOUND ADJUSTER ADJUSTABLE RANGE:**

**3 turns**

**REBOUND ADJUSTER STANDARD POSITION:**


**2 turns out from full hard**



**REAR SUSPENSION INSPECTION**

Support the motorcycle using a hoist or equivalent tool and raise the rear wheel off the ground.


Hold the swingarm and move the rear wheel sideways with force to see if the axle bearings are worn.



## MAINTENANCE

Check for worn swingarm bearings by grabbing the rear swingarm and attempting to move the swingarm side to side.

Replace the bearings if any looseness is noted (page 14-25).




Check the action of the shock absorber by compressing it several times.

Check the entire shock absorber assembly for signs of leaks, damage or loose fasteners.

Replace damaged components which cannot be repaired.

Tighten all nuts and bolts.

Refer to the shock absorber service (page 14-20).



## REAR SUSPENSION ADJUSTMENT

### SPRING PRE-LOAD ADJUSTER

*To avoid possible scratching or other damage, use a cloth to adjust the rear shock spring pre-load.*

Spring pre-load can be adjusted by turning the adjuster.

**PRE-LOAD ADJUSTER ADJUSTABLE RANGE:**  
**10 positions**

**PRE-LOAD ADJUSTER STANDARD POSITION:**  
**3 position from minimum**

### REBOUND DAMPING ADJUSTERS

#### NOTICE


*Do not turn the adjusters more than the given positions or the adjusters may be damaged.*

- Rebound damping adjustments are referenced from the full hard position.

The rebound damping can be adjusted by turning the adjusters.

**DIRECTION H: Increase the damping force**

**DIRECTION S: Decrease the damping force**




Turn the rebound adjuster clockwise until it stops (full hard position), then turn the adjuster counter-clockwise.

**REBOUND ADJUSTER ADJUSTABLE RANGE:**

**3 turns**

**REBOUND ADJUSTER STANDARD POSITION:**

**1-1/2 turns out from full hard**




REBOUND ADJUSTER

## NUTS, BOLTS, FASTENERS

Check that all chassis nuts and bolts are tightened to their specified torque values (page 1-12).

Check that all hose clamps and cable stays are in place and properly secured.




FRONT AXLE BOLT

## WHEELS/TIRES

Tire pressure should be checked when the tires are COLD.

**RECOMMENDED TIRE PRESSURE AND TIRE SIZE:**

	FRONT	REAR
Tire pressure	250 kPa (2.50 kgf/cm <sup>2</sup> , 36 psi)	290 kPa (2.90 kgf/cm <sup>2</sup> , 42 psi)
Tire size	120/70ZR17M/C (58W)	180/55ZR17M/C (73W)
Tire brand: Bridgestone	BT015F RADIAL L	BT015R RADIAL L



Check the tires for cuts, embedded nails, or other damage.

Check the wheel for trueness:


- front wheel (page 13-16)
- rear wheel (page 14-6)

Measure the tread depth at the center of the tires. Replace the tires when the tread depth reaches the following limits.

**MINIMUM TREAD DEPTH:**

**FRONT: 1.5 mm (0.06 in)**

**REAR: 2.0 mm (0.08 in)**




## **STEERING HEAD BEARINGS**

Check that the control cables do not interfere with handlebar rotation.

Support the motorcycle using a safety stand or hoist securely and raise the front wheel off the ground.

Check that the handlebar moves freely from side to side and there is any abnormal play at the steering head bearings.

If the handlebar moves unevenly, binds, or has vertical movement, inspect the steering head bearings (page 13-34).






# 4. LUBRICATION SYSTEM

---

LUBRICATION SYSTEM DIAGRAM .....	4-2	OIL STRAINER/PRESSURE RELIEF VALVE .....	4-6
SERVICE INFORMATION .....	4-3	OIL PUMP .....	4-8
TROUBLESHOOTING .....	4-4	OIL COOLER .....	4-13
OIL PRESSURE INSPECTION.....	4-5		

LUBRICATION SYSTEM

LUBRICATION SYSTEM DIAGRAM



**SERVICE INFORMATION****GENERAL****▲ CAUTION**

Used engine oil may cause skin cancer if repeatedly left in contact with the skin for prolonged periods. Although this is unlikely unless you handle used oil on a daily basis, it is still advisable to thoroughly wash your hands with soap and water as soon as possible after handling used oil.

- The oil pump can be serviced with the engine installed in the frame.
- The service procedures in this section must be performed with the engine oil drained.
- When removing and installing the oil pump, use care not to allow dust or dirt to enter the engine.
- If any portion of the oil pump is worn beyond the specified service limits, replace the oil pump as an assembly.
- After the oil pump has been installed, check that there are no oil leaks and that oil pressure is correct.

**SPECIFICATIONS**

ITEM		STANDARD	SERVICE LIMIT
Engine oil capacity	After draining	2.7 liter (2.9 US qt, 2.4 Imp qt)	–
	After oil filter change	3.0 liter (3.2 US qt, 2.6 Imp qt)	–
	After disassembly	3.6 liter (3.8 US qt, 3.2 Imp qt)	–
Engine oil		Suggested oil: Honda "4-stroke motorcycle oil" or an equivalent Oil recommendation: API classification: SG or higher (except oils labeled as energy conserving on the circular API service label) Viscosity: SAE 10W-30 JASO T 903 standard: MA	–
Oil pressure at EOP (engine oil pressure) switch		510 kPa (5.2 kgf/cm <sup>2</sup> , 74 psi) at 6,000 min <sup>-1</sup> (rpm)/(80°C/176°F)	–
Oil pump	Tip clearance	0.15 (0.006)	0.20 (0.008)
	Body clearance	0.15 – 0.21 (0.006 – 0.008)	0.35 (0.014)
	Side clearance	0.04 – 0.09 (0.002 – 0.004)	0.17 (0.007)

**TORQUE VALUES**

Oil pump assembly bolt  
Oil pump driven sprocket bolt


8.0 N·m (0.8 kgf·m, 5.9 lbf·ft)  
15 N·m (1.5 kgf·m, 11 lbf·ft)

CT bolt  
Apply a locking agent to the threads.

# LUBRICATION SYSTEM


## TOOLS

Oil pressure gauge set  
07506-300001



or equivalent commercially available.

Oil pressure gauge attachment  
07406-0030000



or equivalent commercially available.

## TROUBLESHOOTING

### Oil level too low

- Oil consumption
- External oil leak
- Worn piston rings
- Improperly installed piston rings
- Worn cylinders
- Worn valve stem seals
- Worn valve guide

### Low oil pressure

- Oil level low
- Clogged oil strainer
- Internal oil leak
- Incorrect oil being used

### No oil pressure

- Oil level too low
- Oil pressure relief valve stuck open
- Broken oil pump drive chain
- Broken oil pump drive or driven sprocket
- Damaged oil pump
- Internal oil leak

### High oil pressure

- Oil pressure relief valve stuck closed
- Clogged oil filter, oil cooler gallery or metering orifice
- Incorrect oil being used

### Oil contamination

- Oil or filter not changed often enough
- Worn piston rings


### Oil emulsification

- Blown cylinder head gasket
- Leaky coolant passage
- Entry of water

## OIL PRESSURE INSPECTION

*If the oil pressure indicator light remains on while the engine is running, check the indicator system before checking the oil pressure.*


Remove the rubber cap from the EOP switch.  
Remove the terminal bolt and disconnect the EOP switch wire.  
Remove the EOP switch while holding the switch base.



Install the oil pressure gauge attachment to the switch base.  
Connect the oil pressure gauge to the oil pressure gauge attachment.

### TOOLS:

<b>Oil pressure gauge set</b>	<b>07506-3000001 or equivalent commercially available</b>
<b>Oil pressure gauge attachment</b>	<b>07406-0030000 or equivalent commercially available</b>



Check the oil level and add the recommended oil if necessary (page 3-16).

Warm the engine to normal operating temperature (approximately 80°C/176°F) and increase the engine speed to 6,000 min<sup>-1</sup> (rpm) and read the oil pressure.

### OIL PRESSURE:

**510 kPa (5.2 kgf/cm<sup>2</sup>, 74 psi) at 6,000 min<sup>-1</sup> (rpm)/ (80°C/176°F)**


Stop the engine and remove the tools.

Install the EOP switch (page 20-21).  
Check the oil level and add the recommended oil if the level is below the lower level line (page 3-16).


# OIL STRAINER/PRESSURE RELIEF VALVE

## REMOVAL


Drain the engine oil (page 3-16).  
Remove the exhaust pipe (page 2-19).  
Remove the flange bolts and the oil pan.



Remove the oil strainer and packing.  
Clean the oil strainer screen.




Remove the pressure relief valve and O-ring.




## INSPECTION

Check the operation of the pressure relief valve by pushing on the piston.  
Disassemble the relief valve by removing the snap ring.  
Inspect the piston for wear, unsmooth movement or damage.  
Inspect the spring for fatigue or damage.  
Assemble the relief valve in the reverse order of disassembly.




**INSTALLATION**

Apply engine oil to new packing and install it onto the oil strainer flange.  
Install the oil strainer into the oil pump while aligning the oil strainer boss with the groove of the oil pump.




Apply engine oil to new O-ring and install it onto the relief valve groove.  
Install the relief valve into the crankcase.



Clean the oil pan mating surface thoroughly.

*Do not apply more sealant than necessary.*


Apply sealant (Three Bond 1207B or an equivalent) to the mating surface.



Install the oil pan onto the lower crankcase.  
Install the flange bolts.  
Tighten the bolts in a crisscross pattern in two to three steps.

Install the exhaust pipe (page 2-23).  
Fill the crankcase with the recommended oil (page 3-16).

After installation, check that there are no oil leaks.




## OIL PUMP

### REMOVAL

Drain the engine oil (page 3-16).  
Remove the clutch (page 9-18).

*To gain access to the oil pump driven sprocket, first remove the oil pan.*


Remove the bolt/washer and oil pump driven sprocket.




Remove the oil pan (page 4-6).

Remove the following:

- Oil pump mounting bolts
- Oil pump assembly




- Dowel pins
- Oil pass collar/O-ring




### DISASSEMBLY

Remove the oil pump assembly bolts.






Remove the oil pump cover and dowel pins.



Remove the thrust washer, drive pin, oil pump shaft, outer rotor and inner rotor from the oil pump body.

Clean all disassembly parts in solvent thoroughly.



**INSPECTION**

*If any portion of the oil pump is worn beyond the service limit, replace the oil pump as an assembly.*


Temporarily install the outer and inner rotors into the oil pump body.

Temporarily install the drive pin and oil pump shaft.

Measure the rotor tip clearance.

**SERVICE LIMIT: 0.20 mm (0.008 in)**


TIP CLEARANCE:



Measure the pump body clearance.

**SERVICE LIMIT: 0.35 mm (0.014 in)**


BODY CLEARANCE:




# LUBRICATION SYSTEM

Measure the side clearance using a straight edge and feeler gauge.


**SERVICE LIMIT: 0.17 mm (0.007 in)**




## ASSEMBLY




Dip all parts in clean engine oil.  
Install the outer rotor into the oil pump body.  
Install the inner rotor into the outer rotor with its drive pin groove facing the oil pump cover.



Install the oil pump shaft through the inner rotor and oil pump body.  
Install the drive pin into the hole in the oil pump shaft and align the drive pin with the groove in the inner rotor.  
Install the thrust washer.




Install the dowel pins into the oil pump cover.  
Install the oil pump cover to the oil pump body.



Install and tighten the oil pump assembly bolts to the specified torque.


**TORQUE: 8.0 N·m (0.8 kgf·m, 5.9 lbf·ft)**

Check the oil pump operation by turning the pump shaft.  
If necessary, reassemble the oil pump.




## INSTALLATION

Install the dowel pins.  
Apply engine oil to new O-ring and install it with the oil pass collar.




## LUBRICATION SYSTEM

Install the oil pump assembly onto the crankcase while aligning the oil pump shaft lug with the water pump shaft groove by turning the oil pump shaft.



Install and tighten the flange bolts securely.



Apply oil to the oil pump driven sprocket and drive chain

Install the driven sprocket with its "OUT" mark facing out.

Apply a locking agent to the oil pump driven sprocket bolt threads.

Install and tighten the driven sprocket bolt/washer to the specified torque.


**TORQUE: 15 N·m (1.5 kgf·m, 11 lbf·ft)**

Install the clutch (page 9-25).

Install the right crankcase cover (page 9-25).

After installation, fill the crankcase with the recommended oil (page 3-16) and check that there is no oil leaks.

Check the oil pressure (page 4-5).




# OIL COOLER

## REMOVAL

Drain the engine oil (page 3-16).


Drain the coolant from the system (page 6-7).

Loosen the hose band screws and disconnect the oil cooler water hoses from the oil cooler.




Remove the three bolts and the oil cooler.

Check the oil cooler for damage.




## INSTALLATION

Coat a new O-ring with engine oil and install it into the oil cooler groove.



Install the oil cooler onto the crankcase.

Install and tighten the three bolts securely.




## LUBRICATION SYSTEM

Connect the oil cooler water hoses to the oil cooler and tighten the hose band screws securely.

Fill the crankcase with the recommended oil (page 3-16) and check that there is no oil leaks.

Fill the cooling system and bleed any air (page 6-7).




# 5. FUEL SYSTEM (PGM-FI)

---

COMPONENT LOCATION .....	5-2	FUEL TANK .....	5-60
SERVICE INFORMATION .....	5-3	AIR CLEANER HOUSING .....	5-62
PGM-FI SYMPTOM TROUBLESHOOTING .....	5-6	THROTTLE BODY .....	5-85
PGM-FI SYSTEM LOCATION .....	5-7	INJECTOR .....	5-88
PGM-FI SYSTEM DIAGRAM .....	5-8	ENGINE IDLE SPEED .....	5-93
PGM-FI CONNECTOR LOCATIONS .....	5-9	IACV .....	5-94
PGM-FI TROUBLESHOOTING INFORMATION .....	5-12	MAP SENSOR .....	5-96
DTC INDEX .....	5-17	IAT SENSOR .....	5-96
DTC TROUBLESHOOTING .....	5-18	ECT SENSOR .....	5-96
MIL TROUBLESHOOTING .....	5-36	BANK ANGLE SENSOR .....	5-97
MIL CIRCUIT TROUBLESHOOTING .....	5-52	ENGINE STOP RELAY .....	5-99
FUEL LINE INSPECTION .....	5-52	ECM .....	5-100
FUEL PUMP .....	5-57	SECONDARY AIR SUPPLY SYSTEM ....	5-102
FUEL CUT-OFF RELAY .....	5-59	O <sub>2</sub> SENSOR .....	5-104
		INTAKE AIR DUCT .....	5-105

---

COMPONENT LOCATION





# SERVICE INFORMATION

## GENERAL

- Work in a well ventilated area. Smoking or allowing flames or sparks in the work area or where gasoline is stored can cause a fire or explosion.
- Before disconnecting the fuel feed hose, relieve fuel pressure from the system by disconnecting the quick connect fitting of the fuel tank.
- Bending or twisting the control cables will impair smooth operation and could cause the cables to stick or bind, resulting in loss of vehicle control.
- Do not apply commercially available carburetor cleaners to the inside of the throttle bore.
- Do not snap the throttle valve from full open to full close after the throttle cable has been removed. It may cause incorrect idle operation.
- Seal the intake manifold ports with tape or a clean cloth to keep dirt and debris from entering the engine after the throttle body has been removed.
- Do not damage the throttle body. It may cause incorrect throttle synchronization.
- Prevent dirt and debris from entering the throttle bore and air passages after the throttle body has been removed. Clean them using compressed air if necessary.
- The throttle body is factory pre-set. Do not disassemble in a way other than shown in this manual.
- Do not loosen or tighten the white painted bolts, nuts and screws of the throttle body. Loosening or tightening them can cause throttle synchronization failure.
- The parts of the throttle body not shown in this manual should not be disassembled.
- Always replace the packing when the fuel pump is removed.
- A faulty PGM-FI system is often related to poorly connected or corroded connectors. Check those connections before proceeding.
- The VS sensor sends digital pulse signal to the ECM and computation. Refer to procedures for VS sensor inspection.
  - DTC troubleshooting (page 5-18)
  - MIL troubleshooting (page 5-36)
- When disassembling the fuel system parts, note the location of the O-rings. Replace them with new ones upon reassembly.
- Use a digital tester for PGM-FI system inspection.
- Refer to the fuel level sensor inspection (page 20-24).
- If replacing the ECM, always follow the steps in the IMMOBILIZER SYSTEM (page 21-2).

## SPECIFICATIONS

ITEM	SPECIFICATIONS
Throttle body identification number	GQ3EA
Idle speed	1,200 ± 100 min <sup>-1</sup> (rpm)
Throttle grip free play	2 – 6 mm (1/16 – 1/4 in)
IAT sensor resistance (at 20°C/68°F)	1 – 4 kΩ
ECT sensor resistance (at 20°C/68°F)	2.3 – 2.6 kΩ
Fuel injector resistance (at 20°C /68°F)	11.1–12.3 Ω
PAIR control solenoid valve resistance (at 20°C/68°F)	23 – 27 Ω
Intake duct control (IDC) solenoid valve resistance (at 20°C/68°F)	28 – 32 Ω
CKP sensor peak voltage (at 20°C/68°F)	0.7 V minimum
Fuel pressure at idle	343 kPa (3.5 kgf/cm <sup>2</sup> , 50 psi)
Fuel pump flow (at 12 V)	189 cm <sup>3</sup> (6.4 US oz, 6.7 Imp oz) minimum/10 seconds











## FUEL SYSTEM (PGM-FI)

---

### TORQUE VALUES

Fuel tank rear mounting nut	12 N·m (1.2 kgf·m, 9 lbf·ft)	
Fuel filler cap mounting bolt	1.8 N·m (0.2 kgf·m, 1.3 lbf·ft)	
Fuel pump mounting nut	12 N·m (1.2 kgf·m, 9 lbf·ft)	
Insulator band screw (Throttle body side)	See page 5-87	
Insulator band screw (Cylinder head side)	See page 5-77	
IACV setting plate screw	2.1 N·m (0.2 kgf·m, 1.5 lbf·ft)	
IACV joint screw	2.1 N·m (0.2 kgf·m, 1.5 lbf·ft)	
Fuel rail mounting bolt	5.1 N·m (0.5 kgf·m, 3.8 lbf·ft)	
ECT sensor	23 N·m (2.3 kgf·m, 17 lbf·ft)	
Right resonator air duct screw	0.8 N·m (0.1 kgf·m, 0.6 lbf·ft)	
Right front resonator screw	1.1 N·m (0.1 kgf·m, 0.8 lbf·ft)	
Right air cleaner duct screw	1.1 N·m (0.1 kgf·m, 0.8 lbf·ft)	
Upper air cleaner housing screw	1.1 N·m (0.1 kgf·m, 0.8 lbf·ft)	
Air cleaner housing mounting bolt	3.5 N·m (0.4 kgf·m, 2.6 lbf·ft)	
Footpeg holder mounting bolt	37 N·m (3.8 kgf·m, 27 lbf·ft)	
Swing arm pivot nut	98 N·m (10.0 kgf·m, 72 lbf·ft)	U-nut
Pivot bracket upper nut	69 N·m (7.0 kgf·m, 51 lbf·ft)	
Pivot bracket lower nut	69 N·m (7.0 kgf·m, 51 lbf·ft)	
O <sub>2</sub> sensor	24.5 N·m (2.5 kgf·m, 18 lbf·ft)	

TOOLS


<p>Fuel pressure gauge 07406-0040004</p> 	<p>Pressure gauge manifold 07ZAJ-S5A0111</p> 	<p>Pressure gauge hose attachment C 07ZAJ-S7C0100</p> 	
<p>Pressure gauge hose attachment A 07ZAJ-S5A0120</p> 	<p>Fuel attachment joint C 07ZAJ-S7C0200</p> 	<p>ECM test harness 33P 070MZ-MCA0100</p> 	
<p>SCS connector 070PZ-ZY30100</p> 	<p>Inspection test harness 07GMJ-ML80100</p> 	<p>Test probe 07ZAJ-RDJA110</p> 	
<p>Imrie diagnostic tester (model 625) or Peak voltage adaptor 07HGJ-0020100</p>  <p>with commercially available digital multimeter (impedance 10 MΩ/DCV minimum)</p>			

**PGM-FI SYMPTOM TROUBLESHOOTING**


When the motorcycle has one of these symptoms, check the DTC or MIL blinking, refer to the DTC index (page 5-17) and begin the appropriate troubleshooting procedure. If there are no DTC/MIL blinking stored in the ECM memory, do the diagnostic procedure for the symptom, in sequence listed below, until you find cause.

Symptom	Diagnosis procedure	Also check for
Engine cranks but won't start (No DTC and MIL blinking)	<ol style="list-style-type: none"> <li>1. Crank the starter for more than ten seconds and check the DTC (page 5-14) and execute the troubleshooting according to the DTC.</li> <li>2. Inspect the fuel supply system (page 5-52).</li> </ol>	<ul style="list-style-type: none"> <li>• No fuel to injector                             <ul style="list-style-type: none"> <li>– Clogged fuel filter</li> <li>– Pinched or clogged fuel feed hose</li> <li>– Pinched or clogged fuel tank breather hose</li> </ul> </li> <li>– Faulty fuel pump</li> <li>– Faulty fuel pump circuits</li> <li>• Intake air leak</li> <li>• Contaminated/deteriorated fuel</li> <li>• Faulty fuel injector</li> <li>• IACV stuck</li> <li>• Faulty ignition system</li> </ul>
Engine cranks but won't start (No fuel pump operation sound when the turning the ignition ON)	<ol style="list-style-type: none"> <li>1. ECM power/ground circuits malfunction (page 5-100)</li> <li>2. Inspect the fuel supply system (page 5-52).</li> </ol>	<ul style="list-style-type: none"> <li>• Open circuit in the power input and/or ground wire of the ECM</li> <li>• Faulty bank angle sensor or related circuit</li> <li>• Faulty FI/IGN relay or related circuit</li> <li>• Faulty engine stop switch or related circuit</li> <li>• Blown FI/IGN fuse (20 A)</li> <li>• Blown STARTER/BANK ANGLE SENSOR fuse (10 A)</li> </ul>
Engine stalls, hard to start, rough idling	<ol style="list-style-type: none"> <li>1. Check the idle speed.</li> <li>2. Check the IACV.</li> <li>3. Inspect the fuel supply system (page 5-52).</li> </ol>	<ul style="list-style-type: none"> <li>• Restricted fuel feed hose</li> <li>• Contaminated/deteriorated fuel</li> <li>• Intake air leak</li> <li>• Faulty IACV</li> <li>• Restricted fuel tank breather hose</li> <li>• Faulty ignition system</li> </ul>
Afterburn when engine braking is used	Check the PAIR system (page 5-102).	<ul style="list-style-type: none"> <li>• Faulty PAIR system                             <ul style="list-style-type: none"> <li>– Faulty PAIR control solenoid valve</li> <li>– Faulty PAIR check valve</li> <li>– Clogged hose of the PAIR system</li> </ul> </li> <li>• Faulty ignition system</li> </ul>
Backfiring or misfiring during acceleration	Check the ignition system.	<ul style="list-style-type: none"> <li>• Faulty ignition system</li> </ul>
Poor performance (driveability) and poor fuel economy	<ol style="list-style-type: none"> <li>1. MAP sensor and its hoses connection</li> <li>2. Inspect the fuel supply system</li> </ol>	<ul style="list-style-type: none"> <li>• Pinched or clogged fuel feed hose</li> <li>• Faulty pressure regulator (fuel pump)</li> <li>• Faulty injector</li> <li>• Faulty ignition system</li> <li>• MAP sensor</li> <li>• MAP sensor hose</li> </ul>
Idle speed is below specifications or fast idle too low (No DTC and MIL blinking)	<ol style="list-style-type: none"> <li>1. Check the idle speed</li> <li>2. Check the IACV</li> </ol>	<ul style="list-style-type: none"> <li>• IACV stuck closed</li> <li>• Faulty fuel supply system</li> <li>• Faulty ignition system</li> </ul>
Idle speed is above specifications or fast idle too high (No DTC and MIL blinking)	<ol style="list-style-type: none"> <li>1. Check the idle speed</li> <li>2. Check the throttle operation and lever freeplay</li> <li>3. Check the IACV</li> </ol>	<ul style="list-style-type: none"> <li>• IACV stuck opened</li> <li>• Faulty ignition system</li> <li>• Intake air leak</li> <li>• Engine top end problem</li> <li>• Air cleaner condition</li> </ul>
MIL stays ON but no DTCs set, or MIL never comes ON at all	Troubleshoot the MIL circuit (page 5-52).	<ul style="list-style-type: none"> <li>• Faulty MIL circuit</li> </ul>
MIL stays ON at all (No DTC set)	Inspect the DLC circuit.	<ul style="list-style-type: none"> <li>• Short circuit in the DLC related wire</li> </ul>


# PGM-FI SYSTEM LOCATION



PGM-FI SYSTEM DIAGRAM




(FI) ( ): DTC/MIL number  
 ⊗ : Engine does not start when detecting DTC/MIL  
 : Short terminals for reading MIL




# PGM-FI CONNECTOR LOCATIONS

NOTE 1: Remove the left side cover (page 2-5).




NOTE 2: Remove the right side cover (page 2-5).




# FUEL SYSTEM (PGM-FI)

ECM 33P (Black) AND 33P (Light gray) CONNECTORS  
(NOTE 2)



NOTE 3: Remove the air cleaner housing (page 5-60).




VS SENSOR 3P (Natural) CONNECTOR  
(NOTE 3)




NOTE 4: Lift and support fuel tank (page 3-5).

NOTE 5: Remove the fuel tank (page 5-60).

MAP SENSOR 3P (Black) CONNECTOR  
(NOTE 4)



IACV 4P (Black) CONNECTOR  
(NOTE 5)



ECT SENSOR 3P (Black)  
CONNECTOR (NOTE 4)

## PGM-FI TROUBLESHOOTING INFORMATION

### GENERAL TROUBLESHOOTING

#### Intermittent Failure

The term "intermittent failure" means a system may have had a failure, but it checks OK now. If the MIL does not come on, check for poor contact or loose pins at all connectors related to the circuit that of the troubleshooting. If the MIL was on, but then went out, the original problem may be intermittent.

#### Opens and Shorts

"Opens" and "Shorts" are common electrical terms. An open is a break in a wire or at a connection. A short is an accidental connection of a wire to ground or to another wire. In simple electronics, this usually means something will not work at all. With ECMs this can something mean something work, but not the way it's supposed to.

#### If the MIL has come on

Refer to DTC READOUT (page 5-14).

#### If the MIL did not stay on

If the MIL did not stay on, but there is a driveability problem, do the SYMPTOM TROUBLESHOOTING (page 5-6).

### SYSTEM DESCRIPTION

#### SELF-DIAGNOSIS SYSTEM

The PGM-FI system is equipped with the self-diagnostic system. When any abnormality occurs in the system, the ECM turns on the MIL and stores a DTC in its erasable memory.

#### FAIL-SAFE FUNCTION

The PGM-FI system is provided with a fail-safe function to secure a minimum running capability even when there is trouble in the system. When any abnormality is detected by the self-diagnosis function, running capability is maintained by pre-programmed value in the simulated program map. When any abnormality is detected in the injector(s) and/or crankshaft position (CKP) sensor, the fail-safe function stops the engine to protect it from damage.

#### DTC (Diagnostic Trouble Code)


- The DTC is composed of a main code and a sub code and it is displayed as a hyphenated number when retrieved from the ECM with the HDS pocket tester.

The digits in front of the hyphen are the main code, they indicate the component of function failure.

The digits behind the hyphen are the sub code, they detail the specific symptom of the component or function failure.


For example, in the case of the TP sensor:

- DTC 08 - 1 = (TP sensor voltage) - (lower than the specified value)
  - DTC 08 - 2 = (TP sensor voltage) - (higher than the specified value).
- The MAP, ECT, TP and IAT sensor diagnosis will be made according to the voltage output of the affected sensor. If a failure occurs, the ECM determines the Function Failure, compares the sensor voltage output to the standard value, and then outputs the corresponding DTC to the HDS Pocket Tester.
- For example:
- If the input voltage line (A) on the MAP sensor is opened, the ECM detects the output voltage is about 5 V, then the DTC 1-2 (MAP sensor circuit high voltage) will be displayed.
  - If the input voltage line (B) on the TP sensor is opened, the ECM detects the output voltage is 0 V, then the DTC 8-1 (TP sensor circuit low voltage) will be displayed.



**MIL Blink Pattern**

- If the HDS pocket tester is not available, DTC can be read from the ECM memory by the MIL blink pattern.
- The number of MIL blinks is the equivalent of the main code of the DTC (the sub code cannot be displayed by the MIL).
- The MIL will blink the current DTC, in case the ECM detects the problem at present, when the ignition switch ON or idling with the side stand down. The MIL will stay ON when the engine speed is over 5,000 min<sup>-1</sup> (rpm) or with the side stand up.
- The MIL has two types of blinks, a long blink and short blink. The long blinking lasts for 1.3 seconds, the short blinking lasts for 0.5 seconds. One long blink is the equivalent of ten short blinks. For example, when two long blinks are followed by five short blinks, the MIL is 25 (two long blinks = 20 blinks, plus five short blinks).
- When the ECM stores more than one DTC, the MIL will indicate them by blinking in the order from the lowest number to highest number.



**MIL Check**

When the ignition switch is turned ON and engine stop switch "O", the MIL will stay on for a few seconds, then go off. If the MIL does not come on, troubleshoot the MIL circuit (page 5-52).

**CURRENT DTC/FREEZE DTC**

The DTC is indicated in two ways according to the failure status.

- In case the ECM detects the problem at present, the MIL will come on and the MIL will start to blink as its DTC when the sidestand is lowered. It is possible to readout the MIL blink pattern as the current DTC.
- In case the ECM does not detect any problem at present but has a problem stored in its memory, the MIL will not light and blink. If it is necessary to retrieve the past problem, readout the freeze DTC by following the DTC readout procedure (page 5-14).

## HDS POCKET TESTER INFORMATION

- The HDS can readout the DTC, freeze data, current data and other ECM condition.

### How to connect the HDS Pocket Tester

Turn the ignition switch to OFF.

Remove the right side cover (page 2-5).

Remove the dummy connector from the DLC.

Connect the HDS pocket tester to the DLC.

Turn the ignition switch ON and engine stop switch "O", check the DTC and freeze data.

### NOTE:

- Freeze data indicates the engine conditions when the first malfunction was detected.

### ECM reset

The HDS can reset the ECM data including the DTC, freeze data and some learning memory.

## DTC READOUT



Start the engine and check the MIL.

- If the engine will not start, turn the starter motor for more than 10 seconds and check that the MIL blinks.
- When the ignition switch is turned ON, the MIL will stay on for a few seconds, then go off.

If the MIL stays on or blinks, connect the HDS Pocket Tester to the DLC (page 5-14).

Read the DTC, freeze data and follow the troubleshooting index (page 5-17).

To read the DTC with the MIL blinking, refer to the following procedure.



### Reading DTC with the MIL

Turn the ignition switch to OFF.

Remove the right side cover (page 2-5).

Remove the dummy connector and short DLC terminals using the special tool.

### TOOL:


**SCS connector** 070PZ-ZY30100

**CONNECTION:** Brown – Green

Turn the ignition switch ON, read, note the MIL blinks and refer to the troubleshooting index (page 5-17).

### NOTE:

If the ECM has any DTC in its memory, the MIL will start blinking.



## CLEARING DTC

Connect the HDS Pocket Tester to the DLC (page 5-14).

Clear the DTC with the HDS Pocket Tester while the engine is stopped.

To clear the DTC without HDS Pocket Tester, refer to the following procedure.

### How to clear the DTC with SCS connector


1. Remove the right side cover (page 2-5).
2. Turn the ignition switch to OFF.  
Make sure the engine stop switch is turned to "O".
3. Remove the dummy connector and short the Brown and Green wire terminals of the DLC using the special tool.

**TOOL:**

**SCS connector** 070PZ-ZY30100

**CONNECTION:** Brown – Green

4. Turn the ignition switch to ON.
5. Remove the special tool wire from the DLC.
6. The MIL will light for approximately 5 seconds.  
While the MIL lights, short the DLC terminals again with the special tool. The self-diagnostic memory is erased if the malfunction indicator goes off and starts blinking.



**NOTE:**

- The DLC must be jumped while the MIL lights. If not, the MIL will not start blinking.
- Note that the self-diagnostic memory cannot be erased if the ignition switch is turned to "OFF" before the MIL starts blinking.


## CIRCUIT INSPECTION

### INSPECTION AT ECM CONNECTOR

- Always clean around and keep any foreign material away from the ECM connector before disconnecting it.
- A faulty PGM-FI system is often related to poorly connected or corroded terminals. Check those connections before proceeding.
- In testing at ECM connector (wire harness side) terminal, always use the test probe. Insert the test probe into the connector terminal, then attach the digital multimeter probe to the test probe.

**TOOL:**

**Test probe** 07ZAJ-RDJA110




### TEST HARNESS CONNECTION

Remove the right side cover (page 2-5).

Turn the ignition switch to "OFF".

Pull out the ECM from stay.

Disconnect the 33P connectors from the ECM.




# FUEL SYSTEM (PGM-FI)

Connect the ECM test harness between the main wire harness and the ECM.

**TOOL:**


ECM test harness 33P

070MZ-MCA0100




**TEST HARNESS TERMINAL LAYOUT**

The ECM connector terminals are numbered as shown in this illustration.



The ECM test harness terminals are same layout as for the ECM connector terminals as shown.



# DTC INDEX

DTC (MIL blinks)	Function Failure	Symptom/Fail-safe function	Refer to (DTC)	Refer to (MIL)
1-1 (1)	MAP sensor circuit low voltage (less than 0.2 V) • MAP sensor or its circuit malfunction	• Engine operates normally • Fail-safe value: 760 mmHg/1,013 hPa	5-18	5-36
1-2 (1)	MAP sensor circuit high voltage (more than 3.9 V) • Loose or poor contact of the MAP sensor connector • MAP sensor or its circuit malfunction	• Engine operates normally • Fail-safe value: 760 mmHg/1,013 hPa	5-19	
2-1 (2)	MAP sensor hose connection • Disconnection or poor connection of the MAP sensor hoses	• Engine operates normally	5-21	5-38
7-1 (7)	ECT sensor circuit low voltage (less than 0.07 V) • ECT sensor or its circuit malfunction	• Hard start at a low temperature • Fail-safe value: 85°C/185°F • Cooling fan turns on	5-22	5-39
7-2 (7)	ECT sensor circuit high voltage (more than 4.93 V) • Loose or poor contact of the ECT sensor connector • ECT sensor or its circuit malfunction	• Hard start at a low temperature • Fail-safe value: 85°C/185°F • Cooling fan turns on	5-23	
8-1 (8)	TP sensor circuit low voltage (less than 0.3 V) • TP sensor or its circuit malfunction	• Poor engine acceleration • Fail-safe value: 0°	5-24	5-41
8-2 (8)	TP sensor circuit high voltage (more than 4.93 V) • Loose or poor contact of the TP sensor connector • TP sensor or its circuit malfunction	• Poor engine acceleration • Fail-safe value: 0°	5-26	
9-1 (9)	IAT sensor circuit low voltage (less than 0.07 V) • IAT sensor or its circuit malfunction	• Engine operates normally • Fail-safe value: 28°C/82°F	5-27	5-43
9-2 (9)	IAT sensor circuit high voltage (more than 4.93 V) • Loose or poor contact of the IAT sensor connector • IAT sensor or its circuit malfunction	• Engine operates normally • Fail-safe value: 28°C/82°F	5-28	
11-1 (11)	VS sensor no signal • Loose or poor contact of the VS sensor connector • VS sensor or its circuit malfunction	• Engine operates normally	5-29	5-44
12-1 (12)	No. 1 injector circuit malfunction • Loose or poor contact of the injector connector • Injector or its circuit malfunction	• Engine does not start • Injectors, fuel pump and ignition shut down	5-30	5-46
13-1 (13)	No. 2 injector circuit malfunction • Loose or poor contact of the injector connector • Injector or its circuit malfunction	• Engine does not start • Injectors, fuel pump and ignition shut down	5-31	5-47
14-1 (14)	No. 3 injector circuit malfunction • Loose or poor contact of the injector connector • Injector or its circuit malfunction	• Engine does not start • Injectors, fuel pump and ignition shut down	5-31	5-47
15-1 (15)	No. 4 injector circuit malfunction • Loose or poor contact of the injector connector • Injector or its circuit malfunction	• Engine does not start • Injectors, fuel pump and ignition shut down	5-31	5-47
21-1 (21)	O <sub>2</sub> sensor malfunction • Loose or poor contact of the O <sub>2</sub> sensor connector • O <sub>2</sub> sensor or its circuit malfunction	• Engine operates normally	5-32	5-48
23-1 (23)	O <sub>2</sub> sensor heater circuit malfunction • Loose or poor contact of the O <sub>2</sub> sensor heater connector • O <sub>2</sub> sensor heater or its circuit malfunction	• Engine operates normally	5-33	5-49
29-1 (29)	IACV circuit malfunction • Loose or poor contact of the IACV connector • IACV or its circuit malfunction	• Engine stalls, hard to start, rough idling	5-34	5-50

## DTC TROUBLESHOOTING

### DTC 1-1 (MAP SENSOR LOW VOLTAGE)

- Before starting the inspection, check for loose or poor contact on the MAP sensor 3P (Black) connector and ECM 33P connectors, then recheck the DTC.

#### 1. MAP Sensor System Inspection

Turn the ignition switch ON and engine stop switch "O".  
Check the MAP sensor with the HDS pocket tester.

**Is about 0 V indicated?**

**YES** – GO TO STEP 2.

**NO** – Intermittent failure

#### 2. MAP Sensor Input Voltage Inspection

Turn the ignition switch OFF.  
Disconnect the MAP sensor 3P (Black) connector.

Turn the ignition switch ON and engine stop switch "O".


Measure the voltage at the wire harness side.

**Connection: Yellow/red (+) – Green/orange (-)**

**Is the voltage within 4.75 – 5.25 V?**

**YES** – GO TO STEP 4.

**NO** – GO TO STEP 3.



#### 3. MAP Sensor Input Line Inspection

Turn the ignition switch OFF.  
Disconnect the ECM 33P (Black) connectors.

Check for continuity at the Yellow/red wire between the MAP sensor 3P (Black) connector terminal and the ECM 33P (Black) connector.

**Connection: A9 – Yellow/red**


**TOOL:**

Test probe 07ZAJ-RDJA110

**Is there continuity?**

**YES** – Replace the ECM with a known good one, and recheck; refer to Key Registration Procedures (page 21-6)

**NO** – Open circuit in Yellow/red wire





**4. MAP Sensor Output Line Short Circuit Inspection**

Turn the ignition switch OFF.


Check for continuity between the MAP sensor 3P (Black) connector terminal of the wire harness side and ground.

**Connection:** Light green/yellow – ground

**Is there continuity?**

**YES** – Short circuit in Light green/yellow wire

**NO** – GO TO STEP 5.



**5. MAP Sensor Inspection**

Replace the MAP sensor with a known good one (page 5-96).

Clear the ECM self-diagnosis memory data (page 5-15).

Turn the ignition switch ON and engine stop switch "O".

Check the MAP sensor with the HDS pocket tester.

**Is DTC 1-1 indicated?**

**YES** – Replace the ECM with a known good one, and recheck; refer to Key Registration Procedures (page 21-6)

**NO** – Faulty original MAP sensor

**DTC 1-2 (MAP SENSOR HIGH VOLTAGE)**

- Before starting the inspection, check for loose or poor contact on the MAP sensor 3P (Black) connector and ECM 33P connectors, then recheck the DTC.

**1. MAP Sensor System Inspection 1**

Turn the ignition switch ON and engine stop switch "O".

Check the MAP sensor with the HDS pocket tester.

**Is about 5 V indicated?**

**YES** – GO TO STEP 2.

**NO** – Intermittent failure

**2. MAP Sensor System Inspection 2**

Turn the ignition switch OFF.

Disconnect the MAP sensor 3P (Black) connector.

Connect the MAP sensor terminals at the wire harness side with a jumper wire.

**Connection: Light green/yellow – Green/orange**


Turn the ignition switch ON and engine stop switch "O".

Check the MAP sensor with the HDS pocket tester.

**Is about 0 V indicated?**

**YES** – Faulty MAP sensor

**NO** – GO TO STEP 3.



**3. MAP Sensor Input Voltage Inspection**

Turn the ignition switch OFF.

Remove the jumper wire.

Turn the ignition switch ON and engine stop switch "O".

Measure the voltage at the wire harness side.


**Connection: Yellow/red (+) – Green/orange (-)**

**Is the voltage within 4.75 – 5.25 V?**

**YES** – GO TO STEP 4.

**NO** –

- Open circuit in Yellow/red wire
- Open circuit in Green/orange wire



**4. MAP Sensor Output Line Open Circuit Inspection**

Disconnect the ECM 33P (Light gray) connectors. Check for continuity at the Light green/yellow wire between the MAP sensor 3P (Black) connector terminal and the ECM 33P (Light gray) connector.

**Connection: B9 – Light green/yellow**


**TOOL:**

**Test probe** 07ZAJ-RDJA110

**Is there continuity?**

**YES** – Replace the ECM with a known good one, and recheck; refer to Key Registration Procedures (page 21-6)

**NO** – Open circuit in Light green/yellow wire



## DTC 2-1 (MAP SENSOR HOSE CONNECTION)

- Before starting the inspection, check for loose or poor contact on the MAP sensor 3P (Black) connector and ECM 33P connectors, then recheck the DTC.

### 1. MAP Sensor System Inspection

Turn the ignition switch ON and engine stop switch "○".

Start the engine and check the MAP sensor with the HDS pocket tester.  
The MAP sensor voltage should be changed after engine started.

**Is the MAP sensor voltage indicated normally?**

**YES** – Intermittent failure

**NO** – GO TO STEP 2.

### 2. MAP sensor hose inspection


Turn the ignition switch OFF.

Check for connection and installation of the MAP sensor vacuum hose.

**Is the MAP sensor vacuum hose connection correct?**

**YES** – GO TO STEP 3.

**NO** – Correct the hose installation



### 3. MAP Sensor System Inspection

Replace the MAP sensor with a known good one (page 5-96).

Turn the ignition switch ON and engine stop switch "○".

Start the engine and check the MAP sensor with the HDS pocket tester.

The MAP sensor voltage should be changed after engine started.

**Is the MAP sensor voltage normally?**

**YES** – Faulty original MAP sensor

**NO** – Replace the ECM with a known good one, and recheck; refer to Key Registration Procedures (page 21-6)

**DTC 7-1 (ECT SENSOR LOW VOLTAGE)**

- Before starting the inspection, check for loose or poor contact on the ECT sensor 3P (Black) connector and ECM 33P connectors, then recheck the DTC.

**1. ECT Sensor System Inspection**

Turn the ignition switch ON and engine stop switch "O".

Check the ECT sensor with the HDS pocket tester.

**Is about 0 V indicated?**

**NO** – Intermittent failure

**YES** – GO TO STEP 2.

**2. ECT Sensor Inspection**


Turn the ignition switch OFF.  
Disconnect the ECT sensor 3P (Black) connector.

Turn the ignition switch ON and engine stop switch "O".  
Check the ECT sensor with the HDS pocket tester.

**Is about 0 V indicated?**

**NO** – GO TO STEP 3.

**YES** – GO TO STEP 4.



**3. ECT Sensor Resistance Inspection**

Turn the ignition switch OFF.


Measure the resistance at the ECT sensor terminals.

**CONNECTION:** Pink/white – Green/orange  
**STANDARD:** 2.3 – 2.6 k $\Omega$  (20°C/68°F)

**Is the resistance within 2.3 – 2.6 k $\Omega$  (20°C/68°F)?**

**YES** – Replace the ECM with a new one, and recheck; refer to Key Registration Procedures (page 21-6)

**NO** – Faulty ECT sensor.



**4. ECT Sensor Short Circuit Inspection**

Turn the ignition switch OFF.

Disconnect the ECM 33P connectors.


Check for continuity between the ECT sensor 3P (Black) connector terminal of the wire harness side and ground.

**Connection:** Pink/white – ground

**Is there continuity?**

**YES** – Short circuit in Pink/white wire

**NO** – Replace the ECM with a known good one, and recheck; refer to Key Registration Procedures (page 21-6)



**DTC 7-2 (ECT SENSOR HIGH VOLTAGE)**

- Before starting the inspection, check for loose or poor contact on the ECT sensor 3P (Black) connector and ECM 33P connectors, then recheck the DTC.

**1. ECT Sensor System Inspection**

Turn the ignition switch ON and engine stop switch "O".

Check the ECT sensor with the HDS pocket tester.

**Is about 5 V indicated?**

**NO** – Intermittent failure

**YES** – GO TO STEP 2.

**2. ECT Sensor Inspection**

Turn the ignition switch OFF.

Disconnect the ECT sensor 3P (Black) connector. Connect the ECT sensor terminals with a jumper wire.

**Connection: Pink/white – Green/orange**

Turn the ignition switch ON and engine stop switch "O". Check the ECT sensor with the HDS pocket tester.

**Is about 0 V indicated?**

**YES** – Inspect the ECT sensor (page 20-20).

**NO** – GO TO STEP 3.

**3. ECT Sensor Output Line Inspection**

Turn the ignition switch OFF. Remove the jumper wire.

Disconnect the ECM 33P connectors. Check the continuity between the ECM connectors and ECT sensor connector of the wire harness side.

**Connection: B13 – Pink/white  
A18 – Green/orange**

**TOOL:**



**Test probe 07ZAJ-RDJA110**

**Are there continuity?**

**YES** – Replace the ECM with new one, and recheck; refer to Key Registration Procedures (page 21-6)

**NO** –

- Open circuit in Pink/white wire
- Open circuit in Green/orange wire



## DTC 8-1 (TP SENSOR LOW VOLTAGE)

- Before starting the inspection, check for loose or poor contact on the TP sensor 3P (Black) connector and ECM 33P connectors, then recheck the DTC.

### 1. TP Sensor System Inspection

Turn the ignition switch ON and engine stop switch "O".

Check the TP sensor with the HDS pocket tester when the throttle fully closed.

**Is about 0 V indicated?**

**YES** – GO TO STEP 3.

**NO** – GO TO STEP 2.

### 2. TP Sensor Inspection

Check the TP sensor voltage is increasing uninterrupted when moving the throttle from fully closed to fully opened using the data list menu of the HDS pocket tester.

**Does the voltage increase continuously?**

**YES** – Intermittent failure

**NO** – Faulty TP sensor

### 3. TP Sensor Input Voltage Inspection

Turn the ignition switch OFF.

Disconnect the TP sensor 3P (Black) connector.

Turn the ignition switch ON and engine stop switch "O".


Measure the voltage at the wire harness side.

**Connection: Yellow/red (+) – Green/orange (-)**

**Is the voltage within 4.75 – 5.25 V?**

**YES** – GO TO STEP 5.

**NO** – GO TO STEP 4.



### 4. TP Sensor Circuit Inspection

Turn the ignition switch OFF.

Disconnect the ECM 33P (Black) connectors.


Check the continuity at the Yellow/red wire between the TP sensor 3P (Black) connector terminal and the ECM 33P (Black) connector.

**Connection: A9 – Yellow/red**

**Is there continuity?**

**YES** – Replace the ECM with a known good one, and recheck; refer to Key Registration Procedures (page 21-6)

**NO** – Open circuit in Yellow/red wire



**5. TP Sensor Output Line Open Circuit Inspection**

Turn the ignition switch OFF.  
Disconnect the ECM 33P (Light gray) connectors.

Check for continuity at the Red/yellow wire between the TP sensor 3P (Black) connector terminal and the ECM 33P (Light gray) connector.

**Connection: B31 – Red/yellow**


**TOOL:**

Test probe 07ZAJ-RDJA110

*Is there continuity?*

**YES** – GO TO STEP 6.

**NO** – Open circuit in Red/yellow wire



**6. TP Sensor Output Line Short Circuit Inspection**

Disconnect the TP sensor 3P (Black) connector.


Check for continuity between the TP sensor 3P connector terminal of the wire harness side and ground.

**Connection: Red/yellow – ground**

*Is there continuity?*

**YES** – Short circuit in Red/yellow wire

**NO** – GO TO STEP 7.



**7. TP Sensor Inspection**

Replace the TP sensor with a known good one.  
Clear the ECM self-diagnosis memory data (page 5-15).

Turn the ignition switch ON and engine stop switch "O".

Check the TP sensor with the HDS pocket tester.

*Is DTC 8-1 indicated?*

**YES** – Replace the ECM with a known good one, and recheck; refer to Key Registration Procedures (page 21-6)

**NO** – Faulty original TP sensor

## DTC 8-2 (TP SENSOR HIGH VOLTAGE)

- Before starting the inspection, check for loose or poor contact on the TP sensor 3P (Black) connector and ECM 33P connectors, then recheck the DTC.

### 1. TP Sensor System Inspection

Turn the ignition switch ON and engine stop switch "○".

Check the TP sensor with the HDS pocket tester.

**Is about 5 V indicated?**

**YES** – GO TO STEP 3.

**NO** – GO TO STEP 2.

### 2. TP Sensor Inspection

Check the TP sensor voltage is increasing uninterrupted when moving the throttle from fully closed to fully opened using the data list menu of the HDS pocket tester.

**Does the voltage increase continuously?**

**YES** – Intermittent failure

**NO** – Faulty TP sensor

### 3. TP Sensor Resistance Inspection

Turn the ignition switch OFF.


Disconnect the TP sensor 3P (Black) connector. Measure the resistance at the TP sensor side.

**Connection: Red/yellow – Green/orange**

**Is the resistance within 0.5 – 1.5 k $\Omega$ ?**

**YES** – GO TO STEP 4.

**NO** – Faulty TP sensor



### 4. TP Sensor Input Voltage Inspection

Turn the ignition switch ON and engine stop switch "○".

Measure the voltage at the wire harness side.


**Connection: Yellow/red (+) – Green/orange (-)**

**Is the voltage within 4.75 – 5.25 V?**

**YES** – Replace the ECM with a known good one, and recheck; refer to Key Registration Procedures (page 21-6)

**NO** –

- Open circuit in Green/orange wire
- Open circuit in Yellow/red wire





**DTC 9-1 (IAT SENSOR LOW VOLTAGE)**

- Before starting the inspection, check for loose or poor contact on the IAT sensor 2P (Gray) connector and ECM 33P connectors, then recheck the DTC.

**1. IAT Sensor System Inspection**

Turn the ignition switch ON and engine stop switch "O".

Check the IAT sensor with the HDS pocket tester.

**Is about 0 V indicated?**

**YES** – GO TO STEP 2.

- NO** –
- Intermittent failure
  - Loose or poor contact on the IAT sensor connector

**2. IAT Sensor Inspection**

Turn the ignition switch OFF.  
Disconnect the IAT sensor 2P (Gray) connector.


Turn the ignition switch ON and engine stop switch "O".

Check the IAT sensor with the HDS pocket tester.

**Is about 0 V indicated?**

**YES** – GO TO STEP 3.

**NO** – Faulty IAT sensor



**3. IAT Sensor Output Line Short Circuit Inspection**


Check for continuity between the IAT sensor 2P (Gray) connector terminal of the wire harness side and ground.

**Connection: Gray/blue – ground**

**Is there continuity?**

**YES** – Short circuit in Gray/blue wire

**NO** – Replace the ECM with a known good one, and recheck; refer to Key Registration Procedures (page 21-6)



**DTC 9-2 (IAT SENSOR HIGH VOLTAGE)**

- Before starting the inspection, check for loose or poor contact on the IAT sensor 2P (Gray) connector and ECM 33P connectors, then recheck the DTC.

**1. IAT Sensor System Inspection**

Turn the ignition switch ON and engine stop switch "O".

Check the IAT sensor with the HDS pocket tester.

**Is about 5 V indicated?**

**YES** – GO TO STEP 2.

**NO** – Intermittent failure

**2. IAT Sensor Inspection**

Turn the ignition switch OFF.

Disconnect the IAT sensor 2P (Gray) connector. Connect the IAT sensor terminals with a jumper wire.

**Connection: Gray/blue – Green/orange**

Turn the ignition switch ON and engine stop switch "O".

Check the IAT sensor with the HDS pocket tester.

**Is about 0 V indicated?**

**YES** – Faulty IAT sensor

**NO** – GO TO STEP 3.

**3. IAT Sensor Output Line Inspection**

Turn the ignition switch OFF.

Disconnect the ECM 33P connectors. Check the continuity at the Gray/blue and Green/orange wire between the IAT sensor 2P (Gray) connector terminals and the ECM 33P (Light gray) connectors.

**CONNECTION: B29 – Gray/blue  
A18 – Green/orange**



**TOOL:**

**Test probe 07ZAJ-RDJA110**

**Is there continuity?**

**YES** – Replace the ECM with a known good one, and recheck; refer to Key Registration Procedures (page 21-6)

**NO** – • Open circuit in Gray/blue wire  
• Open circuit in Green/orange wire



**DTC 11-1 (VS SENSOR)**

- Before starting the inspection, check for loose or poor contact on the VS sensor 3P (Natural) connector and ECM 33P connectors, then recheck the DTC.
- If there is failure in the speed meter indication, check the VS sensor (page 20-17).

**1. VS Sensor System Inspection**

Test-ride the motorcycle and check the VS sensor with the HDS pocket tester.

*Is the vehicle speed indicated normally?*

**YES** – Intermittent failure

**NO** – GO TO STEP 2.

**2. VS Sensor Input Voltage Inspection**

Turn the ignition switch OFF.

Disconnect the VS sensor 3P (Natural) connector.

Turn the ignition switch ON and engine stop switch "O".

Measure the voltage at the VS sensor connector of the wire harness side.

**Connection: White/black (+) – Green/black (-)**

*Is there battery voltage?*

- NO** –
- Open or short circuit in the White/black wire
  - Open circuit in the Green/black wire

**YES** – GO TO STEP 3.

**3. VS Sensor Pulse Line Open Circuit Inspection**

Turn the ignition switch OFF.

Disconnect the ECM 33P (Light gray) connectors.

Check the continuity between the ECM 33P (Light gray) connector terminal and VS sensor 3P connector terminal of the wire harness side.

**Connection: B28 – Pink/blue**

**TOOL:**

Test probe 07ZAJ-RDJA110

*Is there continuity?*

**NO** – Open circuit in Pink/blue wire

**YES** – GO TO STEP 4.

**4. VS Sensor Pulse Line Short Circuit Inspection**




Disconnect the combination meter connector. Check for continuity between the VS sensor 3P (Natural) connector of the wire harness side and body ground.

**Connection: Pink/blue – ground**

*Is there continuity?*

**YES** – Short circuit in Pink/blue wire

**NO** – Faulty VS sensor



## DTC 12-1 (No.1 INJECTOR)

- Before starting the inspection, check for loose or poor contact on the injector 2P (Gray) connectors and ECM 33P connectors, then recheck the DTC.

DTC	INJECTOR	POWER INPUT LINE	SIGNAL LINE	SIGNAL AT ECM
12-1	No.1	Black/White	Pink/yellow	A17
13-1	No.2	Black/White	Pink/blue	A6
14-1	No.3	Black/White	Pink/green	A8
15-1	No.4	Black/White	Pink/black	A7

### 1. Injector System Inspection

Clear the ECM self-diagnosis memory data (page 5-15).

Turn the ignition switch ON and engine stop switch "○", then start the engine and check the injector with the HDS pocket tester.

**Is the DTC 12-1 indicated?**

- NO** – • Intermittent failure  
• Loose or poor contact on the injector 2P (Gray) connector

**YES** – GO TO STEP 2.

### 2. Injector Input Voltage Inspection

Turn the ignition switch ON and engine stop switch "○".


Disconnect the injector 2P (Gray) connectors. Measure the voltage between the injector 2P (Gray) connector of the wire harness side and ground.

**Connection: Black/white (+) – Ground (-)**

**Does the battery voltage exist?**

- NO** – Open or short circuit in Black/white wire

**YES** – GO TO STEP 3.



### 3. Injector Resistance Inspection


Turn the ignition switch OFF.

Measure the resistance of the injector connector terminals.

**Is the resistance within 11.1 – 12.3  $\Omega$  (20°C/68°F)?**

- NO** – Faulty injector

**YES** – GO TO STEP 4.



**4. Injector Signal Line Open Circuit Inspection**

Disconnect the ECM 33P (Black) connector.

Check the continuity between the ECM 33P (Black) connector and injector 2P (Gray) connector of the wire harness side.

**Connection: SIGNAL LINE – SIGNAL LINE**


**TOOL:**

**Test probe** 07ZAJ-RDJA110

*Is there continuity?*

**NO** – Open circuit in SIGNAL line wire

**YES** – GO TO STEP 5.



**5. Injector Signal Line Short Circuit Inspection**


Check for continuity between the injector 2P (Gray) connector and ground.

**Connection: SIGNAL LINE – Ground**

*Is there continuity?*

**YES** – Short circuit in SIGNAL LINE wire

**NO** – Replace the ECM with a known good one, and recheck; refer to Key Registration Procedures (page 21-6)



**DTC 13-1 (No.2 INJECTOR)**

See page 5-30

**DTC 14-1 (No.3 INJECTOR)**

See page 5-30

**DTC 15-1 (No.4 INJECTOR)**

See page 5-30

**DTC 21-1 (O<sub>2</sub> SENSOR)**

- Before starting the inspection, check for loose or poor contact on the O<sub>2</sub> sensor 4P (Black) connector and ECM 33P connectors, then recheck the DTC.

**1. O<sub>2</sub> Sensor System Inspection**

Start the engine and warm up the engine up to coolant temperature is 80 °C (176 °F).

Test-ride the motorcycle and check the O<sub>2</sub> sensor with the HDS pocket tester.

**Is the DTC 21-1 indicated?**

**YES** – GO TO STEP 2.

**NO** – Intermittent failure

**2. O<sub>2</sub> Sensor Open Circuit Inspection**

Turn the ignition switch OFF.

Disconnect the ECM 33P connectors and O<sub>2</sub> sensor 4P (Black) connector.

Check the continuity between the ECM 33P connector of the wire harness side and O<sub>2</sub> sensor 4P (Black) connector of the wire harness side.

**Connection: A18 – Green/orange  
B20 – Orange/white**


**TOOL:**

**Test probe 07ZAJ-RDJA110**

**Are there continuity?**

**YES** – GO TO STEP 3.

- NO** –
- Open circuit in Green/orange wire
  - Open circuit in Orange/white wire



**3. O<sub>2</sub> Sensor Short Circuit Inspection**

Connect the O<sub>2</sub> sensor 4P connector and disconnect the ECM connectors.

Check for continuity between the ECM 33P (Light gray) connector of the wire harness side and ground.

**Connection: B20 – Ground**


**TOOL:**

**Test probe 07ZAJ-RDJA110**

**Is there continuity?**

**YES** – Short circuit in the Orange/white wire

**NO** – GO TO STEP 4.



**4. O<sub>2</sub> Sensor Inspection**

Replace the O<sub>2</sub> sensor with a known good one (page 5-104) and clear the DTC.

Start the engine and warm the engine up to coolant temperature is 80 °C (176 °C).

Test-ride the motorcycle and check the O<sub>2</sub> sensor with the HDS pocket tester.

**Is the DTC 21-1 indicated?**

**YES** – Faulty ECM. Replace it with new one and recheck

**NO** – Faulty original O<sub>2</sub> sensor

**DTC 23-1 (O<sub>2</sub> SENSOR HEATER)**

- Before starting the inspection, check for loose or poor contact on the O<sub>2</sub> sensor 4P (Black) connector and ECM 33P connectors, then recheck the DTC.

**1. O<sub>2</sub> Sensor Heater System Inspection**

Clear the ECM self-diagnosis memory data (page 5-15).

Start the engine and check the O<sub>2</sub> sensor heater with the HDS pocket tester.

**Is the DTC 23-1 indicated?**

**YES** – GO TO STEP 2.

**NO** – Intermittent failure

**2. O<sub>2</sub> Sensor Heater Resistance Inspection**

Turn the ignition switch OFF.


Disconnect the O<sub>2</sub> sensor 4P (Black) connector and measure the resistance at the O<sub>2</sub> sensor 4P (Black) connector terminals of the sensor side.

**Connection: White – White**

**Is the resistance within 10 – 40 Ω (20°C/68°F)?**

**YES** – GO TO STEP 3.

**NO** – Faulty O<sub>2</sub> sensor



**3. O<sub>2</sub> Sensor Heater Power Input Line Inspection**


Turn the ignition switch ON, then measure the voltage between O<sub>2</sub> sensor 4P (Black) connector of the wire harness side and ground.

**Connection: Black/white (+) – Ground (-)**

**Does the battery voltage exist?**

**YES** – GO TO STEP 4.

**NO** – Open circuit in the Black/white wire



## 4. O<sub>2</sub> Sensor Heater Open Circuit Inspection

Turn the ignition switch OFF.

Disconnect the ECM 33P (Light gray) connector. Check the continuity between the ECM 33P (Gray) connector and O<sub>2</sub> sensor 4P (Black) connector of the wire harness side.

**Connection: B2 – Black/green**


**TOOL:**

**Test probe 07ZAJ-RDJA110**

*Is there continuity?*

**YES** – GO TO STEP 5.

**NO** – Open circuit in Black/green wire



## 5. O<sub>2</sub> Sensor Heater Short Circuit Inspection 2

Connect the ECM 33P (Light gray) connector.


Check for continuity between the O<sub>2</sub> sensor 4P (Black) connector of the wire harness side and ground.

**Connection: Black/green – Ground**

*Is there continuity?*

**YES** – Short circuit in Black/green wire

**NO** – Replace the ECM with a known good one, and recheck; refer to Key Registration Procedures (page 21-6)



## DTC 29-1 (IACV)

- Before starting the inspection, check for loose or poor contact on the IACV 4P (Black) connector and ECM 33P connectors, then recheck the DTC.

### 1. Recheck DTC


Clear the ECM self-diagnosis memory data (page 5-15).

Start the engine and recheck the DTC.

*Is the DTC 29-1 indicated?*

**NO** – Intermittent failure

**YES** – GO TO STEP 2.





**2. IACV Short Circuit Inspection**

Turn the ignition switch OFF.  
Disconnect the IACV 4P (Black) connector.


Check for continuities between the IACV 4P connector and ground.

- Connection:** **Black/yellow – Ground**  
**Black/red – Ground**  
**Black/blue – Ground**  
**Black/orange – Ground**

**Are there continuities?**

- YES** – • Short circuit in Black/yellow or Black/orange wire  
 • Short circuit in Black/red or Black/blue wire

**NO** – GO TO STEP 3.



**3. IACV Circuit Continuity Inspection**


Disconnect the ECM 33P (Black) connector.  
Check the continuities between the ECM 33P (Black) connector terminals and the IACV 4P connector terminals.

- Connection:** **A19 – Black/yellow**  
**A27 – Black/red**  
**A16 – Black/blue**  
**A29 – Black/orange**

**TOOL:**  
**Test probe 07ZAJ-RDJA110**

**Are there continuities?**

- YES** – GO TO STEP 4.  
**NO** – • Open or loose contact in Black/yellow or Black/orange wire  
 • Open or loose contact in Black/red or Black/blue wire



4. IACV Resistance Inspection

Measure the resistance at the IACV 4P (Black) connector terminals.


**Connection:** Black/yellow – Black/orange  
Black/red – Black/blue

**STANDARD:** 120 – 140 Ω (20 °C/68 °F)

*Is the resistance within 120 – 140 Ω (20°C/68°F)?*

**YES** – Replace the ECM with new one, and recheck; refer to Key Registration Procedures (page 21-6)

**NO** – Faulty IACV



MIL TROUBLESHOOTING

MIL 1 BLINK (MAP SENSOR)

- Before starting the inspection, check for loose or poor contact on the MAP sensor 3P (Black) connector and ECM 33P connectors, then recheck the MIL blinking.

1. MAP Sensor Output Voltage Inspection

Turn the ignition switch OFF.  
Connect the ECM test harness to ECM connectors (page 5-15).

Turn the ignition switch ON and engine stop switch "O".

Measure the voltage at the test harness terminals.

**Connection:** B9 (+) – A18 (-)


*Is the voltage within 1.7 – 2.4 V?*

**YES** –

- Intermittent failure
- Loose or poor contact on the ECM connectors

**NO** –

- About 5 V  
GO TO STEP 2.
- About 0 V  
GO TO STEP 3.



2. MAP Sensor Output Line Inspection

Turn the ignition switch OFF.  
Disconnect the MAP sensor 3P (Black) connector.

Turn the ignition switch ON and engine stop switch "O".

Measure the voltage at the wire harness side.


**Connection:** Light green/yellow (+) – Green/orange (-)

*Is the voltage within 4.75 – 5.25 V?*

**YES** – Faulty MAP sensor

**NO** –

- Open circuit in Light green/yellow wire
- Open circuit in Green/orange wire



**3. MAP Sensor Input Voltage Inspection**


Measure the voltage at the wire harness side.

**Connection: Yellow/red (+) – Ground (-)**

*Is the voltage within 4.75 – 5.25 V?*

**YES** – GO TO STEP 4.

**NO** – GO TO STEP 5.



**4. MAP Sensor Output Line Short Circuit Inspection**

Turn the ignition switch OFF.


Check for continuity between the MAP sensor 3P (Black) connector terminal of the wire harness side and ground.

**Connection: Light green/yellow – Ground**

*Is there continuity?*

**YES** – Short circuit in Light green/yellow wire

**NO** – Faulty MAP sensor



**5. MAP Sensor Input Line Inspection**

Turn the ignition switch OFF.

Disconnect the ECM 33P connectors.


Check the continuity at the Yellow/red wire between the MAP sensor 3P (Black) connector terminal and test harness terminal.

**Connection: A9 – Yellow/red**

*Is there continuity?*

**YES** – Replace the ECM with a known good one, and recheck; refer to Key Registration Procedures (page 21-6)

**NO** – Open circuit in Yellow/red wire



**MIL 2 BLINKS (MAP SENSOR HOSE CONNECTION)**

- Before starting the inspection, check for loose or poor contact on the MAP sensor 3P (Black) connector and ECM 33P connectors, then recheck the MIL blinking.

**1. MAP Sensor Hose Inspection**


Turn the ignition switch OFF.

Check the connection and installation of the MAP sensor vacuum hoses.

*Is the MAP sensor hose connection correct?*

**YES** – GO TO STEP 2.

**NO** – Correct the hose connection or installation



**2. MAP Sensor Output Voltage Inspection**

Connect the ECM test harness to ECM connectors (page 5-15).

Turn the ignition switch ON and engine stop switch "O".

Measure the voltage at the test harness terminals.


The MAP sensor voltage should be changed after engine started.

**Connection: B9 (+) – A18 (-)**

*Is the MAP sensor voltage indicated normally?*

**YES** – GO TO STEP 3.

**NO** – Faulty MAP sensor



**3. MAP Sensor Inspection**

Replace the MAP sensor with a known good one (page 5-96).

Measure the voltage at the test harness terminals.


The MAP sensor voltage should be changed after engine started.

**Connection: B9 (+) – A18 (-)**

*Is the MAP sensor voltage indicated normally?*

**YES** – Replace the ECM with a known good one, and recheck; refer to Key Registration Procedures (page 21-6)

**NO** – Faulty MAP sensor



**MIL 7 BLINKS (ECT SENSOR)**

- Before starting the inspection, check for loose or poor contact on the ECT sensor 3P (Gray) connector and ECM 33P connectors, then recheck the MIL blinking.

**1. ECT Sensor Output Voltage Inspection**

Turn the ignition switch OFF.  
Connect the test harness to ECM 33P connectors (page 5-15).

Turn the ignition switch ON and engine stop switch "O":  
Measure the voltage at the test harness terminals.

**Connection:** B13 (+) – A18 (-)  
**Standard:** 2.7 – 3.1 V (20°C/68°F)

*Is the voltage within 2.7 – 3.1 V?*

**YES** – • Loose or poor contact on the ECM connectors  
• Intermittent failure

**NO** – GO TO STEP 2.

**2. ECT Sensor Input Voltage Inspection**

Turn the ignition switch OFF.  
Disconnect the ECT sensor 3P (Gray) connector.

Turn the ignition switch ON and engine stop switch "O":  
Measure the voltage at the ECT sensor 3P (Gray) connector of wire harness side and ground.

**Connection:** Pink/white – Ground (-)

*Is the voltage within 4.75 – 5.25 V?*

**NO** – GO TO STEP 4.

**YES** – GO TO STEP 3.

**3. ECT Sensor Resistance Inspection**

Turn the ignition switch OFF.  
Measure the resistance at the ECT sensor terminals.




**Connection:** Pink/white – Green/orange  
(Sensor side terminals)

**Standard:** 2.3 – 2.6 kΩ (20°C/68°F)

*Is the resistance within 2.3 – 2.6 kΩ (20°C/68°F)?*

**NO** – Faulty ECT sensor.

**YES** – GO TO STEP 4.



## 4. ECT Sensor Open Circuit Inspection


Turn the ignition switch OFF.  
Check the continuity between the test harness terminals and ECT sensor 3P (Gray) connector of the wire harness side.

**Connection:** B13 – Pink/white  
A18 – Green/orange

*Is there continuity?*

**NO** – • Open circuit in Pink/white wire  
• Open circuit in Green/orange wire

**YES** – GO TO STEP 5.



## 5. ECT Sensor Short Circuit Inspection


Disconnect the ECM 33P connectors disconnected.  
Check for continuity between the ECT sensor 3P (Gray) connector of the wire harness side and ground.

**Connection:** Pink/white – Ground

*Is there continuity?*

**YES** – Short circuit in Pink/white wire

**NO** – Replace the ECM with a known good one, and recheck; refer to Key Registration Procedures (page 21-6)



**MIL 8 BLINKS (TP SENSOR)**

- Before starting the inspection, check for loose or poor contact on the TP sensor 3P (Black) connector and ECM 33P connectors, then recheck the MIL blinking.

**1. TP Sensor Output Voltage**

Turn the ignition switch OFF.  
Connect the ECM test harness to ECM connectors (page 5-15).

Turn the ignition switch ON and engine stop switch "O".  
Measure the TP sensor output voltage at the test harness terminals.

**Connection:** B31 (+) – A18 (-)

**Standard:** \*0.4 – 0.6 V (throttle fully closed)  
\*4.2 – 4.8 V (throttle fully opened)

**NOTE:**

- A voltage marked \* refers to the value of the ECM output voltage (STEP 3) when the voltage reading shows 5 V. When the ECM output voltage reading shows other than 5 V, derive the TP sensor output voltage at the test harness as follows:  
In the case of the ECM output voltage is 4.75 V:  
 $0.4 \times 4.75/5.0 = 0.38 \text{ V}$   
 $0.6 \times 4.75/5.0 = 0.57 \text{ V}$   
Thus, the solution is "0.38 – 0.57 V" with the throttle fully closed.  
Replace 0.4 and 0.6 with 4.2 and 4.8 respectively, in the above equations to determine the throttle fully opened range.

**Is there standard voltage?**

**YES** – Intermittent failure

**NO** – GO TO STEP 2.

**2. TP Sensor Input Voltage Inspection**

Turn the ignition switch OFF.  
Disconnect the TP sensor 3P (Black) connector.



Turn the ignition switch ON and engine stop switch "O".  
Measure the voltage at the wire harness side.

**Connection:** Yellow/red (+) – Green/orange (-)

**Is the voltage within 4.75 – 5.25 V?**

**YES** – GO TO STEP 4.

**NO** – GO TO STEP 3.




## 3. ECM Output Voltage Inspection

Turn the ignition switch ON and engine stop switch "O".  
Measure the voltage at the test harness terminals.

**Connection:** A9 (+) – A18 (-)

**Is the voltage within 4.75 – 5.25 V?**

- YES** – • Open circuit in Yellow/red wire  
• Open circuit in Green/orange wire
- NO** – Replace the ECM with a known good one, and recheck; refer to Key Registration Procedures (page 21-6)



## 4. TP Sensor Output Line Inspection


Turn the ignition switch OFF.

Check the continuity between the TP sensor 3P (Black) connector terminal of the wire harness side and the test harness terminal.

**Connection:** Red/yellow – B31

**Is there continuity?**

- YES** – GO TO STEP 5.
- NO** – Open circuit in Red/yellow wire




## 5. TP Sensor Output Line Short Circuit Inspection

Check for continuity between the TP sensor 3P (Black) connector terminal of the wire harness side and ground.

**Connection:** Red/yellow (+) – Ground (-)

**Is there continuity?**

- YES** – Short circuit in Red/yellow wire
- NO** – Faulty TP sensor





**MIL 9 BLINKS (IAT SENSOR)**

- Before starting the inspection, check for loose or poor contact on the IAT sensor 2P (Gray) connector and ECM 33P connectors, then recheck the MIL blinking.

**1. IAT Sensor Output Voltage Inspection**


Turn the ignition switch OFF.  
Connect the ECM test harness to ECM connectors (page 5-15).

Turn the ignition switch ON and engine stop switch "O".  
Measure the voltage at the test harness terminals.

**Connection:** B29 (+) – A18 (-)  
**Standard:** 2.7 – 3.1 V (20°C/68°F)

*Is the voltage within 2.7 – 3.1 V?*

- YES** – Intermittent failure  
**NO** – GO TO STEP 2.




**2. IAT Sensor Input Voltage Inspection**

Turn the ignition switch OFF.  
Disconnect the IAT sensor 2P (Gray) connector.  
Turn the ignition switch ON and engine stop switch "O".  
Measure the voltage at the wire harness side of IAT sensor connector.

**Connection:** Gray/blue – Green/orange

*Is the voltage within 4.75 – 5.25 V?*

- YES** – GO TO STEP 3.  
**NO** – GO TO STEP 4.




**3. IAT Sensor Resistance Inspection**

Turn the ignition switch OFF.  
Disconnect the IAT sensor 2P (Gray) connector.  
Measure the resistance at the IAT sensor terminals (at 20 – 30°C/68 – 86°F).

**Standard:** 1 – 4 kΩ (20 °C/68°F)

*Is the resistance within 1 – 4 kΩ?*

- NO** – Faulty IAT sensor.  
**YES** – GO TO STEP 4.



## 4. IAT Sensor Open Circuit Inspection


Check for continuity at the Gray/blue and Green/orange wires between the IAT sensor 2P (Gray) connector terminal and the test harness terminals.

**Are there continuity?**

**YES** – GO TO STEP 5.

**NO** –

- Open circuit in Gray/blue wire
- Open circuit in Green/orange wire



## 5. IAT Sensor Output Line Short Circuit Inspection


Check for continuity between the IAT sensor 2P (Gray) connector terminal of the wire harness side and ground.

**Connection: Gray/blue – Ground**

**Is there continuity?**

**YES** – Short circuit in Gray/blue wire

**NO** – Replace the ECM with a known good one, and recheck; refer to Key Registration Procedures (page 21-6)



## MIL 11 BLINKS (VS SENSOR)

- Before starting the inspection, check for loose or poor contact on the VS sensor 3P (Natural) connector and ECM 33P connectors, then recheck the MIL blinking.
- If there is failure in the speed meter indication, check the VS sensor (page 20-17).

### 1. VS Sensor Pulse Inspection At ECM

Turn the ignition switch OFF.  
Connect the ECM test harness to the ECM connectors (page 5-15).

Support the motorcycle securely, raise the rear wheel off the ground.

Shift the transmission into gear.

Measure the voltage between the test harness terminal and ground with the ignition switch "ON" and engine stop switch "⊙" while slowly turning the rear wheel by hand.


**Connection: B28 (+) – Ground (-)**

**Standard: Repeat 0 to 5 V**

**Is the voltage at the standard value?**

**YES** – Intermittent failure

**NO** – GO TO STEP 2.



**2. VS Sensor Input Voltage Inspection**

Turn the ignition switch OFF.  
Disconnect the VS sensor 3P (Natural) connector.

Turn the ignition switch ON and engine stop switch "O".


Measure the voltage at the VS sensor connector of the wire harness side.

**Connection: White/black (+) – Green/black (-)**

*Is there battery voltage?*

- NO** – • Open or short circuit in White/black wire  
• Open circuit in Green/black wire

**YES** – GO TO STEP 3.



**3. VS Sensor Pulse Line Open Circuit Inspection**

Turn the ignition switch OFF.


Check the continuity between the test harness terminal and VS sensor connector of the wire harness side.

**Connection: B28 – Pink/blue**

*Is there continuity?*

- NO** – Open circuit in Pink/blue wire

**YES** – GO TO STEP 4.



**4. VS Sensor Pulse Line Short Circuit Inspection**


Check for continuity between the VS sensor connector and the ground.

**Connection: Pink/blue – Ground**

*Is there continuity?*

- YES** – Short circuit in the Pink/green wire

- NO** – Inspect the VS sensor (page 20-17)



**MIL 12 BLINKS (No.1 INJECTOR)**

- Before starting the inspection, check for loose or poor contact on the injector 2P (Gray) connectors and ECM 33P connectors, then recheck the MIL blinking.

MIL	INJECTOR	POWER INPUT LINE	SIGNAL LINE	SIGNAL AT ECM
12	No.1	Black/white	Pink/yellow	A17
13	No.2	Black/white	Pink/blue	A6
14	No.3	Black/white	Pink/green	A8
15	No.4	Black/white	Pink/black	A7

**1. Injector Input Voltage Inspection**

Disconnect the injector 2P (Gray) connector.

Turn the ignition switch ON and engine stop switch to "O".


Measure the voltage between the injector 2P (Gray) connector of the wire harness side and ground.

**Connection: Black/white (+) – Ground (-)**

*Does the battery voltage exist?*

**NO** – Open or short circuit in Black/white wire

**YES** – GO TO STEP 2.



**2. Injector Resistance Inspection**

Turn the ignition switch OFF.


Measure the resistance of the injector connector terminals.

**STANDARD: 11.1 – 12.3 Ω (20 °C/68 °F)**

*Is the resistance within 11.1 – 12.3 Ω (20°C/68°F)?*

**NO** – Faulty injector

**YES** – GO TO STEP 3.



**3. Injector Circuit Resistance Inspection**


Connect the test harness to the ECM 33P connectors.

Connect the continuity between the test harness terminal and injector 2P (Gray) connector of the wire harness side.

**Connection: SIGNAL LINE – SIGNAL LINE**

*Is there continuity?*

- NO** – Open circuit in SIGNAL line wire
- YES** – GO TO STEP 4.




**4. Injector Signal Line Short Circuit Inspection**

Check for continuity between the injector 2P (Gray) connector of the wire harness side and ground.

**Connection: SIGNAL LINE – Ground**

*Is there continuity?*

- YES** – Short circuit in SIGNAL line wire
- NO** – Replace the ECM with a known good one, and recheck; refer to Key Registration Procedures (page 21-6)



**MIL 13 BLINKS  
(No.2 INJECTOR)**

See page 5-46

**MIL 14 BLINKS  
(No.3 INJECTOR)**

See page 5-46

**MIL 15 BLINKS  
(No.4 INJECTOR)**

See page 5-46

**MIL 21 BLINKS (O<sub>2</sub> SENSOR)**

- Before starting the inspection, check for loose or poor contact on the O<sub>2</sub> sensor 4P (Black) connector and ECM 33P connectors, then recheck the MIL blinking.

**1. O<sub>2</sub> Sensor System Inspection**

Start the engine and warm it up to coolant temperature is 80 °C (176 °F).

Test-ride the motorcycle and recheck the MIL blinking.

*Is the MIL 21 blinks?*

**YES** – GO TO STEP 2.

**NO** – Intermittent failure

**2. O<sub>2</sub> Sensor Open Circuit Inspection**

Turn the ignition switch OFF.

Disconnect the O<sub>2</sub> sensor 4P (Black) connector.


Check the continuity between the test harness terminals and the O<sub>2</sub> sensor connector terminals of the wire harness side.

**Connection: B20 – Orange/white**  
**A18 – Green/orange**

*Is there continuity?*

- NO** – • Open circuit in Orange/white wire
- Open circuit in Green/orange wire

**YES** – GO TO STEP 3.



**3. O<sub>2</sub> Sensor Short Circuit Inspection**

Connect the O<sub>2</sub> Sensor 4P (Black) connector.


Check for continuity between the ECM connector terminal and ground.

**Connection: B20 – Ground**

*Is there continuity?*

**YES** – Short circuit in the Orange/white wire

**NO** – GO TO STEP 4.



**4. O<sub>2</sub> Sensor Inspection**

Replace the O<sub>2</sub> sensor with a known good one (page 5-104).

Start the engine and warm it up until the coolant temperature is 80 °C (176 °F).

Test-ride the motorcycle and recheck the MIL blinking.

*Is the MIL 21 blinks?*

**YES** – Faulty ECM. Replace it with new one and recheck

**NO** – Faulty original O<sub>2</sub> sensor

**MIL 23 BLINKS (O<sub>2</sub> SENSOR HEATER)**

- Before starting the inspection, check for loose or poor contact on the O<sub>2</sub> sensor 4P (Black) connector and ECM 33P connectors, then recheck the MIL blinking.

**1. O<sub>2</sub> Sensor Heater Resistance Inspection**


Turn the ignition switch OFF.

Disconnect the O<sub>2</sub> sensor 4P (Black) connector. Measure the resistance at the sensor side connector white wire terminals.

**Connection: White – White**

*Is the resistance within 10 – 40 Ω (20°C/68°F)?*

- NO** – Faulty O<sub>2</sub> sensor
- YES** – GO TO STEP 2.



**2. O<sub>2</sub> Sensor Heater Open Circuit Inspection 1**


Turn the ignition switch ON.

Measure the voltage at the O<sub>2</sub> sensor 4P (Black) connector of the wire harness side.

**Connection: Black/white (+) – Ground (-)**

*Does the battery voltage exist?*

- NO** – Open or short circuit in Black/white wire
- YES** – GO TO STEP 3.



**3. O<sub>2</sub> Sensor Heater Open Circuit Inspection 2**

Turn the ignition switch OFF.


Connect the ECM test harness to the ECM connectors.

Check the continuity between the test harness terminal and O<sub>2</sub> sensor 4P (Black) connector of the wire harness side.

**Connection: B2 – Black/green**

*Is there continuity?*

- NO** – Open circuit in Black/green wire
- YES** – GO TO STEP 4.



## 4. O<sub>2</sub> Sensor Heater Short Circuit Inspection


Check for continuity between the test harness terminals and ground.

**Connection: B2 – Ground**

*Is there continuity?*

**YES** – Short circuit in the Black/green wire

**NO** – Replace the ECM with a known good one, and recheck; refer to Key Registration Procedures (page 21-6)



## MIL 29 BLINKS (IACV)

- Before starting the inspection, check for loose or poor contact on the IACV 4P (Black) connector and ECM 33P connectors, then recheck the MIL blinking.

### 1. IACV Short Circuit Inspection

Turn the ignition switch OFF.

Disconnect the IACV 4P (Black) connector. Check the connector for loose contacts or corroded terminals.


Check for continuities between the IACV 4P (Black) connectors and ground.

**Connection: Black/yellow – Ground**  
**Black/red – Ground**  
**Black/blue – Ground**  
**Black/orange – Ground**

*Are there continuities?*

**YES** – • Short circuit in Black/yellow or Black/orange wire  
 • Short circuit in Black/red or Black/blue wire

**NO** – GO TO STEP 2.





**2. IACV Circuit Continuity Inspection**


Connect the ECM test harness to ECM connectors.  
Check the continuities between the test harness and the IACV 4P connector.

- Connection:** A19 – Black/yellow  
A27 – Black/red  
A16 – Black/blue  
A29 – Black/orange

**Are there continuities?**

**YES** – GO TO STEP 3.

- NO** –
- Open or loose contact in Black/yellow or Black/orange wire
  - Open or loose contact in Black/red or Black/blue wire



**3. IACV Resistance Inspection**


Connect the IACV 4P (Black) connector.  
Measure the resistance at the test harness terminals.

- Connection:** A19 – A29  
A16 – A27

**STANDARD:** 120 – 140 Ω (20 °C/68 °F)

**Is the resistance within 120 – 140 Ω (20 °C/68 °F)?**

- YES** – Replace the ECM with a new one, and recheck; refer to Key Registration Procedures (page 21-6)
- NO** – Faulty IACV



### MIL CIRCUIT TROUBLESHOOTING


If the engine can be started but the MIL does not come on when the ignition switch is turned "ON" and the engine stop switch is in "O", check as follows:

Check other indicators function properly.

- If they do not function, check the combination meter power input line (page 20-15).
- If they function properly, check as follows:


Remove the right side cover (page 2-5).

Turn the ignition switch to "OFF", disconnect the ECM 33P (Black) connector.



Ground the White/blue wire terminal of the wire harness side connector with a jumper wire. Turn the ignition switch to "ON", the MIL should come on.


- If the MIL comes on, replace the ECM with a new one and recheck the MIL indication. Refer to Key Registration Procedures (page 21-6)
- If the MIL does not come on, check for open circuit in the White/blue wire between the combination meter and ECM. If the wire is OK, replace the combination meter.



### FUEL LINE INSPECTION


#### FUEL PRESSURE RELIEVING/QUICK CONNECT FITTING REMOVAL

- Before disconnecting fuel feed hose, relieve pressure from the system as following procedures.
1. Turn the ignition switch OFF.  
Lift and support the fuel tank (page 3-5).
  2. Disconnect the fuel pump 2P (Black) connector.
  3. Start the engine, and let it idle until the engine stalls.
  4. Turn the ignition switch OFF.
  5. Disconnect the battery negative (-) cable (page 17-6).




6. Check the fuel quick connect fitting for dirt, and clean if necessary.

Place a shop towel over the quick connect fitting.




7. Pull and release the rubber cap from the retainer.
8. Hold the connector with one hand and squeeze the retainer tabs with the other hand to release them from the locking pawls. Pull the connector off and remove the rubber cap from the fuel pipe.

- Prevent the remaining fuel in the fuel feed hose from following out with a shop towel.
- Be careful not to damage the hose or other parts.
- Do not use tools.
- If the connector does not move, keep the retainer tabs pressed down, and alternately pull and push the connector until it comes off easily.




9. To prevent damage and keep foreign matter out, cover the disconnected connector and pipe end with the plastic bags.



## QUICK CONNECT FITTING INSTALLATION


- Always replace the retainer of the quick connect fitting when the fuel feed hose is disconnected.
- If any damage or cut-out on the rubber cap, replace it with a new one.
- Do not bent or twist fuel feed hose.

1. Insert a new retainer into the connector.




2. Install the rubber cap and seat it onto the fuel pipe flange as shown. Align the quick connect fitting with the pipe and align the new retainer locking pawls with the connector grooves. Then press the quick connect fitting onto the pipe until both retainer pawls lock with a "CLICK".


If it is hard to connect, put a small amount of engine oil on the pipe end.



3. Make sure the connection is secure and that the pawls are firmly locked into place; check visually and by pulling the connector.
4. Make sure the rubber cap is in place (between the flange and retainer tab).




5. Connect the fuel pump 2P (Black) connector.



2P (Black) CONNECTOR

6. Connect the battery negative (-) cable (page 17-6).



QUICK CONNECT FITTING

*Do not start the engine.*

7. Turn the ignition switch ON and engine stop switch "O".

The fuel pump will run for about 2 seconds, and fuel pressure will rise.

Repeat 2 or 3 times, and check that there is no leakage in the fuel supply system.

Installation is in the reverse order of removal.


### FUEL PRESSURE TEST

Relieve the fuel pressure and disconnect the quick connect fitting (page 5-52).

Attach the fuel pressure gauge, attachments and manifold.

#### TOOLS:

- |                                       |               |
|---------------------------------------|---------------|
| (1): Fuel pressure gauge              | 07406-0040004 |
| (2): Pressure gauge manifold          | 07ZAJ-S5A0111 |
| (3): Pressure gauge hose attachment C | 07ZAJ-S7C0100 |
| (4): Pressure gauge hose attachment A | 07ZAJ-S5A0120 |
| (5): Fuel attachment joint C          | 07ZAJ-S7C0200 |



Temporarily connect the positive cable and negative cable to the battery.

Start the engine and let it idle.

Read the fuel pressure.

#### STANDARD: 343 kPa (3.5 kgf/cm<sup>2</sup>, 50 psi)

If the fuel pressure is higher than specified, replace the fuel pump assembly (faulty fuel pump or fuel pressure regulator).

If the fuel pressure is lower than specified, inspect the following:

- Fuel line leaking
- Pinched or clogged fuel feed hose or fuel tank breather hose
- Fuel pump (page 5-57)
- Clogged fuel filter (Assembly of the fuel pump: page 5-58)


## FUEL SYSTEM (PGM-FI)

Wrap a shop towel around the attachment to soak up any spilled fuel.

After inspection, relieve the fuel pressure by disconnecting the quick connect fitting (page 5-52).

Remove the fuel pressure gauge, attachments and manifold from the fuel pump.


Connect the quick connect fitting (page 5-54).




## FUEL FLOW INSPECTION

Remove the seat (page 2-4).

Remove the fuse/relay box cover.




Disconnect the fuel cut-off relay.



Jump the Brown and Black/white wire terminals of the wire harness side using a jumper wire.

- Place an approved gasoline container and drain the gasoline.
- Wipe off spilled out gasoline.



Disconnect the quick connect fitting from the fuel joint (page 5-52).  
 Attach the hose attachment to the fuel joint.

**TOOL:**  
**Pressure gauge hose attachment C**      **07ZAJ-S7C0100**


Turn the ignition switch ON and engine stop switch "O" for 10 seconds.

Measure the amount of fuel flow.

**Amount of fuel flow:**  
**189 cm<sup>3</sup> (6.4 US oz, 6.7 Imp oz) minimum**  
**/10 seconds at 12 V**

If the fuel flow is less than specified, inspect the following:

- Pinched or clogged fuel hose
- Fuel pump unit (page 5-57)



## FUEL PUMP


### INSPECTION

Turn the ignition switch ON and engine stop switch "O" and confirm that the fuel pump operates for a few seconds.

If the fuel pump does not operate, inspect as follow:

Open and support the fuel tank (page 3-5).

Disconnect the fuel pump unit 2P (Black) connector.



Turn the ignition switch ON and measure the voltage between the terminals.


**Connection: Brown (+) – Green (-)**

There should be battery voltage for a few seconds.

If there is battery voltage a few seconds, replace the fuel pump unit.

If there is no battery voltage, inspect the following:


- Main fuse 30A
- Sub fuse 10A
- Engine stop switch (page 20-26)
- Fuel cut-off relay (page 5-59)
- Engine stop relay (page 5-99)
- Bank angle sensor (page 5-97)
- ECM (page 5-100)




## REMOVAL

Remove the fuel tank (page 5-60).


Remove the fuel pump unit mounting nuts.



Remove the fuel pump unit and packing.  
*Be careful not to damage the pump wire.*




Remove the fuel pump chamber from fuel pump unit.



## INSPECTION

Check the fuel pump unit for wear or damage, replace it if necessary.


Clean the fuel strainer screen with non-flammable or high flash point solvent.





## INSTALLATION


Install the fuel pump chamber, hooking its tab to the hole of fuel pump unit.



*Always replace the packing with a new one.  
Be careful not to damage the pump wire.*

Place a new packing onto the fuel pump unit.


Install the fuel pump unit into the fuel tank.



Install the fuel pump mounting nuts. Tighten the nuts in the specified sequence as shown.

**TORQUE: 12 N·m (1.2 kgf·m, 9 lbf·ft)**

Install the fuel tank (page 5-61).



## FUEL CUT-OFF RELAY

### INSPECTION

Remove the fuel cut-off relay from the relay box (page 5-56).


Connect the ohmmeter to the fuel cut-off relay connector terminals.

**Connection: A – B**

Connect the 12 V battery to the following fuel cut-off relay connector terminals.

**Connection: C – D**

There should be continuity only when the 12 V battery is connected. If there is no continuity when the 12 V battery is connected, replace the fuel cut-off relay.




# FUEL TANK

## REMOVAL


- Failure to release the fuel pressure could result in fuel spilling onto painted or plastic parts, which will be damaged.

Relieve the fuel pressure and disconnect the quick connect fitting from the fuel tank (page 5-52).


Disconnect the fuel reserve sensor 2P (Natural) connector.




Disconnect the fuel tank drain hose and breather hose from the hose joint.



Remove the fuel tank rear mounting nut and pivot bolt, then remove the fuel tank.



INSTALLATION




Install the fuel tank onto the frame, then install the pivot bolt and fuel tank rear mounting nut.

Hold the pivot bolt and tighten the fuel tank rear mounting nut to the specified torque.

**TORQUE: 12 N·m (1.2 kgf·m, 9 lbf·ft)**


Lift and support the fuel tank (page 3-5).



Connect the fuel tank drain hose and breather hose to the hose joint.

**NOTICE**

- Route the hoses, wires and harness properly (page 1-22).
- Be careful not to damage the harness and hoses.
- After installing the fuel tank, make sure the drain, breather and fuel hoses are not kinked or bound.




## FUEL SYSTEM (PGM-FI)

Connect the fuel reserve sensor 2P (Natural) connector.

Connect the quick connect fitting (page 5-54).

Remove the support tool, then install and tighten the fuel tank front mounting bolts (page 3-6).




## AIR CLEANER HOUSING

### REMOVAL


Make the throttle cable freeplay at the handlebar side (page 3-6).

Loosen the throttle cable nuts fully.  
Disconnect the throttle cables from the throttle pipe (page 13-8).




Remove the air cleaner element (page 3-7).

Disconnect the vacuum hose from the intake air duct diaphragm.




Relieve the fuel pressure and disconnect the quick connect fitting from the fuel tank (page 5-52)


Remove the screw and right front resonator.




Disconnect the PAIR control solenoid valve 2P (Black) connector.




Disconnect the #1/#4 ignition coil connectors.



Disconnect the crankcase breather hose from the air cleaner housing.




Disconnect the ECT sensor 3P (Black) connector.




## FUEL SYSTEM (PGM-FI)

Disconnect the IDC hose from throttle body.




Disconnect the sidestand switch 2P (Black) connector.




Disconnect the PAIR air suction hose from the air cleaner housing.




Disconnect the #2/#3 ignition coil connectors.




Remove the mounting bolt and washer.




Release the fuel tank drain hose, radiator reserve tank overflow hose, alternator wire from the air cleaner housing guide.



Disconnect IDC hose from IDC solenoid valve.




Remove the muffler (page 2-26).  
Remove the bolts and right footpeg holder.




## FUEL SYSTEM (PGM-FI)


Disconnect the O<sub>2</sub> sensor 4P (Black) connector.




Remove the pivot bracket nuts and washers.  
Remove the swingarm pivot nut and washer.



Release the O<sub>2</sub> sensor wire and IDC hoses from the guides on the right pivot bracket.




Release the sub-harness wire from guide.







Remove the screws and right air cleaner duct.




Disconnect the injector sub-harness 10P (Black) and 10P (White) connectors, and CKP sensor 2P (Red) connector.



Remove the screws and ECM stay.  
Pull out the ECM from the air cleaner housing.




Disconnect the ECM 33P (Black and Light gray) connectors from the ECM.




## FUEL SYSTEM (PGM-FI)

Loosen the throttle body insulator band screws (cylinder head side).



Disconnect fuel tank drain hose and breather hose from the fuel tank.



Release the throttle cables from the frame, then pull out the air cleaner housing with the throttle body to the left side.


### NOTICE

*Be careful not to damage the harness and hoses.*


### DISASSEMBLY




Disconnect the IAT sensor 2P (Gray) connector. Remove the screws, IAT sensor and O-ring.




Disconnect the IDC solenoid valve 2P (Gray) connector.



Disconnect the TP sensor 3P (Black) connector.




Disconnect the MAP sensor 3P (Black) connector.  
Disconnect the vacuum hose from the MAP sensor.  
Remove the screw and MAP sensor from the air cleaner housing.




Disconnect the quick connect fitting from the fuel rail (page 5-52).

Remove the fuel feed hose.




## FUEL SYSTEM (PGM-FI)


Disconnect the injector 2P (Gray) connectors.




Disconnect the IACV 4P (Black) connector.




Release the sidestand switch 2P (Black) connector from stay.




Remove the screws and IDC solenoid valve stay.




Release the injector sub-harness from the guides.




Remove the hose clamp and crankcase breather drain hose.



Remove the left air cleaner duct packing.



Remove the right air cleaner duct packing.




## FUEL SYSTEM (PGM-FI)


---

Remove the screws and upper air cleaner housing.


UPPER AIR CLEANER HOUSING




Remove the air cleaner housing packing.



Loosen the screws, then remove the air funnels and throttle body from the lower air cleaner housing.



Remove the rubber seals from the lower air cleaner housing.



ASSEMBLY

1.1 N·m  
(0.1 kgf·m, 0.8 lbf·ft)

PACKING

PACKING

UPPER AIR CLEANER HOUSING

O-RING

IAT SENSOR

AIR FUNNELS

LOWER AIR CLEANER HOUSING

PACKING

MAP SENSOR

DRAIN HOSE


IDC SOLENOID VALVE

RUBBER SEALS

SUB-HARNESS


THROTTLE BODY ASSEMBLY

Install new rubber seals into the lower air cleaner housing.




Install the lower air cleaner housing onto the throttle body, then install the air funnels.

Tighten the air funnel screws securely.



## FUEL SYSTEM (PGM-FI)

Install a new air cleaner case packing into the groove on the housing.




Install the upper air cleaner housing onto the lower housing.


Install and tighten the screws to the specified torque.

**TORQUE: 1.1 N·m (0.1 kgf·m, 0.8 lbf·ft)**


UPPER AIR CLEANER HOUSING



Install a new right air cleaner duct packing into the groove on the housing.




Install a new left air cleaner duct packing into the groove on the housing.






Install the crankcase breather drain hose with hose clamp.




*Refer to the wire harness properly (page 1-22).*


Route the injector sub-harness through the guides of the air cleaner housing.



Install the IDC solenoid valve stay and tighten the screws securely.




Install the sidestand switch 2P (Black) connector to IDC solenoid valve stay securely.




## FUEL SYSTEM (PGM-FI)


Connect the IACV 4P (Black) connector.



Connect the injector 2P (Gray) connectors.




Install the fuel feed hose and connect the quick connect fitting to the fuel rail (page 5-54).




Install the MAP sensor and tighten the screw securely.

Connect the MAP sensor vacuum hose.


Connect the MAP sensor 3P (Black) connector of the injector sub-harness.



Connect the TP sensor 3P (Black) connector of the injector sub-harness.




Connect the IDC solenoid valve 2P (Gray) connector of the injector sub-harness.



Install the IAT sensor with a new O-ring and tighten the screws securely.

Connect the IAT sensor 2P (Gray) connector.



### INSTALLATION

Refer to the wires properly (page 1-22).

Route the throttle cables to the frame properly, then install the air cleaner housing with the throttle body from the left side.


#### NOTICE

- Be careful not to damage the harness and hoses.
- Make sure each insulator is firmly installed to the intake port.




## FUEL SYSTEM (PGM-FI)


Connect fuel tank drain hose and breather hose to the fuel tank.




Tighten the insulator band screws (cylinder head side) so that the width of the band ends is  $10 \pm 1$  mm ( $0.39 \pm 0.04$  in).



Connect the ECM 33P (Black and Light gray) connectors to the ECM.




Install the ECM on the air cleaner housing.  
Install the ECM stay with the screws, then tighten the screws securely.



Refer to the wires properly (page 1-22). Connect the injector sub-harness 10P (Black) and 10P (White) connectors, and CKP sensor 2P (Red) connector.

Attach the connectors to the ECM stay securely.




If the right resonator duct removed, install the right resonator duct onto right air cleaner duct and tighten the screws to the specified torque

**TORQUE: 0.8 N·m (0.1 kgf·m, 0.6 lbf·ft)**


RESONATOR DUCT

SCREW



Install the right air cleaner duct and tighten the screws to the specified torque.


**TORQUE: 1.1 N·m (0.1 kgf·m, 0.8 lbf·ft)**



DUCT

SCREW

Refer to the wires properly (page 1-22). Route the sub-harness wire properly to guide.




GUIDE

SUB-HARNESS WIRE

## FUEL SYSTEM (PGM-FI)


Refer to the wires properly (page 1-22). Route the O<sub>2</sub> sensor and IDC hoses wire through guides.



Install the right pivot bracket, washers and nuts.  
Install the swingarm pivot washer and nut.

Install and tighten the pivot bracket upper and lower nuts to the specified torque.


**TORQUE: 69 N·m (7.0 kgf·m, 51 lbf·ft)**




Install and tighten the swingarm pivot nut to the specified torque.

**TORQUE: 98 N·m (10.0 kgf·m, 72 lbf·ft)**

Move the swingarm up and down several times and make sure it moves smoothly.




Connect the O<sub>2</sub> sensor 4P (Black) connector.




Install the right footpeg holder and tighten the mounting bolts to the specified torque.

**TORQUE: 37 N·m (3.8 kgf·m, 27 lbf·ft)**

Install the muffler (page 2-26).




Connect IDC hose to IDC solenoid valve.




*Refer to the wires properly (page 1-22).*

Route the fuel tank drain hose, radiator reserve tank overflow hose, alternator wire to the air cleaner housing guide.




Install the mounting bolt, washer then tighten the bolt to the specified torque.

**TORQUE: 3.5 N·m (0.4 kgf·m, 2.6 lbf·ft)**




## FUEL SYSTEM (PGM-FI)


Connect the #2/#3 ignition coil connectors.




Connect the PAIR air suction hose to the air cleaner housing.



Connect the sidestand switch 2P (Black) connector.




Connect the IDC hose to throttle body.







Connect the ECT sensor 3P (Black) connector.




Connect the crankcase breather hose to the air cleaner housing.



Connect the #1/#4 ignition coil connectors.



Connect the PAIR control solenoid valve 2P (Black) connector.



## FUEL SYSTEM (PGM-FI)


Install the right front resonator and tighten the screw to the specified torque.

**TORQUE: 1.1 N·m (0.1 kgf·m, 0.8 lbf·ft)**

Route the fuel feed hose to the guide of front resonator.


Connect the quick connect fitting to the fuel tank (page 5-54).

Remove the support tool, then install and tighten the fuel tank front mounting bolts (page 3-5).



Connect the vacuum hose to the intake air duct diaphragm.

Install the air cleaner element (page 3-7).




Connect the throttle cables to the throttle pipe.

Install the right handlebar switch housing (page 13-11).

Tighten the nuts securely.

Check the throttle operation and grip freeplay (page 3-6).




# THROTTLE BODY

## REMOVAL

Remove the throttle body from the air cleaner housing (page 5-68).

Loosen the lock nuts and disconnect the throttle cables from the throttle drum.




Loosen the insulator band screws and remove the insulators.



**NOTE:**

Mark each insulator to be sure of their insulator bands direction for reassembly.

- Do not damage the throttle body. It may cause incorrect throttle synchronization.
- The throttle body is factory pre-set. Do not disassemble in a way other than shown in this manual.
- Do not loosen or tighten the painted white bolts, nut and screws of the throttle body. Loosening or tightening them can cause throttle valve failure.



Viewed from cylinder head side and throttle sensor side:




PAINTED WHITE


PAINTED WHITE

# FUEL SYSTEM (PGM-FI)


Viewed from air cleaner housing side and throttle drum side:



Viewed from top and throttle drum side:




Viewed from bottom:




**INSTALLATION**

Install each insulator onto the throttle body while aligning its groove with the lug on the throttle body. Align the hole on each insulator band with the boss on the insulator.




Confirm the direction of the insulator band screws as shown.

#1 insulator band of the throttle body side is different from the others.




## FUEL SYSTEM (PGM-FI)

Tighten the throttle body side insulator band screws so that the width between the band ends is  $12 \pm 1$  mm ( $0.47 \pm 0.04$  in).



Connect the throttle cables and tighten the lock nuts.

Install the throttle body onto the air cleaner housing (page 5-73).




## INJECTOR

### INSPECTION

Remove the side cover (page 2-5).

Start the engine and let it idle.


Confirm the injector operating sounds with a sounding rod or stethoscope.




### REMOVAL

Remove the throttle body (page 5-85).


Disconnect the MAP sensor vacuum hoses.



Remove the bolts and fuel rail.




Disconnect the IACV distribution hoses.




*Do not loosen the IACV cover screws.*

Remove the IACV joint screw and joint plate.




Remove the injectors from the fuel rail.




# FUEL SYSTEM (PGM-FI)


Remove the seal ring and O-ring from each injector.



Remove the fuel rail from the fuel rail joint.  
Remove the O-rings from the fuel rail joint.




## INSTALLATION







Apply engine oil to new O-rings of the fuel rail joint.  
Install the O-rings onto the fuel rail joint.  
Install the fuel rails to the fuel rail joint.



Apply small amount of engine oil to new seal rings and O-rings.  
Install the seal ring and O-ring to each injector.




Install the injectors to the fuel rail.



Apply engine oil to new O-rings and install them to the IACV joints.


Install the IACV joints to the throttle body.




## FUEL SYSTEM (PGM-FI)

Install the joint plate and tighten the IACV joint screw to the specified torque.

**TORQUE: 2.1 N·m (0.2 kgf·m, 1.5 lbf·ft)**




Connect the IACV distribution hoses.



Install the injectors with the fuel rail.


Install and tighten the bolts to the specified torque.

**TORQUE: 5.1 N·m (0.5 kgf·m, 3.8 lbf·ft)**



Connect the MAP sensor vacuum hoses.

Install the throttle body to the air cleaner housing (page 5-73).



## ENGINE IDLE SPEED

### IDLE SPEED INSPECTION

#### NOTE:

- Inspect the idle speed after all other engine maintenance items have been performed and are within specifications.
- Before checking the idle speed, inspect the following items.
  - No DTC and MIL blinking.
  - Spark plug condition (page 3-8).
  - Air cleaner condition (page 3-7).
- The engine must be warm for accurate idle speed inspection.
- This system eliminates the need for manual idle speed adjustment compared to previous designs.
- Use a tachometer with graduations of  $50 \text{ min}^{-1}$  (rpm) or smaller that will accurately indicate a  $50 \text{ min}^{-1}$  (rpm) change.

Lift and support the fuel tank (page 3-5).

Start the engine and warm it up to coolant temperature  $80 \text{ }^{\circ}\text{C}$  ( $176 \text{ }^{\circ}\text{F}$ ).

Stop the engine and connect a tachometer according to the tachometer manufacturer's operating instructions.

Start the engine and let it idle. Check the idle speed.

**ENGINE IDLE SPEED:  $1,200 \pm 100 \text{ min}^{-1}$  (rpm)**

If the idle speed is out of the specification, check the following:

- Throttle operation and throttle grip free play (page 3-6).
- Intake air leak or engine top-end problem (page 8-3).
- IACV operation (page 5-94).

## IACV

### INSPECTION


The IACV is installed on the throttle body and is operated by the step motor. When the ignition switch is turned ON, the IACV operates for a few seconds.

Check the step motor operating (beep) sound with the ignition switch turned ON.

#### NOTE:

The IACV operation can be checked visually as follows:

- Remove the IACV (page 5-94). Connect the 4P (Black) connector to the IACV, then turn the ignition switch ON.




### REMOVAL


- Always clean the throttle body before the IACV removal to prevent dirt and debris from entering the IACV passage.

Remove the throttle body from the air cleaner housing (page 5-68).

Remove the screws and setting plate.




Remove the IACV motor.




**INSTALLATION**


Turn the slide valve clockwise until lightly seated on IACV.



Install the IACV motor, aligning its groove with the pin inside the motor housing.




Install the setting plate while aligning its cut-out with the lug on the IACV motor.



Install the screws and tighten them to the specified torque.

**TORQUE: 2.1 N·m (0.2 kgf·m, 1.5 lbf·ft)**



## MAP SENSOR


### REMOVAL/INSTALLATION

Lift and support the fuel tank (page 3-5).

Disconnect the MAP sensor 3P (Black) connector.  
Disconnect the vacuum hose from the MAP sensor.

Remove the screw and MAP sensor.

Installation is in the reverse order of removal.



## IAT SENSOR

### REMOVAL/INSTALLATION


Remove the left side cover (page 2-5).

Disconnect the IAT sensor 2P (Gray) connector.

Remove the screws, IAT sensor and O-ring from the air cleaner housing.

*Always replace the O-ring with a new one.*

Installation is in the reverse order of removal.




## ECT SENSOR

### REMOVAL/INSTALLATION

*Replace the ECT sensor while the engine is cold.*


Drain the coolant from the system (page 6-7).

Disconnect the crankcase breather hose.  
Remove the thermostat case mounting bolt.



Disconnect the 3P (Black) connector from the ECT sensor.

Remove the ECT sensor and sealing washer.



*Always replace a sealing washer with a new one.*


Install a new sealing washer and ECT sensor. Tighten the ECT sensor to the specified torque.

**TORQUE: 23 N·m (2.3 kgf·m, 17 lbf·ft)**

Connect the ECT sensor 3P (Black) connector.

Install the removal parts in the reverse order of removal.

Fill the cooling system with recommended coolant (page 6-7).




## BANK ANGLE SENSOR


### REMOVAL/INSTALLATION

Remove the seat (page 2-4).

Disconnect the bank angle sensor the 3P (Green) connector.



Remove the screws/washers and the bank angle sensor.




## FUEL SYSTEM (PGM-FI)

Install the bank angle sensor with its "UP" mark facing up.

Installation is in the reverse order of removal.

Tighten the mounting screws securely.



### INSPECTION

Remove the seat (page 2-4).

Disconnect the bank angle sensor 3P (Green) connector and connect the special tool between the connectors.

#### TOOL:

**Inspection test harness** 07GMJ-ML80100

Turn the ignition switch ON and engine stop switch "O".


Measure the voltage between the following terminals of the test harness.

TERMINAL	STANDARD
White clip (+) - Red clip (-)	Battery voltage
Green clip (+) - Red clip (-)	0 - 1 V

Turn the ignition switch OFF and remove the inspection test harness.

Connect the bank angle sensor 3P (Green) connector.

Remove the screws, washers and the bank angle sensor.




Place the bank angle sensor horizontal as shown, and turn the ignition switch ON and engine stop switch "O".

The bank angle sensor is normal if the engine stop relay clicks and power supply is closed.

Incline the bank angle sensor approximately 60 degrees to the left or right with keeping the ignition switch ON and engine stop switch "O".

The bank angle sensor is normal if the engine stop relay clicks and power supply is open.

If you repeat this test, first turn the ignition switch OFF, then turn the ignition switch ON and engine stop switch "O".






# ENGINE STOP RELAY


## INSPECTION

Remove the seat (page 2-4).

Remove the fuse/relay box cover.



Disconnect the engine stop relay.



Connect the ohmmeter to the engine stop relay connector terminals.


**Connection: A – B**

Connect a 12 V battery to the following engine stop relay connector terminals.

**Connection: C (+) – D (-)**

There should be continuity only when the 12 V battery is connected.

If there is no continuity when the 12 V battery is connected, replace the engine stop relay.





ECM

REMOVAL/INSTALLATION

*Except E and F type:* Remove the right side cover (page 2-5).  
 Pull out the ECM from stay.  
 Disconnect the 33P connectors from the ECM.  
 Installation is in the reverse order of removal.

**NOTE:**  
 After replacing the ECM, register the new transponder keys (page 21-6).



*E and F type:* Remove the right side cover (page 2-5).  
 Pull out the ECM from stay.  
 Remove the ECM protector bracket and discard it.  
 Disconnect the 33P connectors from the ECM.  
 Installation is in the reverse order of removal.

**NOTE:**  
 After replacing the ECM, register the new transponder keys (page 21-6).

ECM POWER/GROUND LINE INSPECTION

ENGINE DOES NOT START (No DTC and MIL blinking)

1. ECM Power Input Voltage Inspection

- Before starting the inspection, check for loose or poor contact on the ECM 33P connectors and recheck the MIL blinking.

Disconnect the ECM 33P (Black) connector.

Turn the ignition switch ON and engine stop switch "O".  
 Measure the voltage at the ECM 33P (Black) connector terminal and ground.

**TOOL:**


Test probe 07ZAJ-RDJA110

Connection: A4 (+) – Ground (-)

*Is there battery voltage?*

**YES** – GO TO STEP 2.

**NO** – GO TO STEP 3.



**2. ECM Ground Line Inspection**

Turn the ignition switch OFF.  
Check the continuity between the ECM 33P (Black) connector terminals and ground.

**TOOL:**

Test probe 07ZAJ-RDJA110

**Connection: A23 – Ground**


**A24 – Ground**

**B4 – Ground**

**Are there continuities?**

**YES** – Replace the ECM with a known good one, and recheck; refer to Key Registration Procedures (page 21-6)

**NO** – Open circuit in Green/white (A23, A24) wires or Green wire (B4)



**3. Engine Stop Relay Inspection 1**

Turn the ignition switch OFF.  
Remove the engine stop relay from the fuse/relay box (page 5-99).

Turn the ignition switch ON and engine stop switch "O".

Measure the voltage at the engine stop relay connector terminals.


**Connection: Black (+) – Red/blue (-)**

**Is there battery voltage?**

**YES** – GO TO STEP 4.

**NO** –

- Blown sub-fuse
- Open circuit in Black or Red/blue wire



## FUEL SYSTEM (PGM-FI)

### 4. Engine Stop Relay Inspection 2

Turn the ignition switch OFF.  
Jump the engine stop relay connector terminals with jumper wire.

**Connection: Red/white – Black/white**

Turn the ignition switch ON and engine stop switch "O".

Measure the voltage at the ECM 33P connector terminal and ground.


**Connection: A4 (+) – Ground (-)**

**TOOL:**

**Test probe** 07ZAJ-RDJA110

**Is there battery voltage?**

- YES** –
- Inspect the engine stop relay (page 5-99)
  - Inspect the engine stop switch (page 20-26)
  - Inspect the bank angle sensor (page 5-98)
- NO** – Open circuit in power input line (Black/white or Red/white) between the battery and the ECM



## SECONDARY AIR SUPPLY SYSTEM

### SYSTEM INSPECTION

Start the engine and warm it up until the coolant temperature is 80 °C (176 °F).

Stop the engine.

Lift and support the fuel tank (page 3-5).


Disconnect the air supply hose from the air cleaner housing.

Check that the secondary air intake port is clean and free of carbon deposits.

Check the PAIR check valves if the port is carbon fouled (page 8-6).



Start the engine and open the throttle slightly to be certain that the air sucked in through the air supply hose. If the air is not drawn in, check the air supply hoses for clogs and the PAIR control solenoid valve.




### PAIR CONTROL SOLENOID VALVE

#### Inspection

Remove the PAIR control solenoid valve.


Check that air flows (A) to (B) when the 12 V battery is connected to the PAIR control solenoid valve terminals. Air should not flow (A) to (B) when the battery is disconnected.



Check the resistance between the terminals of the PAIR control solenoid valve.

**STANDARD: 23 – 27  $\Omega$  (20 °C/68 °F)**


If the resistance is out of specification, replace the PAIR control solenoid valve.



## FUEL SYSTEM (PGM-FI)


### Removal/Installation

Lift and support the fuel tank (page 3-5).  
Disconnect the left PAIR air suction hoses.



Disconnect the right PAIR air suction hoses.  
Disconnect the PAIR control solenoid valve 2P (Black) connector.  
Remove the PAIR control solenoid valve from the stay.

Installation is in the reverse order of removal.




## O<sub>2</sub> SENSOR

### REMOVAL

- Handle the O<sub>2</sub> sensor with care.
- Do not get grease, oil or other materials in the O<sub>2</sub> sensor air hole, or it may be damaged.
- Do not service the O<sub>2</sub> sensor while it is hot.

Remove the exhaust pipe (page 2-19).



Remove the O<sub>2</sub> sensor from the exhaust pipe using the special tool.

**TOOL:**  
FRXM17 (Snap On) or equivalent


- Be careful not to damage the sensor wire.
- Do not use an impact wrench while removing or installing the O<sub>2</sub> sensor, or it may be damaged.

Install the O<sub>2</sub> sensor onto the exhaust pipe.

Tighten the unit to the specified torque.

**TORQUE: 24.5 N·m (2.5 kgf·m, 18 lbf·ft)**

Install the exhaust pipe (page 2-23).



## INTAKE AIR DUCT

### INTAKE DUCT VALVE DIAPHRAGM

#### Inspection


Remove the intake air duct from the air cleaner housing (page 3-7).

Disconnect the vacuum hose from the diaphragm.

Connect a vacuum pump to the diaphragm and apply specified vacuum.

**SPECIFIED VACUUM: 250 mm Hg (9.8 in Hg)**

The vacuum should hold and the duct valve should remain open.




#### Removal/Installation

Remove the intake air duct from the air cleaner housing (page 3-7).

Disconnect the vacuum hose from the diaphragm. Turn the diaphragm counterclockwise and unhook the diaphragm rod from the duct valve.

Installation is in the reverse order of removal.




## IDC SOLENOID VALVE

### Removal/Installation

Remove the air cleaner housing (page 5-62)

Remove the screw and IDC solenoid valve.

IDC SOLENOID VALVE



### Inspection


Remove the IDC solenoid valve.

Check that the air should flow (A) to (B), only when the 12 V battery is connected to the IDC solenoid valve terminals.

### CONNECTION:

Battery (+) terminal – Black/white terminal


Battery (-) terminal – Yellow/black terminal



Check the resistance between the terminals of the IDC solenoid valve.

**STANDARD:** 28 – 32  $\Omega$  (20 °C/68 °F)

If the resistance is out of specification, replace the IDC solenoid valve.






## VACUUM CHAMBER/ONE-WAY VALVE

### Removal/Installation

Remove the muffler (page 2-19)


Disconnect the vacuum chamber hoses.  
Remove the vacuum chamber stay bolt.  
Remove the vacuum chamber stay from the frame.



Remove the vacuum chamber mounting bolt from the vacuum chamber stay.

Installation is in the reverse order of removal.

*White paint mark vacuum hose connect (A) side of the vacuum chamber.*




### Inspection

Check the one-way valve operation as follows:

- Air should flow (B) to (A)
- Air should not flow (A) to (B)

If the operation is incorrect, replace the vacuum chamber/one-way valve assembly.



---

**MEMO**

DATE

---


# 6. COOLING SYSTEM

---

SYSTEM FLOW PATTERN .....	6-2	THERMOSTAT .....	6-8
SERVICE INFORMATION .....	6-3	RADIATOR .....	6-10
TROUBLESHOOTING .....	6-4	WATER PUMP .....	6-16
SYSTEM TESTING .....	6-5	RADIATOR RESERVE TANK .....	6-19
COOLANT REPLACEMENT .....	6-6	FAN CONTROL RELAY .....	6-20

**COOLING SYSTEM**

**SYSTEM FLOW PATTERN**



# SERVICE INFORMATION

## GENERAL

### ⚠ WARNING

Removing the radiator cap while the engine is hot can allow the coolant to spray out, seriously scalding you. Always let the engine and radiator cool down before removing the radiator cap.

### NOTICE

Using coolant with silicate inhibitors may cause premature wear of water pump seals or blockage of radiator passages. Using tap water may cause engine damage.

- Add cooling system at the reserve tank. Do not remove the radiator cap except to refill or drain the system.
- All cooling system services can be done with the engine installed in the frame.
- Avoid spilling coolant on painted surfaces.
- After servicing the system, check for leaks with a cooling system tester.
- Refer to the ECT sensor inspection (page 20-20).

## SPECIFICATIONS

ITEM		SPECIFICATIONS
Coolant capacity	Radiator and engine	3.0 liter (3.2 US qt, 2.6 Imp qt)
	Reserve tank	0.35 liter (0.37 US qt, 0.31 Imp qt)
Radiator cap relief pressure		108 – 137 kPa (1.1 – 1.4 kgf/cm <sup>2</sup> , 16 – 20 psi)
Thermostat	Begin to open	80.5 – 83.5 °C (176.9 – 182.3 °F)
	Fully open	95 °C (203 °F)
	Valve lift	8 mm (0.3 in) minimum
Recommended antifreeze		High quality ethylene glycol antifreeze containing silicate-free corrosion protection inhibitors
Standard coolant concentration		1:1 mixture with distilled water

## TORQUE VALUES

Water pump assembly bolt	12 N·m (1.2 kgf·m, 9 lbf·ft)	CT bolt
Radiator upper mounting bolt	3.5 N·m (0.4 kgf·m, 2.6 lbf·ft)	
Thermostat housing stay bolt	3.5 N·m (0.4 kgf·m, 2.6 lbf·ft)	Apply locking agent to the threads.
Fan motor mounting bolt	5.0 N·m (0.5 kgf·m, 3.7 lbf·ft)	
Cooling fan mounting nut	2.7 N·m (0.3 kgf·m, 2.0 lbf·ft)	
Fan motor shroud mounting bolt	4.4 N·m (0.4 kgf·m, 3.0 lbf·ft)	

### TROUBLESHOOTING

#### Engine temperature too high

- Faulty ECT sensor
- Thermostat stuck closed
- Faulty radiator cap
- Insufficient coolant
- Passage blocked in radiator, hoses or water jacket
- Air in system
- Faulty cooling fan motor
- Faulty fan control relay
- Faulty water pump

#### Engine temperature too low

- Faulty ECT sensor
- Thermostat stuck open
- Faulty fan control relay

#### Coolant leak

- Faulty water pump mechanical seal
- Deteriorated O-rings
- Faulty radiator cap
- Damaged or deteriorated cylinder head gasket
- Loose hose connection or clamp
- Damaged or deteriorated hose


# SYSTEM TESTING

## COOLANT (HYDROMETER TEST)


Lift and support the fuel tank (page 3-5).

Remove the radiator cap.

*Always let the engine and radiator cool down before removing the radiator cap.*



Test the coolant gravity using a hydrometer (see below for "Coolant gravity chart"). For maximum corrosion protection, a 1:1 solution of ethylene glycol and distilled water is recommended (page 6-3). Look for contamination and replace the coolant if necessary.



### COOLANT GRAVITY CHART

		Coolant temperature °C (°F)										
		0 (32)	5 (41)	10 (50)	15 (59)	20 (68)	25 (77)	30 (86)	35 (95)	40 (104)	45 (113)	50 (122)
Coolant ratio%	5	1.009	1.009	1.008	1.008	1.007	1.006	1.005	1.003	1.001	0.999	0.997
	10	1.018	1.017	1.017	1.016	1.015	1.014	1.013	1.011	1.009	1.007	1.005
	15	1.028	1.027	1.026	1.025	1.024	1.022	1.020	1.018	1.016	1.014	1.012
	20	1.036	1.035	1.034	1.033	1.031	1.029	1.027	1.025	1.023	1.021	1.019
	25	1.045	1.044	1.043	1.042	1.040	1.038	1.036	1.034	1.031	1.028	1.025
	30	1.053	1.052	1.051	1.047	1.046	1.045	1.043	1.041	1.038	1.035	1.032
	35	1.063	1.062	1.060	1.058	1.056	1.054	1.052	1.049	1.046	1.043	1.040
	40	1.072	1.070	1.068	1.066	1.064	1.062	1.059	1.056	1.053	1.050	1.047
	45	1.080	1.078	1.076	1.074	1.072	1.069	1.066	1.063	1.060	1.057	1.054
	50	1.086	1.084	1.082	1.080	1.077	1.074	1.071	1.068	1.065	1.062	1.059
	55	1.095	1.093	1.091	1.088	1.085	1.082	1.079	1.076	1.073	1.070	1.067
60	1.100	1.098	1.095	1.092	1.089	1.086	1.083	1.080	1.077	1.074	1.071	

## COOLING SYSTEM

### RADIATOR CAP/SYSTEM PRESSURE INSPECTION

Remove the radiator cap (page 6-5).

*Before installing the cap in the tester, wet the sealing surfaces.*

Pressure test the radiator cap. Replace the radiator cap if it does not hold pressure, or if relief pressure is too high or too low. It must hold specified pressure for at least 6 seconds.

#### RADIATOR CAP RELIEF PRESSURE:



108 – 137 kPa (1.1 – 1.4 kgf/cm<sup>2</sup>, 16 – 20 psi)

Pressure the radiator, engine and hoses, and check for leaks.

#### NOTICE

*Excessive pressure can damage the cooling system components. Do not exceed 137 kPa (1.4 kgf/cm<sup>2</sup>, 20 psi).*

Repair or replace components if the system will not hold specified pressure for at least 6 seconds.



## COOLANT REPLACEMENT

### PREPARATION


- The effectiveness of coolant decreases with the accumulation of rust or if there is a change in the mixing proportion during usage. Therefore, for best performance change the coolant regularly as specified in the maintenance schedule.
- Mix only distilled water with the antifreeze.

#### RECOMMENDED ANTIFREEZE:

High quality ethylene glycol antifreeze containing silicate-free corrosion protection inhibitors

#### RECOMMENDED MIXTURE:

1:1 (distilled water and antifreeze)






**REPLACEMENT/AIR BLEEDING**

Lift and support the fuel tank (page 3-5).

Remove the radiator cap.


*Always let the engine and radiator cool down before removing the radiator cap.*



Remove the drain bolt on the water pump cover and drain the system coolant.

Reinstall the drain bolt with new sealing washer. Tighten the water pump drain bolt to the specified torque.


**TORQUE: 12 N·m (1.2 kgf·m, 9 lbf·ft)**



Disconnect the siphon hose from the reserve tank and drain the reserve tank coolant.

Empty the coolant and rinse the inside of the reserve tank with water.

Connect the siphon hose to the reserve tank.



*When filling the system or reserve tank with a coolant (checking coolant level), place the motorcycle in a vertical position on a flat, level surface.*

Remove the radiator reserve tank cap and fill the reserve tank to the upper level line.

Bleed air from the system as follows:

1. Shift the transmission into neutral. Start the engine and let it idle for 2 – 3 minutes.
2. Snap the throttle three to four times to bleed air from the system.
3. Stop the engine and add coolant up to the proper level if necessary. Reinstall the radiator cap.
4. Check the level of coolant in the reserve tank and fill to the upper level if it is low.

Install the radiator reserve tank cap.

Install the removed parts in the reverse order of removal.




**THERMOSTAT**

**REMOVAL**


Drain the coolant (page 6-7).

Disconnect the crankcase breather hose from the air cleaner housing, and siphon hose from filler neck.


Remove the thermostat case mounting bolt.



Remove the thermostat housing bolts, ECT sensor ground wire terminal and thermostat housing.




Remove the thermostat from the case.



**INSPECTION**

Visually inspect the thermostat for damage. Check for damage of the seal ring.

Replace the thermostat if the valve stays open at room temperature.



**NOTICE**

- *Wear insulated gloves and adequate eye protection.*
- *Keep flammable materials away from the electric heating element.*


*Do not let the thermostat or thermometer touch the pan, or you will get false reading.*

Heat the water with an electric heating element to operating temperature for 5 minutes. Suspend the thermostat in heated water to check its operation.

**THERMOSTAT BEGIN TO OPEN:**  
80.5 – 83.5 °C (176.9 – 182.3 °F)


**VALVE LIFT:**  
8 mm (0.3 in) minimum at 95 °C (203 °F)

Replace the thermostat if the valve responds at temperatures other than those specified.




**THERMOSTAT INSTALLATION**

Install the thermostat into the case with its air bleed hole facing upward.



Install the thermostat housing onto the thermostat case.

Install the ECT sensor ground wire terminal onto the thermostat housing and tighten the thermostat housing bolts securely.




## COOLING SYSTEM

Install the thermostat case onto the frame and tighten the bolt securely.

Route the crankcase breather hose properly and connect it to the air cleaner housing.

Connect the siphon hose to the filler neck.

Fill the system with the recommended coolant and bleed any air (page 6-6).




### THERMOSTAT CASE REMOVAL/ INSTALLATION

Drain the coolant (page 6-7).

Disconnect the crankcase breather hose.

Disconnect the siphon hose.

Remove the thermostat case mounting bolt.




Disconnect the ECT sensor connector.

If necessary, remove the ECT sensor from the thermostat case (page 5-96).

Loosen the hose band screws and disconnect the water hoses from the thermostat case.

Installation is in the reverse order of removal.

Fill the system with the recommended coolant and bleed any air (page 6-6).



## RADIATOR

### REMOVAL


*Be careful not to damage the radiator fins.*

Lift and support the fuel tank (page 3-5).


Drain the coolant (page 6-7).

Remove the radiator reserve tank (page 6-19).


Disconnect the fan motor 2P (Natural) connector.




Loosen the hose band screws and disconnect the lower radiator hose.




Loosen the hose band screw and disconnect the upper radiator hose.



Release the horn wire from the guide of fan motor shroud.




Remove the lower mounting bolt, washer and mounting rubber.




## COOLING SYSTEM

Remove the upper mounting bolts, washers and mounting rubbers, then remove the radiator assembly.




### DISASSEMBLY

Remove the four bolts/washers and cooling fan motor/shroud assembly from the radiator.




Remove the nut and cooling fan.




Release the fan motor wire from the guide of fan motor shroud.

Remove the mounting bolts and fan motor from the fan motor shroud.




ASSEMBLY




Install the fan motor onto the fan motor shroud and tighten the bolts to the specified torque.

**TORQUE: 5.0 N-m (0.5 kgf-m, 3.7 lbf-ft)**

Route the fan motor wire through the guide of fan motor shroud.




Install the cooling fan onto the fan motor shaft by aligning the flat surfaces.



## COOLING SYSTEM


Apply a locking agent to the cooling fan nut threads.  
Tighten the nut to the specified torque.

**TORQUE: 2.7 N·m (0.3 kgf·m, 2.0 lbf·ft)**



Install the cooling fan motor/shroud assembly onto the radiator.  
Install the mounting bolts with washers and tighten the bolts to the specified torque.

**TORQUE: 4.4 N·m (0.4 kgf·m, 3.0 lbf·ft)**




## INSTALLATION

*Be careful not to damage the radiator fins.*

Install the radiator assembly with the mounting rubbers, washers and upper mounting bolts. Tighten the bolts to the specified torque.

**TORQUE: 3.5 N·m (0.4 kgf·m, 2.6 lbf·ft)**




Install the lower mounting bolt with mounting rubber and washer.  
Tighten the bolt securely.






Refer to the wire harness properly (page 1-22).


Route the horn wire through the guide of fan motor shroud.



Connect the upper radiator hose and tighten the hose band screw securely.




Connect the lower radiator hose and tighten the hose band screw securely.



Route the fan motor wire properly and connect the fan motor 2P (Natural) connector.

Install the radiator reserve tank (page 6-19).

Fill the system with the recommended coolant (page 6-6).



# WATER PUMP

## MECHANICAL SEAL INSPECTION


Check the bleed hole of the water pump for signs of coolant leakage.

Make sure that there are no continuous coolant leakage from the bleed hole while operating the engine.

**NOTE:**

- A small amount of coolant weeping from the bleed hole is normal.
- Make sure that there are no continuous coolant leakage from the bleed hole while operating the engine.


Replace the water pump as an assembly if necessary




## REMOVAL

Drain the coolant (page 6-7).


Disconnect the lower radiator hose and bypass hose from the water pump cover.



Remove the flange bolts, drain bolt and sealing washer.



Remove the water pump cover assembly  
Remove the O-ring from the water pump body.




Remove the separator plate from the water pump cover.  
Remove the dowel pins and O-ring from the water pump cover.

SEPARATOR PLATE

O-RING


DOWEL PINS




Disconnect the water joint hose from the water pump body.  
Remove the water pump body and O-ring from the crankcase.

JOINT HOSE

WATER PUMP BODY




## INSTALLATION




## COOLING SYSTEM

Apply engine oil to new O-ring and install it onto the stepped portion of the water pump body.

Install the water pump body into the crankcase while aligning the water pump shaft groove with the oil pump shaft lug.




Align the water pump shaft groove with the oil pump shaft lug by turning the water pump impeller.



Align the mounting bolt holes in the water pump and crankcase, and make sure the water pump is securely installed.


Connect the joint hose to the water pump body, and tighten the hose band screw securely.



Install a new O-ring into the groove in the water pump cover groove.


Install the dowel pins to the water pump cover.

Install the separator plate onto the water pump cover.




Install a new O-ring into the water pump body groove.

Install the water pump cover assembly onto the water pump body.




Install the water pump cover assembly bolts and drain bolt with new sealing washer. Tighten the bolts to the specified torque.

**TORQUE: 12 N·m (1.2 kgf·m, 9 lbf·ft)**



Connect the lower radiator hose and bypass hose to the water pump cover, then tighten the hose band screws securely.

Fill the system with the recommended coolant (page 6-6).



## **RADIATOR RESERVE TANK**

### **REMOVAL/INSTALLATION**


Lift and support the fuel tank (page 3-5).

Disconnect the overflow and siphon hose from the reserve tank.

Remove the radiator reserve tank mounting bolts. Remove the reserve tank from the frame, drain the coolant from the filler neck.

Installation is in the reverse order of removal.

Fill the reserve tank with coolant (page 6-7).




# FAN CONTROL RELAY


## INSPECTION

Remove the seat (page 2-4).

Remove the fuse/relay box cover.



Disconnect the fan control relay.



Connect the ohmmeter to the fan control relay connector terminals.


**Connection: A (Blue/orange) – B (Black/blue)**

Connect a 12 V battery to the following engine stop relay connector terminals.

**Connection: C (Green/blue) – D (Black/white)**

There should be continuity only when the 12 V battery is connected.

If there is no continuity when the 12 V battery is connected, replace the fan control relay.



# 7. ENGINE REMOVAL/INSTALLATION

---


COMPONENT LOCATION ..... 7-2

SERVICE INFORMATION ..... 7-3

ENGINE REMOVAL ..... 7-4

ENGINE INSTALLATION ..... 7-8

**COMPONENT LOCATION**





## SERVICE INFORMATION

### GENERAL

- A hoist or equivalent is required to support the motorcycle when removing and installing the engine.
- A floor jack or other adjustable support is required to support and maneuver the engine.
- Do not use the oil filter and oil cooler as a jacking point.
- The following components can be serviced with the engine installed in the frame.
  - Alternator (page 10-4)
  - Clutch (page 9-18)
  - Camshaft (page 8-8)
  - Gearshift linkage (page 11-7)
  - Oil cooler (page 4-13)
  - Oil pump (page 4-8)
  - Transmission (page 11-12)
  - Water pump (page 6-16)
- The following components require engine removal for service.
  - Cylinder head (page 8-12)
  - Crankshaft (page 12-8)
  - Piston/cylinder (page 12-17)

### SERVICE DATA

ITEM		SPECIFICATIONS
Engine dry weight		65.8 kg (146.8 lbs)
Engine oil capacity	After disassembly	3.6 liter (3.8 US qt, 3.2 Imp qt)
Coolant capacity	Radiator and engine	3.06 liter (3.23 US qt, 2.69 Imp qt)

### TORQUE VALUES

Front engine hanger nut	49 N·m (5.0 kgf·m, 36 lbf·ft)	
Front engine hanger bolt	59 N·m (6.0 kgf·m, 44 lbf·ft)	
Rear engine hanger nut	49 N·m (5.0 kgf·m, 36 lbf·ft)	
Rear engine mounting nut	59 N·m (6.0 kgf·m, 44 lbf·ft)	
Drive sprocket bolt	54 N·m (5.5 kgf·m, 40 lbf·ft)	
Gearshift arm pinch bolt	20 N·m (2.0 kgf·m, 15 lbf·ft)	ALOC bolt; replace with a new one.
Starter motor terminal nut	12 N·m (1.2 kgf·m, 9 lbf·ft)	
Ignition coil stay bolt	3.5 N·m (0.4 kgf·m, 2.6 lbf·ft)	

## ENGINE REMOVAL

Drain the coolant (page 6-7).


Remove the following:

- Exhaust pipe (page 2-19)
- Radiator reserve tank (page 6-19)
- Air cleaner housing (page 5-62)

Disconnect the alternator 3P (Black) connector and release the wire (page 17-7).

Loosen the rear axle bearing holder pinch bolt and make a drive chain slack fully (page 3-21).

Remove the pinch bolt and gearshift arm.




Disconnect the engine sub harness 6P (Black) connector.




Remove the terminal nut and starter motor cable (page 19-6).


Remove the bolt and ground cable.




Loosen the hose band screw and disconnect bypass hose from the water pump.



Loosen the hose band screw and disconnect the lower radiator hose.




Loosen the hose band screw and disconnect the water hose from the hose joint.




Remove the clutch slave cylinder and clutch lifter rod (page 9-14).

Remove the bolts, left crankcase rear cover.




Remove the drive chain guide plate and dowel pins.




## ENGINE REMOVAL/INSTALLATION

Remove the bolt, washer and drive sprocket from countershaft.




Disconnect the left PAIR air suction hose from the PAIR check valve cover.  
Disconnect the crankcase breather hose from the cylinder head cover.

Remove the No.1 and No.2 spark plug caps.




Remove the ignition coil stay mounting bolts.



Disconnect the right PAIR air suction hose from the PAIR check valve cover.


Remove the No.3 and No.4 spark plug caps.



## ENGINE REMOVAL/INSTALLATION

Remove the pivot bracket bolts and washers.


Remove the swingarm pivot bolt, then remove the left pivot bracket.




Remove the radiator the lower mounting bolt and release the horn wire from the guide of fan motor shroud (page 6-10)

Support the engine using a jack or other adjustable support.


Remove the front engine hanger bolts and collars. Remove the front engine hanger bracket bolts, washers and nuts.



Remove the rear lower engine hanger nut and distance collar. Remove the rear lower engine hanger bracket nuts and bracket.




Remove the rear lower engine hanger bolt. Remove the rear lower engine hanger bracket bolts, bracket and dowel pins.




## ENGINE REMOVAL/INSTALLATION

Remove the rear upper engine hanger nut and collar.  
Remove the rear upper engine hanger bracket nuts and bracket.




Remove the rear upper engine hanger bolt.  
Remove the rear upper engine hanger bracket bolts and bracket.

Remove the engine from the frame.



## ENGINE INSTALLATION


- Note the direction of the engine hanger bolts and collars.
- The jack height must be continually adjusted to relieve stress from the mounting fasteners.
- Route the wire and cables properly (page 1-22).



Carefully install the engine into the frame.

Install the left rear upper engine hanger bracket and bracket bolts.

Install the rear upper engine hanger bolt from the left side.




## ENGINE REMOVAL/INSTALLATION

Install the right rear upper engine hanger bracket and nuts.


*Install the collar onto the right side engine bracket.*

Install the collar between the engine and right rear upper engine hanger bracket.  
Install the rear upper engine hanger nut.




Install the rear lower engine hanger bracket bolts dowel pins into the frame.

Install the left lower engine hanger bracket.




Install the rear lower engine hanger bracket bolts.  
Install the rear lower engine hanger bolt from left side.



*Install the collar onto the right side engine bracket.*

Install the collar between the engine and right rear lower engine hanger bracket.  
Install the rear lower engine hanger nut.  
Install the rear lower engine hanger bracket nuts.




## ENGINE REMOVAL/INSTALLATION

Install the front engine hanger bracket bolts, washers and nuts.

Install the front engine hanger bolts and collars.


Install the radiator the lower mounting bolt and route the horn wire to the guide of fan motor shroud (page 6-14)



Tighten the rear lower engine hanger bracket nuts to the specified torque.

**TORQUE:**


Rear lower engine hanger bracket nuts:  
49 N-m (5.0 kgf-m, 36 lbf-ft)



Tighten the rear upper engine hanger bracket nuts to the specified torque.

**TORQUE:**


Rear upper engine hanger bracket nuts:  
49 N-m (5.0 kgf-m, 36 lbf-ft)



Tighten the front engine hanger bracket nuts to the specified torque.

**TORQUE:**

Front engine hanger bracket nuts:  
49 N-m (5.0 kgf-m, 36 lbf-ft)






Tighten the rear lower engine hanger nut to the specified torque.

**TORQUE:**


Rear lower engine hanger nut:  
59 N·m (6.0 kgf·m, 44 lbf·ft)



Tighten the rear upper engine hanger nut to the specified torque.

**TORQUE:**


Rear upper engine hanger bracket nut:  
59 N·m (6.0 kgf·m, 44 lbf·ft)




Tighten the front engine mounting bolts to the specified torque.

**TORQUE:**

Front engine mounting bolts:  
59 N·m (6.0 kgf·m, 44 lbf·ft)




Set the swingarm pivot bracket onto the frame and align the bolt holes.  
Install the bracket bolts, washers and pivot bolt.



## ENGINE REMOVAL/INSTALLATION


Connect the PAIR air suction hose to the PAIR check valve cover.

Install the No.3 and No.4 spark plug caps.



Install and tighten the ignition coil mounting stay bolts to the specified torque.


**TORQUE: 3.5 N·m (0.4 kgf·m, 2.6 lbf·ft)**



Connect the crankcase breather hose to the cylinder head cover.

Connect the left PAIR air suction hoses to the PAIR check valve cover.


Install the No.1 and No.2 spark plug caps.



Install the drive sprocket with its "ML7" mark facing out.


Install the washer and drive sprocket bolt, and tighten the drive sprocket bolt to the specified torque.

**TORQUE: 54 N·m (5.5 kgf·m, 40 lbf·ft)**




# ENGINE REMOVAL/INSTALLATION

Install the dowel pins and the drive chain guide plate.




Install the left crankcase rear cover and tighten the cover bolts securely.


Install the clutch lifter rod and clutch slave cylinder (page 9-16).



Install water hose to hose joint and tighten the hose band screw securely.




Connect the lower radiator hose, then tighten the hose band screw.



## ENGINE REMOVAL/INSTALLATION

Connect the bypass hose to the water pump, then tighten the hose band screw.




Route the starter motor cable and ground cable.

Tighten the starter motor mounting bolts with the ground cable.

Connect the starter motor cable, then tighten the terminal nut to the specified torque.

**TORQUE: 12 N·m (1.2 kgf·m, 9 lbf·ft)**



Connect the engine sub harness 6P (Black) connector.



Install the gearshift arm onto the gearshift spindle, while aligning its slit with the punch mark onto the spindle.

Tighten the new pinch bolt to the specified torque.

**TORQUE: 20 N·m (2.0 kgf·m, 15 lbf·ft)**


Connect the alternator 3P (Black) connector (page 17-8).

Install the following:

- Exhaust pipe (page 2-19)
- Radiator reserve tank (page 6-19)
- Air cleaner housing (page 5-77)

Adjust the drive chain slack (page 3-21).

Fill the cooling system with the recommended coolant and bleed any air (page 6-6).




# 8. CYLINDER HEAD/VALVES

---

COMPONENT LOCATION .....	8-2	CYLINDER HEAD INSPECTION .....	8-14
SERVICE INFORMATION .....	8-3	VALVE GUIDE REPLACEMENT .....	8-17
TROUBLESHOOTING .....	8-5	VALVE SEAT INSPECTION/REFACING ..	8-18
CYLINDER COMPRESSION TEST.....	8-6	CYLINDER HEAD ASSEMBLY .....	8-21
CYLINDER HEAD COVER REMOVAL .....	8-6	CYLINDER HEAD INSTALLATION.....	8-23
CYLINDER HEAD COVER DISASSEMBLY .....	8-7	CAMSHAFT INSTALLATION .....	8-25
CAMSHAFT REMOVAL .....	8-8	CYLINDER HEAD COVER ASSEMBLY....	8-30
CYLINDER HEAD REMOVAL .....	8-12	CYLINDER HEAD COVER INSTALLATION .....	8-31
CYLINDER HEAD DISASSEMBLY.....	8-13		

COMPONENT LOCATION



# SERVICE INFORMATION

## GENERAL

- This section covers service of the cylinder head, valves and camshafts.
- The camshaft services can be done with the engine installed in the frame. The cylinder head service requires engine removal.
- When disassembling, mark and store the disassembled parts to ensure that they are reinstalled in their original locations.
- Clean all disassembled parts with cleaning solvent and dry them by blowing them off with compressed air before inspection.
- Camshaft lubricating oil is fed through oil passages in the cylinder head. Clean the oil passages before assembling cylinder head.
- Be careful not to damage the mating surfaces when removing the cylinder head cover and cylinder head.

## SPECIFICATIONS

Unit: mm (in)

ITEM		STANDARD	SERVICE LIMIT
Cylinder compression		1,500 kPa (15.3 kgf/cm <sup>2</sup> , 218 psi) at 300 min <sup>-1</sup> (rpm)	—
Valve clearance		IN	0.16 ± 0.03 (0.006 ± 0.001)
		EX	0.32 ± 0.03 (0.013 ± 0.001)
Camshaft	Cam lobe height	IN	36.02 – 36.10 (1.418 – 1.421)
		EX	36.08 – 36.16 (1.420 – 1.424)
	Runout	—	0.05 (0.002)
		Oil clearance	0.020 – 0.062 (0.0008 – 0.0024)
Valve lifter	Valve lifter O.D.	25.978 – 25.993 (1.0228 – 1.0233)	25.97 (1.022)
	Valve lifter bore I.D.	26.010 – 26.026 (1.0240 – 1.0246)	26.04 (1.025)
Valve, valve guide	Valve stem O.D.	IN	4.475 – 4.490 (0.1762 – 0.1768)
		EX	4.465 – 4.480 (0.1758 – 0.1764)
	Valve guide I.D.		4.500 – 4.512 (0.1772 – 0.1776)
	Stem-to-guide clearance	IN	0.010 – 0.037 (0.0004 – 0.0015)
		EX	0.020 – 0.047 (0.0008 – 0.0019)
	Valve guide projection above cylinder head	IN	16.0 – 16.3 (0.63 – 0.64)
EX		16.0 – 16.3 (0.63 – 0.64)	
Valve seat width		0.90 – 1.10 (0.035 – 0.043)	1.5 (0.06)
Valve spring free length		IN	39.5 (1.56)
		EX	39.5 (1.56)
Cylinder head warpage		—	0.10 (0.004)


## TORQUE VALUES

Cylinder head mounting bolt	51 N·m (5.2 kgf·m, 38 lbf·ft)	Apply molybdenum disulfide oil to the threads and seating surface.
Camshaft holder flange bolt	12 N·m (1.2 kgf·m, 9 lbf·ft)	Apply engine oil to the threads and seating surface.
Cylinder head sealing bolt	28 N·m (2.9 kgf·m, 21 lbf·ft)	Apply a locking agent to the threads.
Cylinder head cover bolt	10 N·m (1.0 kgf·m, 7 lbf·ft)	
PAIR check valve cover bolt	12 N·m (1.2 kgf·m, 9 lbf·ft)	Apply a locking agent to the threads.
Cam sprocket flange knock bolt	20 N·m (2.0 kgf·m, 15 lbf·ft)	Apply a locking agent to the threads.
Cam chain tensioner socket bolt	10 N·m (1.0 kgf·m, 7 lbf·ft)	Apply a locking agent to the threads.
Cam chain guide torx bolt	12 N·m (1.2 kgf·m, 9 lbf·ft)	Apply a locking agent to the threads.
Exhaust pipe stud bolt	See page 2-23	
Spark plug	16 N·m (1.6 kgf·m, 12 lbf·ft)	

# CYLINDER HEAD/VALVES


## TOOLS

Compression gauge attachment  
07RMJ-MY50100




or equivalent commercially available.


Cam chain tensioner holder  
070MG-0010100




Valve spring compressor  
07757-0010000




Valve spring compressor attachment  
07959-KM30101




Tappet hole protector  
07HMG-MR70002




Valve guide driver  
07HMD-ML00101



Valve guide driver  
07743-0020000



Valve guide reamer, 4.5 mm  
07HMH-ML00101



Valve seat cutter, 29 mm (45° IN)  
07780-0010300



or equivalent commercially available.

Valve seat cutter, 27.5 mm (45° EX)  
07780-0010200



or equivalent commercially available.

Flat cutter, 30 mm (32° IN)  
07780-0012200



or equivalent commercially available.

Flat cutter, 27 mm (32° EX)  
07780-0013300



or equivalent commercially available.




Interior cutter, 30 mm (60° IN/EX)  
07780-0014000



or equivalent commercially available.

Cutter holder, 4.5 mm  
07781-0010600



or equivalent commercially available.

## TROUBLESHOOTING

- Engine top-end problems usually affect engine performance. These problem can be diagnosed by a compression test or by tracing engine noises to the top-end with a sounding rod stethoscope.
- If the performance is poor at low speeds, check for white smoke in the crankcase breather hose. If the hose is smoky, check for a seized piston ring (page 12-18).

### Compression too low, hard starting or poor performance at low speed

- Valves:
  - Incorrect valve adjustment
  - Burned or bent valve
  - Incorrect valve timing
  - Broken valve spring
  - Uneven valve seating
- Cylinder head:
  - Leaking or damaged head gasket
  - Warped or cracked cylinder head
- Worn cylinder, piston or piston rings (page 12-18)

### Compression too high, overheating or knocking

- Excessive carbon build-up on piston crown or on combustion chamber

### Excessive smoke

- Cylinder head:
  - Worn valve stem or valve guide
  - Damaged stem seal
- Worn cylinder, piston or piston rings (page 12-18)

### Excessive noise

- Cylinder head:
  - Incorrect valve adjustment
  - Sticking valve or broken valve spring
  - Damaged or worn camshaft
  - Loose or worn cam chain
  - Worn or damaged cam chain
  - Worn or damaged cam chain tensioner
  - Worn cam sprocket teeth
- Worn cylinder, piston or piston rings (page 12-18)

### Rough idle

- Low cylinder compression

## CYLINDER HEAD/VALVES

### CYLINDER COMPRESSION TEST

Warm the engine to normal operating temperature. Stop the engine and remove the all spark plug caps and spark plugs (page 3-8). Lift and support the fuel tank (page 3-5).

Install a compression gauge into the spark plug hole.

**TOOL:**

**Compression gauge attachment**

**07RMJ-MY50100 or equivalent commercially available**

Open the throttle all the way and crank the engine with the starter motor until the gauge reading stops rising.

The maximum reading is usually reached within 4 – 7 seconds.

**Compression pressure:**


**1,500 kPa (15.3 kgf/cm<sup>2</sup>, 218 psi) at 300 min<sup>-1</sup> (rpm)**

Low compression can be caused by:

- Blown cylinder head gasket
- Improper valve adjustment
- Valve leakage
- Worn piston ring or cylinder

High compression can be caused by:

- Carbon deposits in combustion chamber or on piston head



### CYLINDER HEAD COVER REMOVAL

Remove the fuel tank (page 5-60).



Disconnect the spark plug caps (page 3-8).

Remove the crankcase breather hose.

Disconnect the PAIR air suction hoses from the cylinder head cover and remove the PAIR control solenoid valve (page 5-102).

Remove the cylinder head cover bolts.


Remove the cylinder head cover from the cylinder head.



# CYLINDER HEAD COVER DISASSEMBLY


Remove the cylinder head cover packing.

HEAD COVER PACKING



Remove the bolts and PAIR check valve cover.

BOLTS




PAIR CHECK VALVE COVERS

Remove the PAIR check valves from the cylinder head cover.


Check the PAIR check valve for wear or damage, replace if necessary.

PAIR CHECK VALVES



Remove the port plates from the cylinder head cover.


PORT PLATES




## CAMSHAFT REMOVAL

Remove the cylinder head cover (page 8-6).

Remove the timing hole cap and O-ring.




Turn the crankshaft clockwise, align the "T" mark on the starter clutch outer with the index notch on the right crankcase cover.




The timing marks ("IN" and "EX") on the cam sprockets must be flush with the cylinder head surface and facing outward as shown.

If the timing marks on the cam sprocket are facing inward, turn the crankshaft clockwise one full turn (360°) and realign the timing marks with the cylinder head surface so they are facing outward.



Remove the cam chain tensioner lifter sealing bolt and sealing washer.




Turn the tensioner lifter shaft fully in (clockwise) and secure it using the special tool to prevent damaging the cam chain.


**TOOL:**

**Cam chain tensioner holder 070MG-0010100**

CAM CHAIN TENSIONER HOLDER



Remove the bolts and cam chain guide B.





*It is not necessary to remove the cam sprocket from the camshaft except when replacing the camshaft and/or cam sprocket.*

If you plan to replace the camshaft and/or cam sprocket, loosen and remove the cam sprocket bolts as follows:

*Be careful not to drop the cam sprocket bolts and cam sprocket into the crankcase.*

- Remove the cam sprocket bolts from the intake and exhaust camshafts.
- Turn the crankshaft clockwise one full turn (360°), remove the other cam sprocket bolts from the camshafts.
- Remove the cam sprockets from the camshafts.



## CYLINDER HEAD/VALVES


*Suspend the cam chain with a piece of wire to prevent the chain from falling into the crankcase.*

Loosen and remove the camshaft holder bolts/sealing washers, then remove the camshaft holders and camshafts.

### NOTE:


From outside to inside, loosen the bolts in a criss-cross pattern in several steps or the camshaft holder might break.

Do not forcibly remove the dowel pins from the camshaft holders.



Remove the valve lifters and shims.

- Be careful not to damage the valve lifter bore.
- Shim may stick to the inside of the valve lifter. Do not allow the shims to fall into the crankcase.
- Mark all valve lifters and shims to ensure correct reassembly in their original locations.
- The valve lifter can be easily removed with a valve lapping tool or magnet.
- The shims can be easily removed with a tweezers or magnet.



## INSPECTION


### CAMSHAFT

Check the cam and journal surfaces of the camshaft for scoring, scratches or evidence of insufficient lubrication.

Check the oil holes in the camshaft for clogging.

Support both sides of the camshaft (at journals) with V-blocks and check the camshaft run out with a dial gauge.

**SERVICE LIMIT: 0.05 mm (0.002 in)**




Using a micrometer, measure each cam lobe height.

### SERVICE LIMITS:


**IN: 36.00 (1.417)**

**EX: 36.06 (1.420)**



**CAMSHAFT HOLDERS**


Inspect the journals of the each camshaft holder for scoring, scratches, or evidence of insufficient lubrication.  
Inspect the oil orifices of the holders for clogging.



**CAMSHAFT OIL CLEARANCE**

*Do not rotate the camshaft when using plastigauge.*

Wipe any oil from the journals of the camshaft, cylinder head and camshaft holders.  
Lay a strip of plastigauge lengthwise on top of each camshaft journal.



*Be sure the dowel pins in the camshaft holder align the holes in the cylinder head.*


Install the each camshaft holder to the correct locations with the identification marks.

- "R" mark: center camshaft holder (Holder A)
- "L" mark: left camshaft holder (Holder B)
- No mark: right camshaft holder (Holder C)

Apply engine oil to the threads and seating surfaces of the camshaft holder bolts.

Install the twenty holder bolts with the eight sealing washers.

Finger tighten the bolts.



First gradually tighten the four bolts (No.1 – No.2 – No.7 – No.8) in the numerical order cast on the camshaft holders.


Gradually tighten the other camshaft holder bolts until the camshaft holders lightly contact the cylinder head surface.

**NOTICE**

*Failure to tighten the camshaft holder in a crisscross pattern might cause a camshaft holder to break.*

Tighten all camshaft holder bolts in the numerical order cast on the camshaft holders.

**TORQUE: 12 N·m (1.2 kgf·m, 9 lbf·ft)**




## CYLINDER HEAD/VALVES

Remove the camshaft holders and measure the width of each plastigauge.  
The widest thickness determines the oil clearance.

**SERVICE LIMIT: 0.10 mm (0.004 in)**

When the service limits are exceeded, replace the camshaft and recheck the oil clearance.  
Replace the cylinder head and camshaft holders as a set if the clearance still exceeds the service limit.




## CYLINDER HEAD REMOVAL

Remove the engine from the frame (page 7-4).

Remove the camshafts (page 8-8).

Tilt the engine and drain the coolant from the cylinder head and cylinder.

Remove the bolts, sealing washers, cam chain tensioner lifter and gasket.




Remove the two 6 mm bolts.


Remove the ten 9 mm bolts/washers.

Remove the cylinder head.

*Loosen the 9 mm bolts in a crisscross pattern in two or three steps.*



Remove the gasket and dowel pins.







Remove the following:

- Right crankcase cover (page 9-16)
- Starter clutch (page 9-29)

Remove the torx bolt, washer, cam chain guide and pivot collar.  
Remove the pivot bolt, cam chain tensioner and washer.




Remove the cam chain and timing sprocket from the crankshaft.



## **CYLINDER HEAD DISASSEMBLY**

Remove the cylinder head (page 8-12).  
Remove the spark plugs from the cylinder head.  
Remove the bolt and water hose joint from the cylinder head.  
Remove the O-ring from the water hose joint.




Install the tappet hole protector into the valve lifter bore.

**TOOL:**


**Tappet hole protector**

**07HMG-MR70002**



## CYLINDER HEAD/VALVES

An equivalent tool can easily be made from a plastic 35 mm film container as shown.



To prevent loss of tension, do not compress the valve springs more than necessary to remove the cotters.


Remove the valve spring cotters using the special tools as shown.

### TOOLS:

Valve spring compressor  
Valve spring compressor attachment

07757-001000


07959-KM30101



Mark all parts during disassembly so they can be placed back in their original locations.

Remove the following:

- Spring retainer
- Valve spring
- Valve
- Stem seal
- Valve spring seat




## CYLINDER HEAD INSPECTION

### CYLINDER HEAD


Avoid damaging the gasket surface.

Remove carbon deposits from the combustion chambers. Check the spark plug hole and valve areas for cracks.



Check the cylinder head for warpage with a straight edge and feeler gauge.

**SERVICE LIMIT: 0.10 mm (0.004 in)**




### VALVE LIFTER BORE

Inspect each valve lifter bore for scratches or abnormal wear.

Measure the each valve lifter bore I.D.

**SERVICE LIMIT: 26.04 mm (1.025 in)**




### VALVE LIFTER

Inspect each valve lifter for scratches or abnormal wear.

Measure the each valve lifter O.D.

**SERVICE LIMIT: 25.97 mm (1.022 in)**




### VALVE SPRING

Measure the free length of the valve springs.

**SERVICE LIMITS:**

**IN/EX: 38.7 mm (1.52 in)**

Replace the springs if they are shorter than the service limits.



## VALVE/VALVE GUIDE


Check that the valve moves smoothly in the guide. Inspect each valve for bending, burning or abnormal stem wear.

Measure and record each valve stem O.D.

### SERVICE LIMITS:

**IN:** 4.465 mm (0.1758 in)


**EX:** 4.455 mm (0.1754 in)



Ream the guides to remove any carbon deposits before checking clearances. Insert the reamer from the combustion chamber side of the cylinder head and always rotate the reamer clockwise.

### TOOL:

**Valve guide reamer, 4.5 mm      07HMH-ML00101**



Measure and record each valve guide I.D.


**SERVICE LIMIT: IN/EX: 4.540 mm (0.1787 in)**

Subtract each valve stem O.D. from the corresponding guide I.D. to obtain the stem-to-guide clearance.

### SERVICE LIMITS:

**IN:** 0.075 mm (0.0030 in)

**EX:** 0.085 mm (0.0033 in)




If the stem-to-guide clearance is out of standard, determine if a new guide with standard dimensions would bring the clearance within tolerance. If so, replace any guides as necessary and ream to fit. If the stem-to-guide clearance exceeds the service limit with the new guides, replace the valves and guides.

## CAM CHAIN TENSIONER/CAM CHAIN GUIDE

Inspect the cam chain tensioner and cam chain guide for excessive wear or damage, replace them if necessary.

CAM CHAIN TENSIONER




CAM CHAIN GUIDE

*Reface the valve seats whenever the valve guides are replaced (page 8-19).*

Inspect the cam chain guide B for excessive wear or damage, replace it if necessary.

CAM CHAIN GUIDE B




### CAM CHAIN TENSIONER LIFTER

Check the cam chain tensioner lifter operation as follows.

The tensioner shaft should not go into the body when it is pushed.

When it is turned clockwise with the cam chain tensioner holder or a screwdriver, the tensioner shaft should be pulled into the body. The shaft springs out of the body as soon as the stopper tool is released.



### VALVE GUIDE REPLACEMENT

Chill the replacement valve guides in the freezer section of a refrigerator for about an hour.

*Do not use a torch to heat the cylinder head; it may cause warping.*

Heat the cylinder head to 100 – 150°C (212 – 300°F) with a hot plate or oven.


To avoid burns, wear heavy gloves when handling the heated cylinder head.

Support the cylinder head and drive out the valve guides from combustion chamber side of the cylinder head.

**TOOL:**

Valve guide driver

07HMD-ML00101



## CYLINDER HEAD/VALVES

Drive in the guides to the specified depth from the top of the cylinder head.



**TOOL:**

**Valve guide driver**                      **07743-0020000**

**SPECIFIED DEPTH:**

**IN/EX: 16.0 – 16.3 mm (0.63 – 0.64 in)**

Let the cylinder head cool to room temperature.




*Use cutting oil on the reamer during this operation.*

Ream the new valve guides after installation. Insert the reamer from the combustion chamber side of the head and also always rotate the reamer clockwise.

**TOOL:**


**Valve guide reamer, 4.5 mm**            **07HMH-ML00101**

Clean the cylinder head thoroughly to remove any metal particles.  
Reface the valve seat (page 8-19).



## VALVE SEAT INSPECTION/REFACING

Clean the intake and exhaust valves thoroughly to remove carbon deposits.  
Apply a light coating of Prussian Blue to the valve seats.  
Tap the valves and seats using a rubber hose or other hand-lapping tool.



Remove the valve and inspect the valve seat face. The valve seat contact should be within the specified width and even all around the circumference.


**STANDARD:**

**IN/EX: 0.90 – 1.10 mm (0.035 – 0.043 in)**

**SERVICE LIMIT:**


**IN/EX: 1.5 mm (0.06 in)**

If the seat width is not within specification, reface the valve seat (page 8-19).




Inspect the valve seat face for:

- Uneven seat width:
  - Replace the valve and reface the valve seat.
- Damaged face:
  - Replace the valve and reface the valve seat.



*The valves cannot be ground. If a valve face is burned or badly worn or if it contacts the seat unevenly, replace the valve.*

- Contact area (too high or too low)
  - Reface the valve seat.




**VALVE SEAT REFACING**

*Follow the refacing manufacturer's operating instructions.*

Valve seat cutters/grinders or equivalent valve seat refacing equipment are recommended to correct worn valve seats.


**VALVE SEAT CUTTERS:**



## CYLINDER HEAD/VALVES

If the contact area is too high on the valve, the seat must be lowered using a 32-degree flat cutter.

If the contact area is too low on the valve, the seat must be raised using a 60-degree interior cutter.



*Reface the seat with a 45-degree cutter whenever a valve guide is replaced.*

Use a 45-degree cutter to remove any roughness or irregularities from the seat.


**TOOLS:**

**Seat cutter, 29 mm (IN) 07780-0010300**

**Seat cutter, 27.5 mm (EX) 07780-0010200**

**Cutter holder, 4.5 mm 07781-0010600**

**or equivalent commercially available**



Use a 32-degree cutter to remove the top 1/4 of the existing valve seat material.


**TOOLS:**

**Flat cutter, 30 mm (IN) 07780-0012200**

**Flat cutter, 27 mm (EX) 07780-0013300**

**Cutter holder 07781-0010600**

**or equivalent commercially available**




Use a 60-degree cutter to remove the bottom 1/4 of the old seat.

**TOOLS:**

**Interior cutter, 30 mm (IN/EX) 07780-0014000**


**Cutter holder 07781-0010600**

**or equivalent commercially available**






Using a 45-degree seat cutter, cut the seat to the proper width.  
 Make sure that all pitting and irregularities are removed.  
 Refinish if necessary.



After cutting the seat, apply lapping compound to the valve face, and lap the valve using light pressure.


- Excessive lapping pressure may deform or damage the seat.
- Change the angle of lapping tool frequently to prevent uneven seat wear.
- Do not allow lapping compound to enter the guides.

After lapping, wash all residual compound off the cylinder head and valve.



HAND-LAPPING TOOL

## CYLINDER HEAD ASSEMBLY



## CYLINDER HEAD/VALVES


Blow through all oil passages in the cylinder head with compressed air.

Install the tappet hole protector into the valve lifter bore.

**TOOL:**


Tappet hole protector

**07HMG-MR70002 or refer to page 8-14 for alternative tool**



Install the valve spring seats.  
Install the new stem seals.

Lubricate the valve stems with molybdenum oil solution.  
Insert the valve into the valve guide while turning it slowly to avoid damage to the stem seal.



Install the valve springs with the tightly wound coils facing the combustion chamber.

Install the valve spring retainer.



COMBUSTION CHAMBER SIDE

*Grease the cotters to ease installation.*

Install the valve cotters using the special tools as shown.

**NOTE:**

To prevent loss of tension, do not compress the valve spring more than necessary.


**TOOLS:**

Valve spring compressor

**07757-0010000**

Valve spring compressor attachment

**07959-KM30101**




*Support the cylinder head above the work bench surface to prevent possible valve damage.*


Tap the valve stems gently with plastic hammers and pin driver as shown to seat the cotters firmly.

Install and tighten the spark plugs.

**TORQUE: 16 N·m (1.6 kgf·m, 12 lbf·ft)**




Install the new O-ring onto the water hose joint. Install the water hose joint to the cylinder head and tighten the bolt securely.




## CYLINDER HEAD INSTALLATION

Install the timing sprocket by aligning the wide teeth between the crankshaft and timing sprocket.




Install the cam chain to the timing sprocket.




## CYLINDER HEAD/VALVES

Apply a locking agent to the cam chain guide torx bolt threads.  
Install the pivot collar, cam chain guide, washer and torx bolt.



Apply a locking agent to the cam chain tensioner socket bolt threads.  
Install the washer, cam chain tensioner and pivot bolt.



Tighten the cam chain guide torx bolt to the specified torque.


**TORQUE: 12 N·m (1.2 kgf·m, 9 lbf·ft)**

Tighten the cam chain tensioner pivot bolt to the specified torque.


**TORQUE: 10 N·m (1.0 kgf·m, 7 lbf·ft)**

Install the following:

- Starter clutch (page 9-33)
- Right crankcase cover (page 9-34)



Install the dowel pins and a new cylinder head gasket as shown.




Apply molybdenum disulfide oil solution to the threads and seating surface of the 9 mm bolts/washers and install them.

Install the two 6 mm flange bolts.

Tighten the 9 mm bolts in a crisscross pattern in two or three steps to the specified torque.

**TORQUE: 51 N·m (5.2 kgf·m, 38 lbf·ft)**

Tighten the 6 mm flange bolts securely.




Retract the cam chain tensioner lifter shaft and secure it using the cam chain tensioner holder.

**TOOL:**

**Cam chain tensioner holder 070MG-0010100**

*Point the gasket tab as shown.*

Install a new gasket onto the cam chain tensioner lifter.




*Make sure the gasket tab is in the direction as shown.*

Install the cam chain tensioner lifter onto the cylinder head with new gasket.

Install the mounting bolts with the new sealing washers.

Tighten the mounting bolts securely.

Install the engine into the frame (page 7-8).




## CAMSHAFT INSTALLATION

Apply molybdenum oil solution to the outer surface of the each valve lifter.

*Install the shims and valve lifters in their original locations.*


Install the shims on the retainers and valve lifters into the valve lifter bores.



## CYLINDER HEAD/VALVES


The each camshaft has identification mark.

- IN: Intake camshaft
- EX: Exhaust camshaft




If the cam sprockets are removed, install the cam sprockets onto the camshafts.


- Install the intake cam sprocket with the timing mark (IN) facing outward and the No.1 cam lobes facing up and out as shown.
- Install the exhaust cam sprocket with the timing mark (EX) facing outward and the No.1 cam lobes facing up and out as shown.




Clean the cam sprocket bolt threads and apply a locking agent.  
Install the cam sprockets and bolts.



Turn the crankshaft clockwise and align the "T" mark on the starter clutch outer with the index notch on the right crankcase cover.




Apply molybdenum oil solution to the camshaft journal of the cylinder head.




Install the cam chain over the cam sprockets and then install the intake and exhaust camshafts.

- Install each camshaft to the correct locations with the identification marks.  
 "IN": Intake camshaft  
 "EX": Exhaust camshaft




- Make sure that the timing marks on the cam sprockets are facing outward and flush with the cylinder head upper surface as shown.



Coat new O-rings with clean engine oil and install them into the grooves in the camshaft holders.


Apply molybdenum oil solution to the camshaft journals of the camshaft holders.



## CYLINDER HEAD/VALVES

Note the correct locations with the identification marks as shown.

- "R" mark: center camshaft holder (Holder A)
- "L" mark: left camshaft holder (Holder B)
- No mark: right camshaft holder (Holder C)




*Be sure to align the dowel pins in the camshaft holder with the holes in the cylinder head.*

Install each camshaft holder onto the camshafts.

Apply engine oil to the threads and seating surfaces of the camshaft holder bolts.

Install the twenty holder bolts with new eight sealing washers as shown.

Finger tighten the bolts.



First gradually tighten the four bolts (No.1 – No.2 – No.7 – No.8) in the numerical order cast on the camshaft holders.

Gradually tighten the other camshaft holder bolts until the camshaft holders lightly contact the cylinder head surface.

### NOTICE



*Failure to tighten the camshaft holder in a crisscross pattern might cause a camshaft holder to break.*

Tighten all camshaft holder bolts in the numerical order cast on the camshaft holders.

**TORQUE: 12 N·m (1.2 kgf·m, 9 lbf·ft)**

In case the cam sprockets were removed, apply a locking agent to the cam sprocket bolt threads. Tighten the cam sprocket bolts to the specified torque.


**TORQUE: 20 N·m (2.0 kgf·m, 15 lbf·ft)**






Turn the crankshaft clockwise one full turn (360°) and tighten the other cam sprocket bolts to the specified torque.


**TORQUE: 20 N·m (2.0 kgf·m, 15 lbf·ft)**



Install the cam chain guide B, and tighten the bolts securely.




Remove the special tool from the cam chain tensioner lifter.



Install a new sealing washer and tighten the sealing bolt.


Recheck the valve timing.

Install the cylinder head cover (page 8-31).




# CYLINDER HEAD COVER ASSEMBLY

Install the PAIR check valve port plates into the cylinder head cover.




Install the PAIR check valves into the cylinder head cover.




Apply a locking agent to the PAIR check valve cover mounting bolt threads.

Install the PAIR check valve cover and tighten the bolts to the specified torque.

**TORQUE: 12 N·m (1.2 kgf·m, 9 lbf·ft)**




Install the new cylinder head cover packing into the cylinder head cover grooves.




## CYLINDER HEAD COVER INSTALLATION

Apply sealant to the cylinder head semi-circular cut-outs as shown.



Install the cylinder head cover onto the cylinder head.


Install the washers to the cylinder head cover with their "UP" mark facing up.



Install and tighten the cylinder head cover bolts to the specified torque.

**TORQUE: 10 N·m (1.0 kgf·m, 7 lbf·ft)**

CYLINDER HEAD COVER



Connect the crankcase breather hose to the cylinder head cover.

Install the PAIR control solenoid valve and connect the air suction hoses (page 5-104).


Connect the spark plug caps (page 3-8).

Install the fuel tank (page 5-61).

If the cylinder head was removed, perform as follows:

- Fill and bleed the cooling system (page 6-6)
- Fill the crankcase with engine oil (page 3-16)

PAIR AIR SUCTION HOSES



---


**MEMO**


# 9. CLUTCH/STARTER CLUTCH

---

COMPONENT LOCATION .....	9-2	CLUTCH SLAVE CYLINDER .....	9-14
SERVICE INFORMATION .....	9-4	RIGHT CRANKCASE COVER REMOVAL .....	9-16
TROUBLESHOOTING .....	9-5	CLUTCH .....	9-18
CLUTCH FLUID REPLACEMENT/AIR BLEEDING .....	9-6	STARTER CLUTCH .....	9-29
CLUTCH MASTER CYLINDER .....	9-8	RIGHT CRANKCASE COVER INSTALLATION .....	9-34

**COMPONENT LOCATION**





## CLUTCH/STARTER CLUTCH

### SERVICE INFORMATION

#### GENERAL

##### NOTICE

Spilled fluid will severely damage instrument lenses and painted surfaces, It is also harmful to some rubber parts. Be careful whenever you remove the reservoir cap; make sure the reservoir is horizontal first.

- This section covers service of the clutch and starter clutch. All service can be done with the engine installed in the frame.
- Engine oil viscosity and level have an effect on clutch disengagement. When the clutch does not disengage or the motorcycle creeps with clutch disengaged, inspect the engine oil level before servicing the clutch system.

#### SPECIFICATIONS

Unit: mm (in)




ITEM		STANDARD	SERVICE LIMIT
Specified clutch fluid		DOT 4 brake fluid	-
Clutch master cylinder	Master cylinder I.D.	12.700 – 12.743 (0.5000 – 0.5017)	12.755 (0.5022)
	Master piston O.D.	12.657 – 12.684 (0.4983 – 0.4994)	12.645 (0.4978)
Clutch	Spring free length	58.2 (2.29)	55.7 (2.19)
	Disc A thickness	3.72 – 3.88 (0.146 – 0.153)	3.4 (0.13)
	Disc B thickness	3.22 – 3.38 (0.127 – 0.133)	2.9 (0.11)
	Plate warpage	-	0.30 (0.012)
Clutch outer guide A (Without ID mark)	I.D.	27.993 – 28.003 (1.1021 – 1.1025)	28.012 (1.1028)
	O.D.	35.004 – 35.012 (1.3781 – 1.3784)	34.994 (1.3777)
Clutch outer guide B (With ID mark)	I.D.	27.993 – 28.003 (1.1021 – 1.1025)	28.012 (1.1028)
	O.D.	34.996 – 35.004 (1.3778 – 1.3781)	34.986 (1.3774)
Primary driven gear I.D.	A	41.008 – 41.016 (1.6145 – 1.6148)	41.026 (1.6152)
	B	41.000 – 41.008 (1.6142 – 1.6145)	41.018 (1.6149)
Oil pump drive sprocket guide	I.D.	28.000 – 28.021 (1.1024 – 1.1032)	28.030 (1.1035)
	O.D.	34.975 – 34.991 (1.3770 – 1.3776)	34.965 (1.3766)
Oil pump drive sprocket I.D.		35.025 – 35.145 (1.3789 – 1.3837)	35.155 (1.3841)
Mainshaft O.D. at clutch outer guide		27.980 – 27.990 (1.1016 – 1.1020)	27.96 (1.101)
Mainshaft O.D. at oil pump drive sprocket guide		27.980 – 27.990 (1.1016 – 1.1020)	27.96 (1.101)
Starter idle gear	Gear I.D.	10.013 – 10.035 (0.3942 – 0.3951)	10.05 (0.396)
	Shaft O.D.	9.991 – 10.000 (0.3933 – 0.3937)	9.98 (0.393)
Starter driven gear boss O.D.		45.657 – 45.673 (1.7975 – 1.7981)	45.642 (1.7969)

#### TORQUE VALUES

Clutch center lock nut	128 N·m (13.1 kgf·m, 94 lbf·ft)	Apply engine oil to the threads and seating surface. Stake the nut.
Clutch spring bolt	12 N·m (1.2 kgf·m, 9 lbf·ft)	
Oil pump driven sprocket bolt	15 N·m (1.5 kgf·m, 11 lbf·ft)	Apply a locking agent to the threads.
Right crankcase cover rubber damper set plate bolt	12 N·m (1.2 kgf·m, 9 lbf·ft)	Apply a locking agent to the threads. CT bolt
Starter clutch outer special bolt	83 N·m (8.5 kgf·m, 61 lbf·ft)	Apply engine oil to the threads and seating surface.
Clutch lever pivot bolt	1.0 N·m (0.1 kgf·m, 0.7 lbf·ft)	Apply silicone grease to the sliding surface.
Clutch lever pivot nut	5.9 N·m (0.6 kgf·m, 4.4 lbf·ft)	
Clutch master cylinder holder bolt	12 N·m (1.2 kgf·m, 9 lbf·ft)	
Clutch master cylinder oil cup mounting screw	1.5 N·m (0.15 kgf·m, 1.1 lbf·ft)	Apply a locking agent to the threads.
Clutch master cylinder oil cup stopper plate screw	1.2 N·m (0.1 kgf·m, 0.9 lbf·ft)	
Clutch switch mounting screw	1.2 N·m (0.1 kgf·m, 0.9 lbf·ft)	
Clutch hose oil bolt	34 N·m (3.5 kgf·m, 25 lbf·ft)	



## TOOLS

<p>Snap ring pliers 07914-SA50001</p> 	<p>Clutch center holder 07724-0050002</p>  <p>or equivalent commercially available.</p>	<p>Gear holder, M2.5 07724-0010100</p> 
---	---	--

## TROUBLESHOOTING

**Clutch lever soft or spongy**

- Air in hydraulic system
- Low fluid level
- Hydraulic system leaking

**Clutch lever too hard to pull in**

- Sticking master cylinder piston
- Sticking slave cylinder
- Clogged hydraulic system
- Damaged clutch lifter mechanism
- Faulty clutch lifter bearing
- Clutch lifter piece installed improperly

**Clutch slips when accelerating**

- Hydraulic system sticking
- Worn clutch disc
- Weak clutch springs
- Transmission oil mixed with molybdenum or graphite additive

**Clutch will not disengage or motorcycle creeps with clutch disengaged**

- Air in hydraulic system
- Low fluid level
- Hydraulic system leaking or clogged
- Clutch plate warped
- Loose clutch lock nut
- Oil level too high
- Improper oil viscosity
- Damaged clutch lifter mechanism
- Clutch lifter piece installed improperly

**Hard to shift**

- Improper clutch operation
- Improper oil viscosity


## CLUTCH/STARTER CLUTCH

# CLUTCH FLUID REPLACEMENT/AIR BLEEDING


### CLUTCH FLUID DRAINING

Turn the handlebar to the right until the reservoir is parallel to the ground, before removing the reservoir cap.

Remove the screw and stopper plate. Remove the reservoir cap, set plate, diaphragm and float.



Connect a bleed hose to the bleed valve of the clutch slave cylinder. Loosen the bleed valve and pump the clutch lever until fluid stops flowing out of the bleed valve.



### CLUTCH FLUID FILLING/AIR BLEEDING


Fill the reservoir with DOT 4 brake fluid from a sealed container.

Connect a commercially available brake bleeder to the bleed valve.

Operate the brake bleeder and loosen the bleed valve.

Add brake fluid when the fluid level in the reservoir is low.

- Check the fluid level often while bleeding the clutch to prevent air from being pumped into the system.
- When using a brake bleeding tool, follow the manufacturer's operating instruction.




*If air is entering the bleeder from around the bleed valve threads, seal the threads with teflon tape.*

Repeat the above procedures until new fluid flows out of the bleed valve and air bubbles do not appear in the plastic hose.

Close the bleed valve and operate the clutch lever. If it is still spongy, bleed the system again.

**BRAKE BLEEDER**




If a brake bleeder is not available, use the following procedure.

Pump the clutch lever until lever resistance is felt.

Connect a bleed hose to the bleed valve and bleed the system as follows:


1. Squeeze the clutch lever, open the bleed valve 1/4 of a turn and then close it. Do not release the clutch lever until the bleed valve has been closed.
2. Release the clutch lever slowly and wait several seconds after it reaches the end of its travel.



Repeat steps 1. and 2. until air bubbles do not appear in the bleed hose.

Tighten the bleed valve securely.

**BLEED VALVE**




Fill the reservoir to the upper level line with DOT 4 brake fluid from a sealed container.

Install the float, diaphragm and set plate.

**UPPER LEVEL LINE**

**SET PLATE**



**FLOAT/DIAPHRAGM**


## CLUTCH/STARTER CLUTCH

Install and tighten the reservoir cap.

Install the stopper plate and tighten the screw to the specified torque.

**TORQUE: 1.2 N·m (0.1 kgf·m, 0.9 lbf·ft)**

Check the clutch operation (page 3-30).



## CLUTCH MASTER CYLINDER

### REMOVAL


#### NOTICE

*Spilled fluid can damage painted, plastic, or rubber parts. Place a rag over these parts whenever the system is serviced.*


Drain the clutch hydraulic system (page 9-6).

Disconnect the clutch switch wire connectors.

Remove the clutch hose oil bolt, sealing washers and clutch hose eyelet.




Remove the bolts, master cylinder holder and master cylinder assembly.




**DISASSEMBLY**


Remove the nut, pivot bolt and clutch lever assembly.




Remove the screw and clutch switch.



Remove the screw and oil cup and O-rings from the master cylinder body.



Remove the boot and push rod.




## CLUTCH/STARTER CLUTCH

Remove the snap ring from the master cylinder body using the special tool as shown.


**TOOL:**

**Snap ring pliers**

**07914-SA50001**



Remove the master piston assembly and spring.  
Clean the inside of the master cylinder with brake fluid.



### INSPECTION


Check the piston boot, primary cup and secondary cup for fatigue or damage.  
Check the master cylinder and piston for abnormal scratches.

Measure the master cylinder I.D.


**SERVICE LIMIT: 12.755 mm (0.5022 in)**

Measure the master piston O.D.

**SERVICE LIMIT: 12.645 mm (0.4978 in)**



ASSEMBLY




Coat all parts with clean brake fluid before assembly.  
Dip the piston in brake fluid.

*When installing the cups, do not allow the lips to turn inside out.*

Install the primary and secondary cups onto the master piston.

Install the spring and master piston assembly into the master cylinder.




*Be certain the snap ring is firmly seated in the groove.*

Install the snap ring using the special tool.

**TOOL:**  
Snap ring pliers


07914-SA50001



## CLUTCH/STARTER CLUTCH

Apply clean brake fluid to new O-rings and install them oil cup and master cylinder body grooves.


Install the oil cup onto the master cylinder body.



Clear and apply locking agent to the oil cup mounting screw threads.


Install and tighten the oil cup mounting screw to the specified torque.

**TORQUE: 1.5 N·m (0.15 kgf·m, 1.1 lbf·ft)**




Apply silicone grease to the boot inside and tip of the push rod.

PUSH ROD



Install the clutch switch and tighten the screw to the specified torque.


**TORQUE: 1.2 N·m (0.1 kgf·m, 0.9 lbf·ft)**





Set the push rod in the joint piece hole. Apply silicone grease to the tip of the push rod, then install the joint piece and clutch lever assembly.

CLUTCH LEVER ASSEMBLY



Apply silicone grease to the clutch lever pivot bolt sliding surface.


Install and tighten the pivot bolt to the specified torque.

**TORQUE: 1.0 N·m (0.1 kgf·m, 0.7 lbf·ft)**

Hold the pivot bolt and tighten the nut to the specified torque.

**TORQUE: 5.9 N·m (0.6 kgf·m, 4.4 lbf·ft)**

PIVOT BOLT



PIVOT NUT

CLUTCH LEVER

## INSTALLATION

*Install the master cylinder holder with the "UP" mark facing up.*

Place the master cylinder assembly onto the handlebar and install the holder and bolts.


Align the end of the master cylinder with the punch mark on the handlebar.

Tighten the upper bolt first, then the lower bolt.

**TORQUE: 12 N·m (1.2 kgf·m, 9 lbf·ft)**

HOLDER

MASTER CYLINDER



PUNCH MARK

BOLTS

Install the clutch hose eyelet with the oil bolt and new sealing washers.


While pushing the clutch hose against the stopper, tighten the oil bolt to the specified torque.

**TORQUE: 34 N·m (3.5 kgf·m, 25 lbf·ft)**

Connect the clutch switch connectors.

Fill the reservoir to the upper level and bleed the hydraulic system (page 9-6).

SEALING WASHERS



OIL BOLT

CONNECTORS

# CLUTCH SLAVE CYLINDER

## REMOVAL


Drain the clutch hydraulic system (page 9-6).

*Avoid spilling fluid on painted, plastic, or rubber parts.*


*Place a rag over these parts whenever the system is serviced.*

Remove the clutch hose oil bolt, sealing washers and clutch hose eyelet.

Remove the bolts and clutch slave cylinder assembly.



Remove the gasket and dowel pins.



## DISASSEMBLY


Place a shop towel over the piston to cushion the piston when it is expelled, and position the cylinder with the piston down.

*Do not use high pressure air or bring the nozzle too close to the inlet.*

Apply small squirts of air pressure to the fluid inlet to remove the piston.




Remove the piston and spring from the slave cylinder.




**INSPECTION**

Check the piston spring for weakness or damage.  
 Inspect the oil seal and O-rings for damage or deterioration, replace if necessary.  
 Clean the O-ring grooves with clean brake fluid.


Check the slave cylinder for scoring or other damage.  
 Check the piston for scratches, scoring or other damage.



**ASSEMBLY**




Lubricate the piston with clean brake fluid.  
 Apply grease (included in the slave cylinder O-ring set) to new O-rings and install them to the slave cylinder piston grooves.  
 Install the spring into the boss of the piston.  
 Install the spring and piston into the slave cylinder.  
 Lubricate the oil seal with brake fluid and install the spring into the boss of the piston.



## CLUTCH/STARTER CLUTCH

### INSTALLATION

Install the dowel pins and new gasket.  
Apply silicone grease to the tip of the lifter rod.



Install the slave cylinder onto the left crankcase rear cover.


Install and tighten the bolts securely.

Install the clutch hose eyelet with the oil bolt and new sealing washers.

While pushing the clutch hose against the stopper, tighten the oil bolt to the specified torque.

**TORQUE: 34 N·m (3.5 kgf·m, 25 lbf·ft)**

Fill the reservoir to the upper level and bleed the hydraulic system (page 9-6).




## RIGHT CRANKCASE COVER REMOVAL


Drain the engine oil (page 3-16).

*Be careful not to drop the thrust and wave washers into the crankcase.*

Remove the bolts and right crankcase cover.




Remove the bolt/washer.  
Remove the wire grommet from the cover.  
Remove the bolts and CKP sensor.




*Do not turn the crankshaft counterclockwise after removing the right crankcase cover to prevent the starter reduction gear from damage.*

Remove the dowel pins.

Clean off any sealant from the right crankcase cover mating surfaces.




Remove the thrust washer and wave washer from the starter idle gear shaft.




## RUBBER DAMPER REMOVAL/INSTALLATION

Remove the bolt and set plate.



Remove the rubber damper.

Check the rubber damper for fatigue or damage, replace it if necessary.




## CLUTCH/STARTER CLUTCH

Install the rubber damper into the right crankcase cover and install the set plate.

Clean and apply a locking agent to the set plate bolt threads and install the set plate bolt. Tighten the bolt to the specified torque.

**TORQUE: 12 N·m (1.2 kgf·m, 9 lbf·ft)**




## CLUTCH

### REMOVAL


Remove the right crankcase cover (page 9-16).

To prevent damaging the starter reduction gear shaft, remove the starter idle gear and shaft from the crankcase.




Loosen the clutch spring bolts in a crisscross pattern in two to three steps, then remove the clutch spring bolts and clutch springs.

Remove the pressure plate.




Remove the clutch lifter piece and lifter rod.




Remove the following:

- Two clutch disc A
- Six clutch disc B
- Six clutch plates A
- Clutch plates B
- Judder spring
- Spring seat



Unstake the clutch center lock nut.




Hold the clutch center with the special tool and remove the clutch center lock nut.

**TOOL:**


**Clutch center holder**

**07724-0050002 or  
equivalent commercially  
available**

Discard the lock nut.




Remove the lock washer, thrust washer and clutch center.




# CLUTCH/STARTER CLUTCH


Remove the thrust washer.



Pull out the clutch outer guide, then remove the needle bearing.



Remove the clutch outer.




*To gain access to the oil pump driven sprocket, first remove the oil pan.*

Remove the oil pump driven sprocket bolt/washer.

Remove the oil pump drive and driven sprocket with the drive chain.

*Be careful not to drop the sprocket bolt/washer in the crankcase.*

Remove the oil pump drive sprocket guide from the mainshaft.






## INSPECTION

### Clutch lifter bearing

Turn the inner race of the lifter bearing with your finger.  
The bearing should turn smoothly and freely without excessive play.  
If necessary, replace the bearing.

LIFTER BEARING




### Clutch spring

*Replace the clutch springs as a set.*


Measure the clutch spring free length.

**SERVICE LIMIT: 55.7 mm (2.19 in)**



### Clutch center

Check the grooves of the clutch center for damage or wear caused by the clutch plates.  
Replace it if necessary.



### Clutch lifter piece


Check the clutch lifter piece for damage or abnormal wear.



## CLUTCH/STARTER CLUTCH

### Clutch lifter rod

Check the clutch lifter rod for bend or other damage.



### Clutch disc

*Replace the clutch discs and plates as a set.*


Replace the clutch discs if they show signs of scoring or discoloration.

Measure the disc thickness of each disc.

#### SERVICE LIMITS:

A (larger I.D.): 3.4 mm (0.13 in)

B: 2.9 mm (0.11 in)



### Clutch plate

*Replace the clutch discs and plates as a set.*

Check the plates for discoloration.

Check the plate warpage on a surface plate using a feeler gauge.


**SERVICE LIMIT: 0.30 mm (0.012 in)**



### Judder spring/spring seat

Check the judder spring and spring seat for deformation, warpage or damage; replace as necessary.

- A damaged or warped spring seat will cause the judder spring to be pressed unevenly.
- A damaged judder spring also causes the weak contact between the discs and plates or uneven disc/plate contact.



## Clutch outer/primary driven gear

Check the slots of the clutch outer for damage or wear caused by the clutch discs.

Check the primary driven gear for abnormal wear or damage.

Measure the I.D. of the primary driven gear.

### SERVICE LIMITS:

A: 41.026 mm (1.6152 in)

B: 41.018 mm (1.6149 in)

Replace the clutch outer assembly if necessary.

When the clutch outer assembly is replaced, be sure to select the needle bearing according to the selective fit table (page 9-24).

## Clutch outer guide/needle bearing

Measure the O.D. and I.D. of the clutch outer guide.

– I.D. mark indication of guide A or B (page 9-24)

### SERVICE LIMITS:

A (without ID mark):

O.D.: 34.994 mm (1.3777 in)

I.D.: 28.012 mm (1.1028 in)

B (with ID mark):

O.D.: 34.986 mm (1.3774 in)

I.D.: 28.012 mm (1.1028 in)



Check the needle bearing for wear or damage.

Replace the bearing if necessary.


When the clutch outer guide and/or needle bearing is replaced, be sure to select the needle bearing according to the selective fit table (page 9-24).

CLUTCH OUTER

PRIMARY DRIVEN GEAR



NEEDLE BEARING



## Oil pump drive sprocket/sprocket guide

Measure the O.D. and I.D. of the oil pump drive sprocket guide.


### SERVICE LIMITS:

O.D.: 34.965 mm (1.3766 in)

I.D.: 28.030 mm (1.1035 in)

Measure the I.D. of the oil pump drive sprocket.

SERVICE LIMIT: 35.155 mm (1.3841 in)



# CLUTCH/STARTER CLUTCH

## Mainshaft


Measure the mainshaft O.D. at clutch outer guide and oil pump drive sprocket guide sliding surfaces.

### SERVICE LIMITS:

**Oil pump drive sprocket**


**guide position:** 27.96 mm (1.101 in)

**Clutch outer guide position:** 27.96 mm (1.101 in)



## NEEDLE BEARING SELECTION

The primary driven gear has I.D. code letter as shown.




I.D. CODE LETTER

The clutch outer guide A has no identification mark and outer guide B has identification mark (2 mm hole).


Cross-reference the primary driven gear and clutch outer guide codes to determine the replacement needle bearing color.

Refer to the selection table below for bearing selection.

MARK PORTION




IDENTIFICATION COLOR




### NEEDLE BEARING SELECTION TABLE:

			CLUTCH OUTER GUIDE ID MARK	
			GUIDE A (Without ID mark)	GUIDE B (With ID mark)
			35.004 – 35.012 mm (1.3781 – 1.3784 in)	34.996 – 35.004 mm (1.3778 – 1.3781 in)
PRIMARY DRIVEN GEAR I.D. MARK	A	41.008 – 41.016 mm (1.6145 – 1.6148 in)	NEEDLE BEARING B (White)	NEEDLE BEARING A (Red)
	B	41.000 – 41.008 mm (1.6142 – 1.6145 in)	NEEDLE BEARING C (Purple)	NEEDLE BEARING B (White)

INSTALLATION



Install the oil pump drive sprocket guide.



## CLUTCH/STARTER CLUTCH


*Install the oil pump driven sprocket with its "OUT" mark facing out.*

Install the oil pump drive and driven sprocket with the drive chain.

Apply a locking agent to the threads of the oil pump driven sprocket bolt.


Install the oil pump driven sprocket bolt/washer and tighten the bolt to the specified torque.

**TORQUE: 15 N·m (1.5 kgf·m, 11 lbf·ft)**



Apply molybdenum oil solution to the clutch outer sliding surface.

Install the clutch outer while aligning the bosses on the oil pump drive sprocket with holes in the clutch outer.




Apply molybdenum oil solution to the clutch outer guide sliding surface.


*Install the clutch outer guide with its grooves facing out.*

Install the clutch outer guide and needle bearing onto the mainshaft

Refer to the needle bearing selection (page 9-24).




Install the thrust washer.



## CLUTCH/STARTER CLUTCH

Install the clutch center and thrust washer.

Install the lock washer with its "OUT" mark facing out.



Apply engine oil to the threads and seating surface of a new clutch center lock nut, then install it onto the mainshaft.


Hold the clutch center with the special tool and tighten the lock nut to the specified torque.

**TOOL:**

**Clutch center holder**


**07724-0050002 or equivalent commercially available**

**TORQUE: 128 N·m (13.1 kgf·m, 94 lbf·ft)**



*Be careful not to damage the mainshaft threads.*

Stake the lock nut into the mainshaft groove with a punch.




## CLUTCH/STARTER CLUTCH

Install the spring seat and judder spring onto the clutch center as shown.


Coat the clutch discs and plates with clean engine oil.

*Surface treatment of clutch plate B is different from that of plate A.*


First install the clutch disc A (larger I.D. disc) onto the clutch center, and then install the clutch plate B. Stack the six clutch discs (B) and plates (A) alternately.



Install the tabs of outside clutch disc A (larger I.D. disc) into the shallow slots of the clutch outer.




Install the lifter rod and clutch lifter piece into the mainshaft.






Install the pressure plate.  
 Install the clutch springs and spring bolts.  
 Tighten the bolts in a crisscross pattern in two to three steps, then torque them in specified value.

**TORQUE: 12 N·m (1.2 kgf·m, 9 lbf·ft)**



Install the shaft and starter idle gear and shaft.  
 Install the right crankcase cover (page 9-34).




## STARTER CLUTCH

### REMOVAL

Remove the clutch (page 9-18).

Remove the starter reduction gear from the crankcase.



*Be careful not to drop the gear holder into the crankcase.*

Temporarily install the following:

- Oil pump drive sprocket guide
- Oil pump drive sprocket
- Clutch outer
- Clutch outer guide
- Needle bearing

Insert the gear holder between the primary drive and driven gear as shown.

#### TOOL:


**Gear holder, M2.5**

**07724-0010100**

Remove the starter clutch outer special bolt and washer.


Remove the temporarily installed parts.

Remove the starter clutch outer assembly.




## CLUTCH/STARTER CLUTCH

Remove the thrust washer.



### INSPECTION

Check the operation of the one-way clutch by turning the driven gear. You should be able to turn the driven gear clockwise smoothly, but the gear should not turn counterclockwise.




### DISASSEMBLY

Remove the starter driven gear while turning it clockwise.

Remove the needle bearing.


STARTER DRIVEN GEAR



Remove the snap ring and one-way clutch.

ONE-WAY CLUTCH



SNAP RING



## CLUTCH/STARTER CLUTCH

Check the starter clutch outer inner surface and one-way clutch for abnormal wear or damage, and replace them if necessary.

STARTER CLUTCH OUTER




ONE-WAY CLUTCH

Check the starter driven gear for abnormal wear or damage.


Measure the starter driven gear boss O.D.

**SERVICE LIMIT: 45.642 mm (1.7969 in)**



Check the starter reduction gear for wear or damage, and replace it if necessary.

STARTER REDUCTION GEAR




Check the starter idle gear and shaft for wear or damage.

Measure the starter idle gear I.D. and shaft O.D.

**SERVICE LIMITS:**


**Gear I.D.: 10.05 mm (0.396 in)**

**Shaft O.D.: 9.98 mm (0.393 in)**




# CLUTCH/STARTER CLUTCH

## ASSEMBLY




Apply engine oil to the one-way clutch sliding surface.  
Install the one-way clutch into the starter clutch outer with its identification mark (white paint) facing out.

IDENTIFICATION MARK ONE-WAY CLUTCH



Install the snap ring into the starter clutch outer groove securely.


ONE-WAY CLUTCH SNAP RING



Install the needle bearing onto the starter clutch outer.


STARTER DRIVEN GEAR

NEEDLE BEARING



Install the starter driven gear into the starter clutch outer while turning the starter driven gear clockwise.


Recheck the one-way clutch operation (page 9-30).




STARTER DRIVEN GEAR

## INSTALLATION

Install the thrust washer onto the crankshaft.




Install the starter clutch outer assembly onto the crankshaft while aligning its wide groove with the wide teeth of the crankshaft.



## CLUTCH/STARTER CLUTCH

Apply engine oil to the starter clutch outer special bolt threads and seating surface.

Install the washer and starter clutch outer special bolt.



Temporarily install the following:

- Oil pump drive sprocket outer guide
- Oil pump drive sprocket
- Clutch outer
- Clutch outer guide
- Clutch outer needle bearing

*Be careful not to drop the gear holder into the crankcase.* Attach the gear holder between the primary drive gear and driven gear.

**TOOL:**

**Gear holder, M2.5**

**07724-0010100**

Tighten the starter clutch special bolt to the specified torque.



**TORQUE: 83 N-m (8.5 kgf·m, 61 lbf·ft)**

Remove the temporarily installed parts.

Apply molybdenum oil solution to the starter reduction gear sliding surface.


Install the starter reduction gear into the crankcase.

Install the clutch (page 9-25).




## RIGHT CRANKCASE COVER INSTALLATION


Apply sealant (Three Bond 1207B) to the mating surface of the right crankcase cover.




Install the two dowel pins.



Install the wave washer and thrust washer onto the starter idle gear.



Install the CKP sensor and tighten the mounting bolts securely.  
Route the CKP sensor wire into the groove of the right crankcase cover.  
Apply sealant to the grommet seating surface and install the grommet into the cover groove properly.  
Install the bolt/washer to clamp the CKP sensor wire, then tighten the bolt securely.




Install the right crankcase cover while aligning the starter idle gear shaft and reduction gear shaft with the holes in the right crankcase cover, then align the dowel pins with the cover holes.

Install the right crankcase cover bolts.

Tighten the right crankcase cover bolts in a criss-cross pattern in two to three steps.

Check the clutch operation (page 3-30).

Add the recommended engine oil (page 3-16).



---

**MEMO**

---




# 10. ALTERNATOR

---

COMPONENT LOCATION .....	10-2	STATOR .....	10-7
SERVICE INFORMATION .....	10-3	FLYWHEEL .....	10-8
ALTERNATOR COVER .....	10-4		

# ALTERNATOR

## COMPONENT LOCATION



## SERVICE INFORMATION



### GENERAL

- This section covers service of the alternator stator and flywheel. All service can be done with the engine installed in the frame.
- Refer to procedures for alternator stator inspection (page 17-7).
- Refer to procedures for starter motor servicing (page 19-6).

### TORQUE VALUES

Flywheel flange bolt	103 N·m (10.5 kgf·m, 76 lbf·ft)	Apply engine oil to the threads and seating surface.
Stator mounting socket bolt	12 N·m (1.2 kgf·m, 9 lbf·ft)	

### TOOLS

<p>Flywheel holder 070MB-MELC100</p>  A circular metal flywheel holder with a central hole and a small rectangular notch on the outer edge.	<p>Rotor puller 07733-0020001</p>  A rotor puller consisting of two crossed metal rods with threaded ends and a central nut.
--	--


## ALTERNATOR

### ALTERNATOR COVER


#### REMOVAL

Remove the seat (page 2-4).

Disconnect the alternator 3P (Black) connector.




Release the alternator wire clamp.




Remove the left side cover (page 2-5).

Remove the air cleaner duct cover mounting screws and cover.




Unhook the alternator wire from the guide.



The alternator cover (stator) is magnetically attached to the flywheel, be careful during removal.


Remove the alternator cover bolts and alternator cover.

- Engine oil will run out when the alternator cover is removed. Set a clean oil pan under the engine and add the recommended oil to the specified level after installation.




Remove the dowel pins.

Clean off any sealant from the crankcase mating surfaces.




## INSTALLATION

Apply a sealant (Three Bond 1207B) to the mating surface of the alternator cover.




Install the dowel pins.



# ALTERNATOR


The alternator cover (stator) is magnetically attached to the flywheel, be careful during installation.

Install the alternator cover.  
Install and tighten the bolts securely.




Refer to the wires properly (page 1-22).


Hook the alternator wire on the guide.




Install the air cleaner duct cover and mounting screws.



Install the alternator wire clamp to the rear fender B.




Connect the alternator 3P (Black) connector.  
Install the seat (page 2-4).  
Install the left side cover (page 2-5).




## STATOR

### REMOVAL

Remove the alternator cover (page 10-4).  
Remove the flange bolt and stator wire clamp.  
Remove the alternator wire grommet from the alternator cover.  
Remove the socket bolts and stator.



### INSTALLATION



## ALTERNATOR


Install the stator into the alternator cover.

Apply sealant to the wire grommet, then install the wire grommet into the alternator cover groove securely.

Install and tighten the socket bolts to the specified torque.

**TORQUE: 12 N·m (1.2 kgf·m, 9 lbf·ft)**

Install the wire clamp and tighten the flange bolt securely.



## FLYWHEEL

### REMOVAL


Remove the alternator cover (page 10-4).

Hold the flywheel using the special tool, then loosen the flywheel bolt.

**TOOL:**

**Flywheel holder**                      **070MB-MELC100**


Remove the flywheel bolt and washer.



Remove the flywheel using the special tool.


**TOOL:**

**Rotor puller**                      **07733-0020001**



### INSTALLATION

Clean any oil from the crankshaft taper area.






Install the flywheel.

Apply oil to the flywheel bolt threads and seating surface.

Install the washer and flywheel bolt.




Hold the flywheel using the special tool, then tighten the bolt to the specified torque.

**TOOL:**

Flywheel holder                      070MB-MELC100

**TORQUE:** 103 N·m (10.5 kgf·m, 76 lbf·ft)

Install the alternator cover (page 10-5).



---

**MEMO**


---


# 11. TRANSMISSION/GEARSHIFT LINKAGE

---

COMPONENT LOCATION .....	11-2	GEARSHIFT SPINDLE .....	11-7
SERVICE INFORMATION .....	11-4	TRANSMISSION.....	11-12
TROUBLESHOOTING .....	11-6		

COMPONENT LOCATION





29 N·m (3.0 kgf·m, 21 lbf·ft)

## TRANSMISSION/GEARSHIFT LINKAGE

# SERVICE INFORMATION

## GENERAL

- This section covers the transmission and gearshift linkage service. These service can be done engine installed in the frame.

## SPECIFICATIONS











Unit: mm (in)

ITEM		STANDARD	SERVICE LIMIT	
Shift fork	I.D.	12.000 – 12.018 (0.4724 – 0.4731)	12.03 (0.474)	
	Claw thickness	5.93 – 6.00 (0.233 – 0.236)	5.9 (0.23)	
Shift fork shaft O.D.		11.957 – 11.968 (0.4707 – 0.4712)	11.95 (0.470)	
Transmission	Gear I.D.	M5, M6	31.000 – 31.025 (1.2205 – 1.2215)	31.04 (1.222)
		C1	28.000 – 28.021 (1.1024 – 1.1032)	28.04 (1.104)
		C2, C3, C4	33.000 – 33.025 (1.2992 – 1.3002)	33.04 (1.301)
	Gear busing O.D.	M5, M6	30.955 – 30.980 (1.2187 – 1.2197)	30.935 (1.2179)
		C2	32.955 – 32.980 (1.2974 – 1.2984)	32.935 (1.2967)
		C3, C4	32.950 – 32.975 (1.2972 – 1.2982)	32.930 (1.2964)
	Gear-to-bushing clearance	M5, M6	0.020 – 0.070 (0.0008 – 0.0028)	0.10 (0.004)
		C2	0.020 – 0.070 (0.0008 – 0.0028)	0.10 (0.004)
		C3, C4	0.025 – 0.075 (0.0010 – 0.0030)	0.11 (0.004)
	Gear bushing I.D.	M5	27.985 – 28.006 (1.1018 – 1.1026)	28.016 (1.1030)
		C2	29.985 – 30.006 (1.1018 – 1.1026)	30.021 (1.1819)
	Mainshaft O.D.	at M5	27.967 – 27.980 (1.1011 – 1.1016)	27.957 (1.1007)
	Countershaft O.D.	at C2	29.967 – 29.980 (1.1798 – 1.1803)	29.960 (1.1795)
	Bushing to shaft clearance	M5	0.005 – 0.039 (0.0002 – 0.0015)	0.06 (0.002)
C2		0.005 – 0.039 (0.0002 – 0.0015)	0.06 (0.002)	

## TORQUE VALUES

Transmission holder mounting bolt	29 N·m (3.0 kgf·m, 21 lbf·ft)	Apply a locking agent to the threads.
Countershaft bearing set plate bolt	12 N·m (1.2 kgf·m, 9 lbf·ft)	
Mainshaft bearing set plate bolt	12 N·m (1.2 kgf·m, 9 lbf·ft)	
Shift drum center socket bolt	23 N·m (2.3 kgf·m, 17 lbf·ft)	Apply a locking agent to the threads
Shift drum stopper arm pivot bolt	12 N·m (1.2 kgf·m, 9 lbf·ft)	Apply a locking agent to the threads.
Gearshift spindle return spring pin	23 N·m (2.3 kgf·m, 17 lbf·ft)	
Shift drum bearing setting bolt	12 N·m (1.2 kgf·m, 9 lbf·ft)	
Gearshift cam bolt	12 N·m (1.2 kgf·m, 9 lbf·ft)	Apply a locking agent to the threads.
Gearshift arm pinch bolt	20 N·m (2.0 kgf·m, 15 lbf·ft)	Aloc bolt; replace with a new one.
Drive sprocket bolt	54 N·m (5.5 kgf·m, 40 lbf·ft)	
Gearshift pedal pivot bolt	27 N·m (2.8 kgf·m, 20 lbf·ft)	

TOOLS

<p>Bearing remover handle 07936-3710100</p> 	<p>Bearing remover set, 20 mm 07936-3710600</p> 	<p>Remover weight 07741-0010201</p> 
<p>Driver 07749-0010000</p> 	<p>Attachment, 42 x 47 mm 07746-0010300</p> 	<p>Attachment, 52 x 55 mm 07746-0010400</p> 
<p>Attachment, 62 x 68 mm 07746-0010500</p> 	<p>Pilot, 20 mm 07746-0040500</p> 	<p>Pilot, 25 mm 07746-0040600</p> 
<p>Pilot, 28 mm 07746-0041100</p> 		

## **TROUBLESHOOTING**

### **Hard to shift**

- Improper clutch operation
- Incorrect engine oil weight
- Bent shift fork
- Bent shift fork shaft
- Bent shift fork claw
- Damaged shift drum cam groove
- Bent gearshift spindle

### **Transmission jumps out of gear**

- Worn gear dogs
- Worn gear shifter groove
- Bent shift fork shaft
- Broken shift drum stopper arm
- Broken shift drum stopper arm spring
- Worn or bent shift forks
- Broken gearshift spindle return spring

### **Excessive engine noise**


- Worn or damaged transmission gear
- Worn or damaged transmission bearings




## GEARSHIFT SPINDLE

### REMOVAL


Remove the pinch bolt and remove the gearshift arm from the gearshift spindle.




Remove the clutch slave cylinder (page 9-14).  
Remove the clutch lifter rod.



Remove the bolts and left crankcase rear cover.




Remove the guide plate and dowel pins.




## TRANSMISSION/GEARSHIFT LINKAGE

Loosen the axle bearing holder pinch bolt and turn the axle bearing holder using the equipped tool to make the drive chain slack fully (page 3-21).


Remove the drive sprocket bolt, washer and drive sprocket.




Remove the air cleaner housing (page 5-62).  
Remove the bolts and gearshift linkage cover.



Remove the gasket and dowel pins.




Remove the gearshift spindle and washers.




**INSPECTION**

Check the gearshift spindle for wear, damage or bending.  
Check the return spring for fatigue or damage.  
If the snap rings are removed, install them with their chamfered side facing the return spring.




Check the dust seal for damage or deterioration.  
Check the needle bearing for wear or damage.




**INSTALLATION**

Install the washers to the gearshift spindle.




Install the gearshift spindle assembly into the crankcase while aligning the spring ends with the crankcase stopper pin.



## TRANSMISSION/GEARSHIFT LINKAGE


Install a dowel pins and new gasket.



Install the gearshift linkage cover being careful not to damage the oil seal lips.

*Apply a locking agent to the threads of the bolt indicated.*


Install and tighten the linkage cover bolts securely.




Install the drive sprocket with its "ML7" mark facing out.

Install the washer and drive sprocket bolt, then tighten the drive sprocket bolt to the specified torque.


**TORQUE: 54 N·m (5.5 kgf·m, 40 lbf·ft)**




Install the dowel pins and guide plate.



Install the left crankcase rear cover and tighten the mounting bolts securely.



Install the clutch lifter rod.  
Install the clutch slave cylinder (page 9-14).




Install the gearshift arm onto the gearshift spindle, while aligning its slit with the punch mark onto the spindle.

Install and tighten the new pinch bolt to the specified torque.

**TORQUE: 20 N·m (2.0 kgf·m, 15 lbf·ft)**

Adjust the drive chain slack (page 3-21).




*Check the pivot dust seals for deterioration or damage, replace them if necessary.*

If the gearshift pedal has been removed, install the washer, gearshift pedal and pivot bolt onto the frame.

Tighten the pivot bolt to the specified torque.

**TORQUE: 27 N·m (2.8 kgf·m, 20 lbf·ft)**



## TRANSMISSION

### REMOVAL


Remove the following:

- Right crankcase cover (page 9-16)
- Clutch (page 9-18)
- Drive sprocket (page 11-7)


Remove the transmission holder mounting bolts.

*Be careful not to fall the oil orifice into the crankcase when removing the transmission holder.*

Pull out the transmission holder and transmission assembly from the crankcase.




Remove the oil orifice from the crankcase.




### DISASSEMBLY

Remove the shift fork shafts and shift forks.




Remove the mainshaft and countershaft assembly.




# TRANSMISSION/GEARSHIFT LINKAGE


Remove the pivot bolt, washer, stopper arm and return spring.




Remove the bolt and gearshift cam.



Remove the dowel pins from the shift drum.  
Remove the flange collar.




Remove the shift drum from the transmission holder.



# TRANSMISSION/GEARSHIFT LINKAGE

## INSPECTION

Disassemble the mainshaft and countershaft assembly.




Check the shift fork guide pin for abnormal wear or damage

Measure the shift fork I.D.

**SERVICE LIMIT: 12.03 mm (0.474 in)**


Measure the shift fork claw thickness.

**SERVICE LIMIT: 5.9 mm (0.23 in)**



Measure the shift fork shaft O.D.


**SERVICE LIMIT: 11.95 mm (0.470 in)**



Turn the outer race of the shift drum bearing with your finger.


The bearing should turn smoothly and freely without excessive play.

If necessary replace the bearing.





Inspect the shift drum guide grooves for abnormal wear or damage.




Check the gear dogs, dog holes and teeth for abnormal wear or lack of lubrication.

Measure the I.D. of each gear.

**SERVICE LIMITS:**

- M5, M6: 31.04 mm (1.222 in)
- C1: 28.04 mm (1.104 in)
- C2, C3, C4: 33.04 mm (1.301 in)



Measure the O.D. of each gear bushing.

**SERVICE LIMITS:**

- M5, M6: 30.935 mm (1.2179 in)
- C2: 32.935 mm (1.2967 in)
- C3, C4: 32.930 mm (1.2964 in)

Measure the I.D. of each gear bushing.

**SERVICE LIMITS:**

- M5: 28.016 mm (1.1030 in)
- C2: 30.021 mm (1.1819 in)


Calculate the gear-to-bushing clearance.

**SERVICE LIMITS:**

- M5, M6: 0.10 mm (0.004 in)
- C2: 0.10 mm (0.004 in)
- C3, C4: 0.11 mm (0.004 in)

Check the gear shifter groove for abnormal wear or damage.

SHIFTER GROOVE



## TRANSMISSION/GEARSHIFT LINKAGE

Check the mainshaft and countershaft for abnormal wear or damage.

Measure the mainshaft O.D. at the M5 gear.

**SERVICE LIMIT: 27.957 mm (1.1007 in)**

Measure the countershaft O.D. at the C2 gear.


**SERVICE LIMIT: 29.960 mm (1.1795 in)**

Calculate the gear bushing-to-shaft clearance.

**SERVICE LIMITS:**

**M5: 0.06 mm (0.002 in)**


**C2: 0.06 mm (0.002 in)**



Turn the inner race of each transmission bearing with your finger.

The bearing should turn smoothly and freely without excessive play.

If necessary replace the bearing (page 11-16).




## TRANSMISSION BEARING REPLACEMENT


*Replace the transmission holder and crankcase as a set.*

Remove the shift drum bearing setting bolts.

Remove the bolts and mainshaft bearing set plate.



Remove the bolt and countershaft bearing set plate.




## TRANSMISSION/GEARSHIFT LINKAGE

Remove the countershaft bearing using the special tools.


### TOOLS:

Bearing remover handle	07936-3710100
Bearing remover set, 20 mm	07936-3710600
Remover weight	07741-0010201

Drive out the countershaft bearing and shift drum bearing.



### Bearing Locations:



Drive the each bearing into the bearing holder using the special tools.

### TOOLS:

#### Mainshaft bearing:


Driver	07749-0010000
Attachment, 62 x 68 mm	07746-0010500
Pilot, 28 mm	07746-0041100

#### Countershaft bearing:

Driver	07749-0010000
Attachment, 52 x 55 mm	07746-0010400
Pilot, 20 mm	07746-0040500

#### Shift drum bearing:


Driver	07749-0010000
Attachment, 42 x 47 mm	07746-0010300
Pilot, 25 mm	07746-0040600



## TRANSMISSION/GEARSHIFT LINKAGE

Clean and apply a locking agent to the countershaft bearing set plate bolt threads.  
Install the set plate and tighten the bolt to the specified torque.


**TORQUE: 12 N·m (1.2 kgf·m, 9 lbf·ft)**



Clean and apply a locking agent to the mainshaft bearing set plate bolt threads and shift drum bearing setting bolt threads.


Install the mainshaft bearing set plate with its "MEL OUTSIDE" mark facing out.  
Install and tighten the bearing set plate bolts and setting bolts to the specified torque.

**TORQUE: 12 N·m (1.2 kgf·m, 9 lbf·ft)**





## ASSEMBLY

Mainshaft:



Countershaft:




# TRANSMISSION/GEARSHIFT LINKAGE



Apply clean engine oil to the gear teeth, sliding surfaces and the bushings.

Assemble the transmission gears and shafts.

- Always install the thrust washer and snap ring with the chamfered (rolled) edge facing away from the thrust load.
- Install the snap ring so that its end gap aligns with the groove in the splines.
- Make sure that the snap ring is fully seated in the shaft groove after installing it.
- Align the lock washer tabs with the spline washer grooves.




Apply molybdenum oil solution to the shift fork grooves in the M3/4, C5 and C6 shift gear.




Install the shift drum into the transmission holder.

TRANSMISSION HOLDER




Install the flange collar with its flange facing in.

FLANGE COLLAR




Install the dowel pins onto the gearshift cam.



Install the gearshift cam onto the gearshift drum.  
Clean and apply a locking agent to the gearshift cam  
bolt threads.  
Install and tighten the bolt to the specified torque.

**TORQUE: 12 N-m (1.2 kgf-m, 9 lbf-ft)**

BOLT




## TRANSMISSION/GEARSHIFT LINKAGE

Install the following:


- Return spring
- Washer
- Stopper arm
- Pivot bolt

Tighten the stopper arm pivot bolt to the specified torque.

**TORQUE: 12 N·m (1.2 kgf·m, 9 lbf·ft)**




Install the mainshaft and countershaft as an assembly to the transmission holder.



The shift forks have location marks:

- "RL" for right and left
- "C" for center




*Install the shift forks with their identification marks facing up.*

Install each shift fork and align its claw with each shifter groove.

*The shaft for center shift fork is shorter than that for right/left shift forks.*

Install the shift fork shafts onto the transmission holder.






**INSTALLATION**


*Be careful not to drop the oil orifice into the crankcase.*

Install the oil orifice with its small I.D. side facing in.



Turn the shift drum while turning the mainshaft, and position the transmission into neutral.

Install the transmission holder and transmission assembly into the crankcase.




Install and tighten the bearing holder mounting bolts in numerical order in the illustration in two to three steps to the specified torque.

**TORQUE: 29 N·m (3.0 kgf·m, 21 lbf·ft)**

Install the following:

- Gearshift linkage (page 11-9)
- Clutch (page 9-25)
- Right crankcase cover (page 9-34)



---

**MEMO**

---


# 12. CRANKCASE/CRANKSHAFT/BALANCER/PISTON/CYLINDER

---

COMPONENT LOCATION .....	12-2	CRANKPIN BEARING .....	12-14
SERVICE INFORMATION .....	12-3	PISTON/CYLINDER .....	12-17
TROUBLESHOOTING .....	12-5	COUNTERSHAFT BEARING REPLACEMENT .....	12-23
CRANKCASE SEPARATION .....	12-6	CRANKCASE ASSEMBLY .....	12-24
CRANKSHAFT .....	12-8	BALANCER .....	12-31
MAIN JOURNAL BEARING .....	12-11		

# CRANKCASE/CRANKSHAFT/BALANCER/PISTON/CYLINDER

## COMPONENT LOCATION



# SERVICE INFORMATION

## GENERAL

- The crankcase must be separated to service the following:
  - Crankshaft (page 12-8)
  - Piston/connecting rod/cylinder (page 12-17)
  - Balancer (page 12-31)
- The following components must be removed before separating the crankcase:
  - Engine (page 7-4)
  - Clutch (page 9-18)
  - Cylinder head (page 8-12)
  - Flywheel (page 10-8)
  - Gearshift linkage/transmission (page 11-12)
  - Oil pan (page 4-6)
  - Oil pump (page 4-8)
  - Oil cooler (page 4-13)
  - Starter clutch (page 9-29)
  - Starter motor (page 19-6)
  - Water pump (page 6-16)
- Replace the crankcase and transmission holder as an assembly.
- Be careful not to damage the crankcase mating surfaces when servicing.
- Prior to assembling the crankcase halves, apply sealant to their mating surfaces. Wipe off excess sealant thoroughly.
- Mark and store the connecting rods, bearing caps and bearing inserts to be sure of their correct locations for reassembly.
- The crankpin and main journal bearing inserts are select fit and are identified by color codes. Select replacement bearings from the code tables. After selecting new bearings, recheck the oil clearance with a plastigauge. Incorrect oil clearance can cause major engine damage.

## SPECIFICATIONS

Unit: mm (in)







ITEM		STANDARD	SERVICE LIMIT	
Crankshaft	Connecting rod side clearance	0.05 – 0.20 (0.002 – 0.008)	0.25 (0.098)	
	Crankpin bearing oil clearance	0.030 – 0.052 (0.0012 – 0.0020)	0.06 (0.002)	
	Main journal bearing oil clearance	0.019 – 0.037 (0.0007 – 0.0015)	0.05 (0.002)	
	Runout	–	0.05 (0.002)	
Piston, piston rings	Piston O.D. at 9.0 (0.35) from bottom	74.960 – 74.980 (2.9512 – 2.9520)	74.895 (2.9486)	
	Piston pin bore I.D.	17.002 – 17.008 (0.6694 – 0.6696)	17.030 (0.6705)	
	Piston pin O.D.	16.994 – 17.000 (0.6690 – 0.6693)	16.980 (0.6685)	
	Piston-to-piston pin clearance	0.002 – 0.014 (0.0001 – 0.0006)	0.04 (0.002)	
	Piston ring end gap	Top	0.17 – 0.27 (0.0067 – 0.0106)	0.52 (0.020)
		Second	0.48 – 0.63 (0.019 – 0.025)	0.82 (0.032)
		Oil (side rail)	0.2 – 0.7 (0.01 – 0.03)	1.0 (0.04)
Piston ring-to-ring groove clearance	Top	0.050 – 0.085 (0.0020 – 0.0033)	0.125 (0.0049)	
	Second	0.015 – 0.045 (0.0006 – 0.0018)	0.075 (0.0030)	
Cylinder	I.D.	75.000 – 75.015 (2.9528 – 2.9533)	75.15 (2.959)	
	Out of round	–	0.10 (0.004)	
	Taper	–	0.10 (0.004)	
	Warpage	–	0.10 (0.004)	
Cylinder-to-piston clearance		0.020 – 0.055 (0.0008 – 0.0022)	0.10 (0.004)	
Connecting rod small end I.D.		17.030 – 17.042 (0.6705 – 0.6709)	17.048 (0.6712)	
Connecting rod-to-piston pin clearance		0.030 – 0.046 (0.0012 – 0.0018)	0.07 (0.003)	

# CRANKCASE/CRANKSHAFT/BALANCER/PISTON/CYLINDER

## TORQUE VALUES

Crankcase	7 mm bolt	18 N·m (1.8 kgf·m, 13 lbf·ft)	
	8 mm bolt	24 N·m (2.4 kgf·m, 18 lbf·ft)	
	9 mm bolt (main journal bolt)	See page 12-27	
Lower crankcase sealing bolt (22 mm)		59 N·m (6.0 kgf·m, 44 lbf·ft)	Apply a locking agent to the threads.
Lower crankcase socket bolt (10 mm)		12 N·m (1.2 kgf·m, 9 lbf·ft)	Apply a locking agent to the threads.
Lower crankcase sealing bolt (20 mm)		30 N·m (3.1 kgf·m, 22 lbf·ft)	Apply a locking agent to the threads.
Lower crankcase socket bolt (8 mm)		23 N·m (2.3 kgf·m, 18 lbf·ft)	Apply a locking agent to the threads.
Connecting rod bolt (new bolt)		See page 12-9	Apply engine oil to the threads and seating surface.
Connecting rod bolt (retightening)		See page 12-14	Apply engine oil to the threads and seating surface.
EOP switch		12 N·m (1.2 kgf·m, 9 lbf·ft)	Apply sealant to the threads.
EOP switch wire terminal bolt		2.0 N·m (0.2 kgf·m, 1.5 lbf·ft)	

## TOOLS:

<p>Bearing remover shaft, 35 mm 07936-3710400</p> 	<p>Remover shaft handle 07936-3710100</p> 	<p>Remover weight 07741-0010201</p> 
<p>Driver 07749-0010000</p> 	<p>Attachment, 72 x 75 mm 07746-0010600</p> 	<p>Pilot, 35 mm 07746-0040800</p> 

## **TROUBLESHOOTING**

### **Cylinder compression is too low, hard to starting or poor performance at low speed**

- Leaking cylinder head gasket
- Worn, stuck or broken piston ring
- Worn or damaged cylinder and piston

### **Cylinder compression too high, overheating or knocking**

- Excessive carbon built-up on piston head or combustion chamber

### **Excessive smoke**

- Worn cylinder, piston or piston ring
- Improper installation of piston rings
- Scored or scratched piston or cylinder wall

### **Abnormal noise**

- Worn piston pin or piston pin hole
- Worn connecting rod small end
- Worn cylinder, piston or piston rings
- Worn main journal bearings or crankpin bearings

### **Engine vibration**

- Excessive crankshaft runout
- Incorrect balancer timing


**CRANKCASE SEPARATION**

Refer to Service Information for removal of necessary parts before separating the crankcase (page 12-3).


Unhook the EOP switch wire clip from stay and remove the dust cover.

Remove the terminal bolt and terminal eyelet from the EOP switch.

Remove the EOP switch.




Remove the dust cover, terminal nut and terminal eyelet from the neutral switch.




Remove the bolts and water hose joint.

Remove the O-ring from the hose joint.



Remove the bolts, stay and oil inspection window.


Remove the O-ring from the oil inspection window.






## CRANKCASE/CRANKSHAFT/BALANCER/PISTON/CYLINDER

Loosen the 7 mm bolts (six) in two to three steps.  
Loosen the 8 mm bolts (five) in two to three steps.  
Remove the 8 mm bolts, 7 mm bolts and sealing washer.




Place the engine upside down.  
Loosen the 7 mm bolts (six) and 8 mm bolt in a crisscross pattern in two to three steps, then remove the bolts.  
Loosen the 9 mm bolts (main journal bolts) in a crisscross pattern in two to three steps, then remove the bolts.




Separate the lower crankcase from the upper crankcase.

Remove the three dowel pins and two oil orifices.  
Clean any sealant off from the crankcase mating surface.



Remove the mainshaft bearing and clutch lifter rod oil seal from the upper crankcase.




## CRANKSHAFT

### SIDE CLEARANCE INSPECTION

Separate the crankcase halves (page 12-6).  
Measure the connecting rod side clearance.

**SERVICE LIMIT: 0.25 mm (0.098 in)**

If the clearance exceeds the service limit, replace the connecting rod.  
Recheck and if still out of limit, replace the crankshaft.



### REMOVAL

#### NOTICE


- Before removal, position all the pistons at TDC (Top Dead Center) to prevent damaging the crankpin with the connecting rod.
- Do not interchange the bearing inserts. they must be installed in their original locations or the correct bearing oil clearance may not be obtained, resulting in engine damage.

Mark the bearing caps and bearings as you remove them to indicate the correct cylinder for reassembly.

Remove the connecting rod bolts and bearing caps.

Position all the pistons at TDC (Top Dead Center), then remove the crankshaft.

*Tap the side of the bearing cap lightly if it is hard to remove.*




### INSPECTION

Support the crankshaft on both end journals.  
Set a dial gauge on the center main journal of the crankshaft.  
Rotate the crankshaft two revolutions and read the runout.


**SERVICE LIMIT: 0.05 mm (0.002 in)**

Check the primary drive gear and balancer drive gear teeth for abnormal wear or damage.




**INSTALLATION**

Apply molybdenum oil solution to the main journal bearing sliding surfaces on the upper crankcase and the crankpin bearing sliding surfaces on the connecting rods.



Apply molybdenum oil solution to each thrust surface of the crankshaft as shown.



**NOTICE**


*Position all the pistons at TDC (Top Dead Center) to prevent damaging the crankpin with the connecting rod.*

Install the crankshaft carefully onto the upper crankcase.

Set the connecting rods onto the crankpins.

Apply molybdenum oil solution to the crankpin bearing sliding surfaces on the connecting rod bearing caps.


Install the connecting rod bearing caps, aligning the dowel pins with the holes in the connecting rods. Be sure each part is installed in its original position, as noted during removal.



## CRANKCASE/CRANKSHAFT/BALANCER/PISTON/CYLINDER

*The connecting rod bolts cannot be reused. Once the connecting rod bolts have been loosened, replace them with new ones.*

Apply engine oil to new connecting rod bolt threads and seating surfaces, and install the bolts.




*Tighten the connecting rod bolts with a Plastic Region Tightening Method.*

Tighten the bolts in two to three steps alternately, then tighten the bolts to the specified torque.

Further tighten the connecting rod bolts 90 degrees.

**TORQUE: 20 N·m (2.0 kgf·m, 15 lbf·ft) + 90°**

Assemble the upper and lower crankcase (page 12-24).



## MAIN JOURNAL BEARING

### NOTICE


*Do not interchange the bearing inserts. They must be installed in their original locations or the correct bearing oil clearance may not be obtained, resulting in engine damage.*

### BEARING INSPECTION

Remove the crankshaft (page 12-8).

Inspect the main journal bearing inserts on the upper and lower crankcase halves for unusual wear or peeling.

Check the bearing tabs for damage.




### OIL CLEARANCE INSPECTION

Clean off any oil from the bearing inserts and main journals.

Install the crankshaft onto the upper crankcase.

Put a strip of plastigauge lengthwise on each main journal avoiding the oil hole.

- Do not rotate the crankshaft during inspection.




## CRANKCASE/CRANKSHAFT/BALANCER/PISTON/CYLINDER

Install the three dowel pins (page 12-25).


Install the lower crankcase onto the upper crankcase, then install the crankcase 9 mm bolts (main journal bolts).

Tighten the crankcase 9 mm bolts (main journal bolts) in numerical order in the illustration in two to three steps to the specified torque.

Further tighten the crankcase 9 mm bolts (main journal bolts) 150 degrees.




**TORQUE: 20 N·m (2.0 kgf·m, 15 lbf·ft)+ 150°**



Remove the crankcase 9 mm bolts (main journal bolts) and the lower crankcase, measure the compressed plastigauge at its widest point on each main journal to determine the oil clearance.


**SERVICE LIMIT: 0.05 mm (0.002 in)**

If the oil clearance exceeds the service limit, select a replacement bearing (page 12-12).



### BEARING SELECTION


Letters (A, B or C) on the left side of upper crankcase are codes for the bearing support I.D. from left to right. Record the crankcase bearing support I.D. code letters from the left side of the upper crankcase as shown.



CRANKCASE I.D. CODE

# CRANKCASE/CRANKSHAFT/BALANCER/PISTON/CYLINDER

Numbers (1, 2 or 3) on the crank weight are codes for the main journal O.D. from left to right. Record the corresponding main journal O.D. code numbers from the crank weight.



Cross reference the main journal and bearing support codes to determine the replacement bearing color code.


**MAIN JOURNAL BEARING SELECTION TABLE:**

		BEARING SUPPORT I.D.CODE			
		A	B	C	
		37.000 – 37.006 mm (1.4567 – 1.4569 in)	37.006 – 37.012 mm (1.4569 – 1.4572 in)	37.012 – 37.018 mm (1.4572 – 1.4574 in)	
MAIN JOURNAL O.D. CODE	1	34.000 – 34.006 mm (1.3386 – 1.3388 in)	Red	Pink	Yellow
	2	33.994 – 34.000 mm (1.3383 – 1.3386 in)	Pink	Yellow	Green
	3	33.988 – 33.994 mm (1.3381 – 1.3383 in)	Yellow	Green	Brown

**BEARING THICKNESS:**  
 Brown: Thickest  
 Green:  
 Yellow: †  
 Pink:  
 Red: Thinnest

**NOTICE**

After selecting new bearings, recheck the clearance with a plastigauge. Incorrect clearance can cause severe engine damage.





## BEARING INSTALLATION

Clean the bearing outer surfaces and crankcase bearing supports.

Apply molybdenum oil solution to the main journal bearing sliding surfaces on the upper and lower crankcase.

Install the main journal bearing inserts onto the crankcase bearing supports, aligning each tab with each groove.



## CRANKPIN BEARING

### NOTICE


*Do not interchange the bearing inserts. They must be installed in their original locations or the correct bearing oil clearance may not be obtained, resulting in engine damage.*

Remove the crankshaft (page 12-8).

### BEARING INSPECTION

Check the bearing inserts for unusual wear or peeling.

Check the bearing tabs for damage.






**OIL CLEARANCE INSPECTION**

Clean off any oil from the bearing inserts and crankpins.  
Carefully install the crankshaft onto the upper crankcase.

Set the connecting rods onto the crankpins.  
Put a strip of plastigauge lengthwise on each crankpin avoiding the oil hole.

- Do not rotate the crankshaft during inspection.



Carefully install the connecting rod bearing caps, aligning the dowel pins with the holes in the connecting rods.


*Use the removed connecting rod bolts when checking the oil clearance.*

Apply oil to the connecting rod bolt threads and seating surfaces and install the bolts.

Tighten the bolts in two to three steps alternately, then tighten the bolts to the specified torque.

Further tighten the connecting rod bolts 90 degrees.


**TORQUE: 14 N·m (1.4 kgf·m, 10 lbf·ft) + 90°**



Remove the bolts and bearing caps, and measure the compressed plastigauge at its widest point on the crankpin to determine the oil clearance.

**SERVICE LIMIT: 0.06 mm (0.002 in)**


If the oil clearance exceeds the service limit, select the correct replacement bearings (page 12-15).



**BEARING SELECTION**

*Numbers (1, 2 or 3) on the connecting rods are the codes for the connecting rod I.D.*

Record the connecting rod I.D. code number (1, 2 or 3) or measure the I.D. with the connecting rod bearing cap installed without bearing inserts.




CONNECTING ROD I.D. CODE

# CRANKCASE/CRANKSHAFT/BALANCER/PISTON/CYLINDER

Letters (A, B or C) on the crankweight are the codes for the crankpin O.D.s from left to right.

If you are replacing the crankshaft, record the corresponding crankpin O.D. code letter (A, B or C).

If you are reusing the crankshaft, measure the crankpin O.D. with the micrometer.



Cross-reference the connecting rod and crankpin codes to determine the replacement bearing color.


## CRANKPIN BEARING SELECTION TABLE:

			CONNECTING ROD I.D.CODE		
			1	2	3
			39.500 – 39.506 mm (1.5551 – 1.5554 in)	39.506 – 39.512 mm (1.5554 – 1.5556 in)	39.512 – 39.518 mm (1.5556 – 1.5558 in)
CRANK PIN O.D.CODE	A	36.497 – 36.503 mm (1.4369 – 1.4371 in)	Yellow	Green	Brown
	B	36.491 – 36.497 mm (1.4367 – 1.4369 in)	Green	Brown	Black
	C	36.485 – 36.491 mm (1.4364 – 1.4367 in)	Brown	Black	Blue

## BEARING THICKNESS:

Blue: Thickest  
 Black:  
 Brown: ↓  
 Green:  
 Yellow: Thinnest

## IDENTIFICATION COLOR




## NOTICE

After selecting new bearings, recheck the clearance with a plastigauge. Incorrect clearance can cause severe engine damage.

## BEARING INSTALLATION

Clean the bearing outer surfaces, connecting rod bearing cap and connecting rod. Install the crankpin bearing inserts onto the bearing cap and connecting rod, aligning each tab with each groove.

## CRANKPIN BEARING INSERTS



## PISTON/CYLINDER

### PISTON/CONNECTING ROD REMOVAL


#### NOTICE

- This motorcycle is equipped with aluminum cylinder sleeves. Before piston removal, place a clean shop towel around the connecting rod to prevent damaging the cylinder sleeve.
- Do not try to remove the piston/connecting rod assembly from bottom of the cylinder; the assembly will get stuck in the gap between the cylinder liner and the upper crankcase.
- Do not interchange the bearing inserts. They must be installed in their original locations or the correct bearing oil clearance may not be obtained, resulting in engine damage.

Separate the crankcase halves (page 12-6).


*Mark all parts as you remove them to indicate the correct cylinder for reassembly.*

Remove the connecting rod bolts and connecting rod bearing caps.




*Do not try to remove the connecting rod/piston assembly from the bottom of the cylinder; the assembly will be locked so that the oil ring expands in the gap between the cylinder liner and the upper crankcase.*

Remove the piston/connecting rod assembly from the top of the cylinder.



### PISTON REMOVAL


Remove the piston pin clip with pliers. Push the piston pin out of the piston and connecting rod, and remove the piston.



## PISTON DISASSEMBLY


*Be careful not to damage the piston ring by spreading the ends too far.*

Spread each piston ring ends and remove them by lifting up at a point opposite the gap.



*Never use a wire brush; it will scratch the groove.*

Clean carbon deposits from the piston ring grooves with a ring that will be discarded.



## PISTON INSPECTION

Inspect the piston rings for movement by rotating the rings. The rings should be able to move in their grooves without catching.

Push the ring until the outer surface of the piston ring is nearly flush with the piston and measure the ring-to-ring groove clearance.



### SERVICE LIMITS:


**Top:** 0.125 mm (0.0049 in)  
**Second:** 0.075 mm (0.0030 in)

*Push the rings into the cylinder with the piston head to be sure they are squarely in the cylinder.*

Insert the piston ring squarely into the top of the cylinder and measure the ring end gap.


### SERVICE LIMITS:

**Top:** 0.52 mm (0.020 in)  
**Second:** 0.82 mm (0.032 in)  
**Oil (side rail):** 1.0 mm (0.04 in)



Measure the piston pin bore.

**SERVICE LIMIT: 17.030 mm (0.6705 in)**




Measure the O.D. of the piston pin.

**SERVICE LIMIT: 16.980 mm (0.6685 in)**


Calculate the piston-to-piston pin clearance.

**SERVICE LIMIT: 0.04 mm (0.002 in)**



Measure the diameter of the piston at 9.0 mm (0.35 in) from the bottom and 90 degrees to the piston pin hole.

**SERVICE LIMIT: 74.895 mm (2.9486 in)**




## CONNECTING ROD INSPECTION

Measure the connecting rod small end I.D.

**SERVICE LIMIT: 17.048 mm (0.6712 in)**

Calculate the connecting rod-to-piston pin clearance.

**SERVICE LIMIT: 0.07 mm (0.003 in)**



## CYLINDER INSPECTION

Inspect the cylinder bore for wear or damage. Measure the cylinder I.D. in X and Y axis at three levels. Take the maximum reading to determine the cylinder wear.

**SERVICE LIMIT: 75.15 mm (2.959 in)**

Calculate the piston-to-cylinder clearance. Take a maximum reading to determine the clearance. Refer to the procedures for measurement of the piston O.D. (page 12-19).

**SERVICE LIMIT: 0.10 mm (0.004 in)**

Calculate the taper and out-of-round at three levels in X and Y axis. Take the maximum reading to determine them.

**SERVICE LIMITS:**

**Taper: 0.10 mm (0.004 in)**

**Out-of-round: 0.10 mm (0.004 in)**




The cylinder must be rebored and an oversize piston fitted if the service limits are exceeded.

**The following oversize piston is available:**  
**0.25 mm (0.010 in)**

The piston to cylinder clearance for the oversize piston must be: 0.015 – 0.050 mm (0.0006 – 0.0020 in).

Inspect the top of the cylinder for warpage.


**SERVICE LIMIT: 0.10 mm (0.004 in)**




## PISTON OIL JET REPLACEMENT

Remove the bolts and piston oil jets from the upper crankcase.

Inspect the oil jets for clogs, and replace if necessary.



Install the oil jet collar onto the oil jet.




The piston oil jet has identification marks (A or B) on the body.

Install the oil jet A into the No.2 and 3 cylinder, and the oil jet B into the No.1 and 4 cylinder as shown.

Apply a locking agent to the piston oil jet mounting bolts threads.

Install and tighten the piston oil jet mounting bolts.



**PISTON ASSEMBLY**


Clean the piston ring grooves thoroughly and install the piston rings.

- Apply engine oil to the piston rings.
- Avoid piston and piston ring damage during installation.
- Install the piston rings with the marking (R: top ring, RN: second ring) facing up. Do not confuse the top and second rings.
- To install the oil ring, install the spacer first, then install the side rails.

Stagger the piston ring end gaps 120° apart from each other.

Stagger the side rail end gaps as shown.


After installation, the rings should rotate freely in the ring groove.



## PISTON INSTALLATION


Apply molybdenum oil solution to the connecting rod small end inner surfaces and piston pin outer surfaces.

Assemble the piston and connecting rod with the journal bearing tab facing to the piston "IN" mark.



Install the piston pin and secure it using new piston pin clips.

- Make sure that the piston pin clips are seated in the groove securely.
- Do not align the piston pin clip end gap with the cut-out of the piston bore.



Coat the cylinder walls, piston outer surfaces and piston rings with engine oil.


*Install the piston/ connecting rod assembly with the piston "IN" mark facing the intake side.*

Install the piston/connecting rod assemblies into the cylinders using a commercially available piston ring compressor tool.

When reusing the connecting rods, they must be installed in their original locations.

### NOTICE

- While installing the piston, be careful not to damage the top surface of the cylinder, especially around the cylinder bore.
- Be careful not to damage the cylinder sleeve and crankpin with the connecting rod.



*Make sure the piston ring compressor tool sits flush on the top surface of the cylinder.*


Use the handle of a plastic hammer or equivalent tool to tap the piston into the cylinder.

Install the crankshaft (page 12-9).




Apply molybdenum oil solution to the crankpin bearing sliding surface on the bearing caps.

Install the connecting rod bearing caps, aligning the dowel pins with the holes in the connecting rods.



*The connecting rod bolts cannot be reused. Once the connecting rod bolts have been loosened replace them with new ones.*

Apply engine oil to new connecting rod bolt threads and seating surfaces, and install the bolts.




Tighten the bolts in two to three steps alternately, then tighten the bolts to the specified torque.

Further tighten the connecting rod bolts 90 degrees.

**TORQUE: 20 N·m (2.0 kgf·m, 15 lbf·ft) + 90 °**


Assemble the crankcase halves (page 12-24).



## COUNTERSHAFT BEARING REPLACEMENT

Separate the crankcase halves (page 12-6).  
Remove the main journal bearings from the lower crankcase (page 12-11).

Remove the bolt and bearing set plate.




## CRANKCASE/CRANKSHAFT/BALANCER/PISTON/CYLINDER

Remove the countershaft bearing from the lower crankcase using the special tool.


### TOOLS:

Bearing remover shaft, 35 mm	07936-3710400
Remover shaft handle	07936-3710100
Remover weight	07741-0010201



Remove the countershaft oil seal from inside of the crankcase.


Apply grease to new countershaft oil seal lips and install it to inside of the crankcase.



Drive the new countershaft bearing into the lower crankcase using the special tool.

### TOOLS:


Driver	07749-0010000
Attachment, 72 x 75 mm	07746-0010600
Pilot, 35 mm	07746-0040800



## CRANKCASE ASSEMBLY


*Replace the transmission bearing holder and crankcase as a set.*

Apply a light, but thorough, coating of liquid sealant (Three Bond 1207B or equivalent) to the crankcase mating surface. Do not apply sealant to the crankcase 9 mm bolt (main journal bolt) area and the oil passage area as shown.




# CRANKCASE/CRANKSHAFT/BALANCER/PISTON/CYLINDER


Install the mainshaft bearing while aligning its locating pin with the crankcase hole.




Install the clutch lifter rod oil seal.



*Align each flat of the oil orifice and crankcase.* Install the oil orifices in the upper crankcase.




Install the three dowel pins.




## BALANCER TIMING ALIGNMENT/ LOWER CRANKCASE INSTALLATION

1. Avoid damaging the balancer drive and driven gear, turn the balancer shaft and place the punch mark facing down, make the balancer backlash maximum.




2. Remove the sealing bolt and sealing washer from the lower crankcase.



3. Temporarily install the special bolt into the sealing bolt hole, hold the balancer weight securely.


Make sure the special bolt tip into the balancer weight hole.

**Special bolt, 6 x 18 mm: 90004-MM5-00**



4. Place the crankshaft onto the upper crankcase so that the No.1 piston at TDC (Top Dead Center).


Slightly turn the crankshaft clockwise and align the crankshaft 5th spline center (from the wide spline) with the "Δ" mark on the upper crankcase as shown.



- Carefully place the lower crankcase onto the upper crankcase.

**NOTE:**

The crankshaft will slightly move counterclockwise when engaging the balancer gears.




- Check that the upper and lower crankcase seats properly.

Check that the crankshaft 5th spline center aligns with the next "Δ" mark on the upper crankcase as shown.

Make sure the No.1 piston at TDC (Top Dead Center).


If the crankshaft is not proper position, reassemble the crankcase halves from the beginning.

*Temporarily install the starter clutch assembly to check the TDC.*



- Remove the temporarily installed special bolt from the balancer weight.

Install a new sealing washer and sealing bolt, and tighten the bolt securely.




## CRANKCASE BOLT TIGHTENING PROCEDURE

Install new crankcase 9 mm bolts (main journal bolts).

Loosely install all the lower crankcase bolts (8 mm bolt and 7 mm bolts).

Make sure the upper and lower crankcase are seated firmly.


- Tighten the crankcase 9 mm bolts (main journal bolts) using the Plastic Region Tightening Method described on next procedure.
- Do not reuse the crankcase 9 mm bolts (main journal bolts), because the correct axial tension will not be obtained.
- The crankcase 9 mm bolts (main journal bolts) are pre-coated with an oil additive for axial tension stability. Do not remove the oil additive from the new 9 mm bolts (main journal bolts) surface.




## CRANKCASE/CRANKSHAFT/BALANCER/PISTON/CYLINDER

Tighten the crankcase 9 mm bolts (main journal bolts) in numerical order in the illustration in two to three steps to the specified torque.

Further tighten the crankcase 9 mm bolts (main journal bolts) 150 degrees.



**TORQUE: 20 N·m (2.0 kgf·m, 15 lbf·ft) + 150 °**




Tighten the 8 mm bolt to the specified torque.

**TORQUE: 24 N·m (2.4 kgf·m, 18 lbf·ft)**


From the inside to outside, tighten the 7 mm bolts to the specified torque.

**TORQUE: 18 N·m (1.8 kgf·m, 13 lbf·ft)**




Place the engine with the lower side down.

Install the upper crankcase 8 mm bolts, new sealing washer and 7 mm bolts.



## CRANKCASE/CRANKSHAFT/BALANCER/PISTON/CYLINDER

The sealing washer locations are indicated on the upper crankcase using the "△" mark.




Tighten the 8 mm bolts in a crisscross pattern in 2 to 3 steps.


**TORQUE: 24 N·m (2.4 kgf·m, 18 lbf·ft)**

Tighten the 7 mm bolts in a crisscross pattern in 2 to 3 steps.


**TORQUE: 18 N·m (1.8 kgf·m, 13 lbf·ft)**



Apply engine oil to new O-ring and install it into the oil inspection window groove.




Install the oil inspection window and stay onto the lower crankcase.  
Install the bolts and tighten the bolts securely.




# CRANKCASE/CRANKSHAFT/BALANCER/PISTON/CYLINDER

Install a new O-ring into the water hose joint groove.




Install the water hose joint to the crankcase, then tighten the two bolts securely.




Connect the terminal eyelet to the neutral switch and tighten the terminal nut.

Install the dust cover over the neutral switch.



Apply a sealant (Three Bond 1207B or equivalent) to the EOP switch threads as shown.





Tighten the EOP switch to the specified torque.

**TORQUE: 12 N·m (1.2 kgf·m, 9 lbf·ft)**


Connect the terminal eyelet to the oil pressure switch, and tighten the terminal bolt to the specified torque.

**TORQUE: 2.0 N·m (0.2 kgf·m, 1.5 lbf·ft)**

*Refer to "Cable & Harness Routing" for EOP switch wire (page 1-22).*

Install the EOP switch wire clip to stay and install the dust cover.

Install the removed parts in the reverse order of removal.




## BALANCER


### REMOVAL

Separate the crankcase halves (page 12-6).

Loosen the balancer shaft pinch bolt. Remove the balancer shaft holder bolt and balancer holder.




Pull the balancer shaft out and remove the balancer weight assembly from the lower crankcase.




### DISASSEMBLY

Remove the O-ring from the balancer shaft.




# CRANKCASE/CRANKSHAFT/BALANCER/PISTON/CYLINDER


Remove the washers (A, B) and needle bearings from the balancer weight assembly.



Remove the balancer gear assembly from the balancer weight.




Remove the damper rubbers from the balancer gear.




## INSPECTION

*Replace the balancer weight, balancer shaft, needle bearings as a set*

Check the needle bearing for wear or damage, replace if necessary.




Check the balancer weight and gear for wear or damage.  
 Check the damper rubbers for fatigue or damage, replace if necessary.




**BALANCER BEARING SELECTION**

*The balancer weight and needle bearings are select fitted.*

The balancer weight has two I.D. code letters as shown. The marking identify each I.D. of the balancer weight as shown.



Reference the balancer weight I.D. code letters to determine the replacement bearing color. Refer to the selection table below for bearing selection.




**BALANCER BEARING SELECTION TABLE:**


		BALANCER WEIGHT I.D. CODE		
		A	B	C
		27.000 – 27.004 mm (1.0630 – 1.0631 in)	26.991 – 26.996 mm (1.0626 – 1.0628 in)	26.987 – 26.991 mm (1.0624 – 1.0626 in)
BALANCER SHAFT	17.990 – 17.996 mm (0.7083 – 0.7085 in)	Blue	White	Green

# CRANKCASE/CRANKSHAFT/BALANCER/PISTON/CYLINDER

## DISASSEMBLY




Install the damper rubbers into the balancer gear.  
Assemble the balancer gear and weight while aligning the index marks.




Apply engine oil to the needle bearings, install them into the balancer weight.

Install the washer A and B to the balancer weight assembly.




Install a new O-ring to the balancer shaft groove.




## INSTALLATION

Install the balancer weight assembly into the lower crankcase.


Install the balancer shaft into the lower crankcase.



Turn the balancer shaft and place the punch mark on the shaft facing down.



Install the balancer shaft holder.  
Install and tighten the holder bolt securely.  
Tighten the balancer shaft holder pinch bolt.  
Assemble the crankcase halves (page 12-24).





## BACKLASH ADJUSTMENT

Install the engine into the frame (page 7-8).

*Adjust the backlash while the engine is cold (below 35°C/95°F) and the engine is not running.*

*Excessive force can cause balancer gear, bearing and shaft damage. Do not turn the shaft more than necessary.*

Loosen the balancer shaft holder pinch bolts. Turn the balancer shaft clockwise until resistance is felt, then back it off one graduation using the punch mark as a measure.



Warm up the engine and let it idle.

If the balancer gear noises are excessive, adjust the balancer backlash as follows:


Turn the balancer gear shaft counterclockwise until the gears begin to make a "whining" noise. Then turn the gear shaft clockwise until the gear "whining" noise disappears.

Tighten the balancer shaft pinch bolt.

After all gear backlash adjustments are done, snap the throttle and make sure the gear noises are not excessive.

If the gear "whine" noise is excessive, the backlash is too small.

If the gear "rattling" noise is excessive, the backlash is excessive.



# **13. FRONT WHEEL/SUSPENSION/STEERING**


---

<b>COMPONENT LOCATION .....</b>	<b>13-2</b>	<b>FRONT WHEEL .....</b>	<b>13-16</b>
<b>SERVICE INFORMATION .....</b>	<b>13-4</b>	<b>FORK .....</b>	<b>13-23</b>
<b>TROUBLESHOOTING .....</b>	<b>13-7</b>	<b>STEERING STEM.....</b>	<b>13-34</b>
<b>HANDLEBAR.....</b>	<b>13-8</b>		

# FRONT WHEEL/SUSPENSION/STEERING


## COMPONENT LOCATION

CB1000R:





CB1000RA:



## FRONT WHEEL/SUSPENSION/STEERING

### SERVICE INFORMATION

#### GENERAL

- When servicing the front wheel, fork or steering stem, support the motorcycle using a safety stand or hoist.
- A contaminated brake disc or pad reduces stopping power. Discard contaminated pads and clean a contaminated disc with a high quality brake degreasing agent.
- After the front wheel installation, check the brake operation by applying the brake lever.
- Use only tires marked "TUBELESS" and tubeless valves on rim marked "TUBELESS TIRE APPLICABLE".
- Refer to the brake system information (page 15-4).
- Refer to the light, meter and switch information (page 20-3).

#### SPECIFICATIONS







Unit: mm (in)

ITEM		STANDARD	SERVICE LIMIT	
Minimum tire tread depth		–	1.5 (0.06)	
Cold tire pressure	Driver only	250 kPa (2.50 kgf/cm <sup>2</sup> , 36 psi)	–	
	Driver and passenger	250 kPa (2.50 kgf/cm <sup>2</sup> , 36 psi)	–	
Axle runout		–	0.2 (0.01)	
Wheel rim runout	Radial	–	2.0 (0.08)	
	Axial	–	2.0 (0.08)	
Wheel balance weight		–	60 g (2.1oz) max.	
Fork	Spring free length		249.7 (9.83)	
	Fork tube runout		–	
	Recommended fork fluid		Honda ULTRA CUSHION OIL 10W or equivalent	
	Fluid level	CB1000R	91 (3.6)	–
		CB1000RA	67 (2.6)	–
	Fluid capacity	CB1000R	511 ± 2.5 cm <sup>3</sup> (17.3 ± 0.08 US oz, 18.0 ± 0.09 Imp oz)	–
		CB1000RA	542 ± 2.5 cm <sup>3</sup> (18.4 ± 0.08 US oz, 19.1 ± 0.09 Imp oz)	–
	Pre-load adjuster initial setting		8 turns from minimum	–
	Rebound damping adjuster initial setting		2 turns out from full hard	–
Compression damping adjuster initial setting		2 turns out from full hard	–	
Steering head bearing pre-load		9.8 – 12.5 N (1.0 – 1.3 kgf, 2.2 – 2.9 lbf)	–	













**TORQUE VALUES**

Handlebar holder bolt	27 N·m (2.8 kgf·m, 20 lbf·ft)	
Right handlebar switch screw	0.9 N·m (0.1 kgf·m, 1.0 lbf·ft)	
Left handlebar switch screw	2.7 N·m (0.3 kgf·m, 2.0 lbf·ft)	
Clutch master cylinder holder bolt	12 N·m (1.2 kgf·m, 9 lbf·ft)	
Steering stem adjusting lock nut	See page 13-41	
Steering stem adjusting nut	26 N·m (2.7 kgf·m, 19 lbf·ft)	Apply engine oil to the threads.
Steering stem nut	103 N·m (10.5 kgf·m, 76 lbf·ft)	
Bottom bridge pinch bolt	27 N·m (2.8 kgf·m, 20 lbf·ft)	
Top bridge pinch bolt	22 N·m (2.2 kgf·m, 16 lbf·ft)	
Fork bolt	34 N·m (3.5 kgf·m, 25 lbf·ft)	
Fork bolt lock nut	20 N·m (2.0 kgf·m, 15 lbf·ft)	
Fork socket bolt	34 N·m (3.5 kgf·m, 25 lbf·ft)	Apply a locking agent to the threads.
Front axle pinch bolt	22 N·m (2.2 kgf·m, 16 lbf·ft)	
Front axle bolt	59 N·m (6.0 kgf·m, 44 lbf·ft)	
Front brake disc mounting bolt	20 N·m (2.0 kgf·m, 15 lbf·ft)	
Front brake master cylinder holder bolt	12 N·m (1.2 kgf·m, 9 lbf·ft)	ALOC bolt; replace with a new one.
Front brake caliper mounting bolt		
	CB1000R: 45 N·m (4.6 kgf·m, 33 lbf·ft)	ALOC bolt; replace with a new one.
	CB1000RA: 30 N·m (3.1 kgf·m, 22 lbf·ft)	ALOC bolt; replace with a new one.
Front brake hose clamp bolt/nut		
	CB1000R: 12 N·m (1.2 kgf·m, 9 lbf·ft)	ALOC bolt; replace with a new one.
	CB1000RA: 10 N·m (1.0 kgf·m, 7 lbf·ft)	ALOC bolt; replace with a new one.
Front pulser ring mounting bolt (CB1000RA)	7.0 N·m (0.7 kgf·m, 5.2 lbf·ft)	ALOC bolt; replace with a new one.
Front fender mounting bolt	12 N·m (1.2 kgf·m, 9 lbf·ft)	

**TOOLS**

<p>Fork damper holder 070MF-MBZC120</p>  <p><b>NOTE</b> This tool is a part of fork damper install set (P/N 070MF-MBZC100).</p>	<p>Spring collar holder 070MF-MBZC110</p>  <p><b>NOTE</b> This tool is a part of fork damper install set (P/N 070MF-MBZC100).</p>	<p>Stopper plate 070MF-MBZC130</p>  <p><b>NOTE</b> This tool is a part of fork damper install set (P/N 070MF-MBZC100).</p>
<p>Driver attachment (upper) 070MF-MCJ0100</p> 	<p>Driver attachment (lower) 070MF-MCJ0200</p> 	<p>Attachment, 42 x 47 mm 07746-0010300</p> 

# FRONT WHEEL/SUSPENSION/STEERING

<p>Pilot, 20 mm 07746-0040500</p> 	<p>Bearing remover head, 20 mm 07746-0050600</p> 	<p>Driver 07749-0010000</p> 
<p>Steering stem socket 07916-3710101</p> 	<p>Steering stem driver 07946-MB00000</p> 	<p>Driver shaft assembly 07946-KM90301</p> 
<p>Bearing remover, A 07946-KM90401</p> 	<p>Assembly base 07946-KM90600</p> 	<p>Bearing remover shaft 07GGD-0010100</p>  <p>or 07746-0050100</p>
<p>Bearing remover, B 07NMF-MT70110</p> 	<p>Fork damper holder attachment 07YMB-MCF0101</p> 	<p>Fork seal driver weight 07YMD-MCF0100</p> 

---

## TROUBLESHOOTING

### Hard steering

- Steering stem adjusting nut too tight
- Faulty or damaged steering head bearings
- Bent steering stem
- Faulty tire
- Insufficient tire pressure

### Steers to one side or does not track straight

- Damaged or loose steering head bearings
- Bent forks
- Bent axle
- Bent frame
- Wheel installed incorrectly
- Worn or damaged wheel bearings
- Worn or damaged swingarm pivot bearings

### Front wheel wobbling

- Bent rim
- Worn or damaged front wheel bearings
- Faulty tire
- Unbalanced front tire and wheel

### Front wheel turns hard

- Faulty front wheel bearing
- Bent front axle
- Front brake drag

### Soft suspension

- Insufficient fluid in fork
- Incorrect fork fluid weight
- Weak fork springs
- Insufficient tire pressure

### Hard suspension

- Bent fork pipes
- Too much fluid in fork
- Incorrect fork fluid weight
- Clogged fork fluid passage


### Front suspension noise

- Insufficient fluid in fork
- Loose fork fasteners

# HANDLEBAR


## REMOVAL

Remove the rearview mirrors.




*For inner weight replacement, see page 13-16.*

Hold the handlebar weights and remove the screws, then remove both handlebar weights from the handlebar.




Disconnect the clutch switch wire connectors from the clutch switch.




*Keep the clutch master cylinder upright to prevent air from entering the hydraulic system*

Remove the clutch master cylinder holder bolts, holder and the clutch master cylinder assembly.




Remove the screws and left handlebar switch housing.

LEFT HANDLEBAR SWITCH HOUSING




Remove the left handle grip from the handlebar.

GRIP



Disconnect the front brake light switch wire connectors from the front brake light switch.

CONNECTORS




*Keep the brake master cylinder upright to prevent air from entering the hydraulic system*

Remove the front brake master cylinder holder bolts, holder and the front brake master cylinder assembly.

FRONT BRAKE MASTER CYLINDER

HOLDER


HOLDER BOLTS



# FRONT WHEEL/SUSPENSION/STEERING


Remove the right handlebar switch screws, then remove the right handlebar switch housing from the handlebar.

RIGHT HANDLEBAR SWITCH HOUSING




Remove the throttle housing screws.

THROTTLE HOUSING




Remove the handlebar holder bolt caps.

HOLDER BOLT CAPS



Remove the handlebar holder bolts and handlebar holder.


HANDLEBAR HOLDER BOLTS





Remove the right handlebar grip/throttle pipe from the handlebar.

Disconnect the throttle cable ends from the throttle pipe and remove the throttle housing.




## INSTALLATION

Apply Honda Bond A or equivalent to the inside surface of the right handlebar grip and to the clean surfaces of the throttle pipe.


*Allow the adhesive to dry for 1 hour before using.*

Wait 3–5 minutes and install the grip. Rotate the grip for even application of the adhesive.



Apply grease to the throttle pipe flange groove, sliding areas and throttle cable ends. Connect the throttle cable ends to the throttle pipe flange.

Install the throttle pipe onto the handlebar.




Place the handlebar on the lower holders aligning the punch mark on the handlebar with the edge of the lower holder.

Install the handlebar holder with its direction as shown.

Install the handlebar holder bolts.


Tighten the front bolts first, then tighten the rear bolts to the specified torque.

**TORQUE: 27 N·m (2.8 kgf·m, 20 lbf·ft)**




## FRONT WHEEL/SUSPENSION/STEERING

Install the handlebar holder bolt caps securely.




Align the locating pin in the throttle housing with the hole in the handlebar.

THROTTLE HOUSING




Tighten the forward screw first, then the rear screw securely.

THROTTLE HOUSING



Install the right handlebar switch housing aligning its location pin with the hole in the handlebar.


RIGHT HANDLEBAR SWITCH HOUSING



Tighten the forward screw first, then the rear screw to the specified torque.


**TORQUE: 0.9 N·m (0.1 kgf·m, 1.0 lbf·ft)**

RIGHT HANDLEBAR SWITCH HOUSING




Install the front brake master cylinder by aligning the edge of the front brake master cylinder with the punch mark on the handlebar. Install the front brake master cylinder holder with the "UP" mark facing up. Tighten the upper bolt first, then the lower bolt to the specified torque.

**TORQUE: 12 N·m (1.2 kgf·m, 9 lbf·ft)**




Connect the front brake light switch wire connectors to the front brake light switch.



Apply Honda Bond A or equivalent to the inside surface of the left handlebar grip and to the clean surfaces of the handlebar.


*Allow the adhesive to dry for 1 hour before using.*

Wait 3-5 minutes and install the grips. Rotate the grips for even application of the adhesive.




## FRONT WHEEL/SUSPENSION/STEERING

Install the left handlebar switch housing aligning its locating pin with the hole in the handlebar.



Tighten the forward screw first, then the rear screw to the specified torque.

**TORQUE: 2.7 N·m (0.3 kgf·m, 2.0 lbf·ft)**




Install the clutch master cylinder by aligning the edge of the clutch master cylinder with the punch mark on the handlebar.


Install the clutch master cylinder holder with its direction as shown.

Tighten the upper bolt first, then the lower bolt to the specified torque.

**TORQUE: 12 N·m (1.2 kgf·m, 9 lbf·ft)**




Connect the clutch switch wire connectors to the clutch switch.




## FRONT WHEEL/SUSPENSION/STEERING

Install both handlebar weights onto the inner weights, aligning each cut-out of the weights.




Tighten both new screws while holding the weights securely.



Install the rearview mirrors.

Check the following:

- Throttle operation and grip freeplay (page 3-6)
- Clutch operation (page 3-30)



## FRONT WHEEL/SUSPENSION/STEERING

### HANDLEBAR INNER WEIGHT REPLACEMENT

Remove the left handlebar grip and throttle pipe.

Straighten the retainer tab with a screwdriver or punch.

*Apply lubricant spray through the tab locking hole for easy removal.*

Temporarily install the handlebar weight and screw, then remove the inner weight by turning the handlebar weight.

Remove the handlebar weight, retainer and rubber cushions from the inner weight.

Discard the retainer.


*Install the rubber cushion with identification mark to the inward of inner weight.*

Install the rubber cushions onto the inner weight.

Install the new retainer onto the inner weight, aligning the flats each other. Tighten new screw while holding the weight securely.

Insert the weight assembly into the handlebar. Turn the handlebar weight and hook the retainer tab with the hole in the handlebar.


Install the left handlebar grip and throttle grip.




## FRONT WHEEL

### REMOVAL

**CB1000R:** Remove the mounting bolts and left brake caliper.




**CB1000RA:** Remove the mounting bolts and left brake caliper.



Remove the axle bolt and loosen the right axle pinch bolt.

Support the motorcycle securely using a hoist or equivalent and raise the front wheel off the ground.




Loosen the left axle pinch bolt.

Pull the front axle out and remove the front wheel.


*CB1000RA: Be careful not to damage the front wheel speed sensor on the brake caliper.*

**NOTE:**

- Do not operate the brake lever after removing the wheel. To do so will cause difficulty in fitting the brake disc between the brake pads.



Remove the right and left side collars.




## INSPECTION

### Axle

Set the axle in V-block and measure the runout. Actual runout is 1/2 the total indicator reading.

**SERVICE LIMIT: 0.2 mm (0.01 in)**



## FRONT WHEEL/SUSPENSION/STEERING

### Wheel bearing

Turn the inner race of each bearing with your finger.


The bearings should turn smoothly and quietly.

Also check that the bearing outer race fits tightly in the hub.

*Replace the bearings in pairs.*

Remove and discard the bearings if they do not turn smoothly, quietly, or if they fit loosely in the hub.

Replace new bearings, if necessary (page 13-19).



### Wheel rim runout

Check the rim runout by placing the wheel in a turning stand.


Spin the wheel by hand, and read the runout using a dial indicator.

Actual runout is 1/2 the total indicator reading.

#### SERVICE LIMITS:

**Radial: 2.0 mm (0.08 in)**


**Axial: 2.0 mm (0.08 in)**




### Wheel balance

#### NOTE:

- Mount the tire with the arrow mark facing to the direction of rotation.




- The wheel balance must be checked when the tire is remounted.
- For optimum balance, the tire balance mark (light mass point: a paint dot on the side wall) must be located next to the valve stem. Remount the tire if necessary.






Mount the wheel, tire and brake disc (and pulser ring; CB1000RA) assembly on an inspection stand. Spin the wheel, allow it to stop, and mark the lowest (heaviest) part of the wheel with chalk. Do this two or three times to verify the heaviest area. If the wheel is balanced, it will not stop consistently in the same position.



To balance the wheel, install a balance weight on the lightest side of the rim, on the side opposite the chalk marks. Add just enough weight so the wheel will no longer stop in the same position when it is spun. Do not add more than 60 g (2.1 oz) to the front wheel.


**NOTE:**

- This model is equipped with a new shape balance weight made of zinc spelter. This balance weight is incompatible with the conventional one in case of installation to the wheel.




**DISASSEMBLY**

*CB1000RA only:* Remove the mounting bolts and the front pulser ring.



Remove the mounting bolts and brake discs. Remove the dust seals.




# FRONT WHEEL/SUSPENSION/STEERING


Install the bearing remover head into the bearing. From the opposite side, install the bearing remover shaft and drive the bearing out of the wheel hub. Remove the distance collar and drive out the other bearing.

**TOOLS:**

- Bearing remover head, 20 mm **07746-0050600**
- Bearing remover shaft **07GGD-0010100** or **07746-0050100**



## ASSEMBLY



*Never install the old bearings. Once the bearings has been removed, the bearing must be replaced with new ones.*


Drive in a new right bearing squarely with the marked side facing up until it is fully seated using the special tool.

**TOOLS:**

- Driver **07749-0010000**
- Attachment, 42 x 47 mm **07746-0010300**
- Pilot, 20 mm **07746-0040500**

Install the distance collar.

Using the same tools, drive in the left bearing squarely with the marked side facing up until it is fully seated on the distance collar.




*Do not get grease on the brake discs or stopping power will be reduced.*

Install the brake discs with the arrow mark facing in the direction of rotation. Install and tighten the new mounting bolts to the specified torque.

**TORQUE: 20 N·m (2.0 kgf·m, 15 lbf·ft)**


Apply grease to the dust seal lips and install the dust seals until they are flush with the wheel hub.



*CB1000RA only:*

Install the front pulser ring onto the right wheel hub. Install the new mounting bolts and tighten them to the specified torque.


**TORQUE: 7.0 N·m (0.7 kgf·m, 5.2 lbf·ft)**



**INSTALLATION**

*The right side collar is longer than the left side collar.*


Install the side collars.



Coat the axle surface with thin layer of grease.

*Be careful not to damage the brake pads and front wheel speed sensor (CB1000RA).*

Place the wheel between the fork legs so that the right brake disc is positioned between the brake pads. Insert the axle from the left side until its end is flush with the outer surface of the left fork leg.




## FRONT WHEEL/SUSPENSION/STEERING

Hold the axle and tighten the axle bolt to the specified torque.

**TORQUE: 59 N·m (6.0 kgf·m, 44 lbf·ft)**


Tighten the right axle pinch bolt to the specified torque.

**TORQUE: 22 N·m (2.2 kgf·m, 16 lbf·ft)**




*CB1000R:* Install the left brake caliper and tighten new mounting bolts to the specified torque.

**TORQUE: 45 N·m (4.6 kgf·m, 33 lbf·ft)**



*CB1000RA:* Install the left brake caliper and tighten new mounting bolts to the specified torque.

**TORQUE: 30 N·m (3.1 kgf·m, 22 lbf·ft)**




With the front brake applied, pump the fork up and down several times to seat the axle and check brake operation by applying the brake lever.



Make sure that the front axle end is flush with the outer surface of the left fork leg.  
Tighten the left axle pinch bolt to the specified torque.

**TORQUE: 22 N·m (2.2 kgf·m, 16 lbf·ft)**

*CB1000RA only:* Check the front wheel speed sensor air gap (page 16-23).



## FORK


### REMOVAL

Remove the following:

- Front wheel (page 13-16)
- Front brake calipers
  - CB1000R (page 15-37)
  - CB1000RA (page 15-41)
- Front fender (page 2-13)


**NOTE:**

If it is necessary to disassemble the fork leg, turn the pre-load, rebound and compression damping adjusters counterclockwise to the softest position (be sure to record the number of turns from the starting position).




Loosen the fork top bridge pinch bolt.

If it is necessary to disassemble the front fork, loosen the fork bolt at this moment.



Loosen the fork bottom bridge pinch bolts, remove the fork slider from the fork top bridge and steering stem.




# FRONT WHEEL/SUSPENSION/STEERING

## DISASSEMBLY

Remove the front fork bolt from the fork slider.

Push the fork slider slowly down, and gently seat the dust seal onto the axle holder.




*Be careful not to damage the spring collar holes.*

Set the spring collar holder to the spring collar holes.

**TOOL:**  
**Spring collar holder 070MF-MBZC110**


Compress the spring collar with the spring collar holder.




Insert the stopper plate between the lock nut and the spring collar.

**TOOL:**  
**Stopper plate 070MF-MBZC130**


Loosen the lock nut while holding the fork bolt.



Remove the fork bolt and O-ring.  
Remove the spring seat stopper.  
Remove the stopper plate and spring collar holder tool.




Remove the spring collar and fork spring from the fork slider.



Pour out the fork fluid by pumping the fork slider several times.

And also pour out the fork fluid from the fork damper by pumping the fork damper rod several times.




Remove the axle pinch bolt.


Hold the axle holder in a vice with soft jaws or a shop towel.

Hold the fork damper with the fork damper holder attachment, then remove the fork socket bolt and sealing washer.

**TOOL:**  
Fork damper holder attachment 07YMB-MCF0101



Remove the fork damper from the fork pipe.




## FRONT WHEEL/SUSPENSION/STEERING


Remove the dust seal.

*Do not scratch the fork pipe sliding surface.*


Remove the stopper ring.



Pull the fork pipe out until you feel resistance from the slider bushing. Then move it in and out, tapping the bushing lightly until the fork pipe separates from the fork slider. The slider bushing will be forced out by the fork pipe bushing.




Remove the slider bushing, back-up ring, oil seal, stopper ring and dust seal from the fork pipe.



*Do not remove the fork pipe bushing unless it necessary to replace it with a new one.*

Carefully remove the fork pipe bushing by prying the slit with a screwdriver until the bushing can be pulled off by hand.






**INSPECTION**

**Fork spring**

Measure the fork spring free length.

**SERVICE LIMIT: 244.7 mm (9.63 in)**




**Fork pipe/slider/fork damper**

Check the fork pipe and fork slider for score marks, scratches, deformation, or excessive or abnormal wear.

Replace any components which are worn or damaged.


CB1000RA shown:



Check the fork damper for bend or damage.

Check the oil lock valve for wear or damage.

Replace the fork damper, if any components is damaged.




Place the fork pipe in V-block and measure the runout.

Actual runout is 1/2 of the total indicator reading.

**SERVICE LIMIT: 0.20 mm (0.008 in)**

CB1000RA shown:




# FRONT WHEEL/SUSPENSION/STEERING

## Fork pipe bushing/slider bushing/back-up ring


Visually inspect the slider and fork pipe bushings.

Replace the bushings if there is excessive scoring or scratching, or if the teflon is worn so that the copper surface appears on more than 3/4 of the entire surface.

Check the back-up ring; replace it if there is any distortion at the points shown.




## ASSEMBLY



# FRONT WHEEL/SUSPENSION/STEERING

- Before assembly, wash all parts with a high flash or non-flammable solvent and wipe them dry.
- When installing the fork dust seal and the oil seal, wrap the edge and groove of the fork pipe with a tape.



Apply fork fluid to new dust seal lips and new oil seal lips.


*Install the oil seal with its marked side facing toward the axle holder.*

Install the dust seal, stopper ring and oil seal.

*Remove the burrs from the slider bushing mating surface, being careful not to peel off the coating.*

Install the back-up ring, slider bushing and a new fork pipe bushing.

Install the fork pipe into the fork slider.




Drive the oil seal in using the special tools.

**TOOL:**

**Fork seal driver**


**07YMD-MCF0100**



*Do not scratch the fork pipe sliding surface.*

Install the stopper ring into the fork slider groove securely.


Install the dust seal into the fork slider securely.



## FRONT WHEEL/SUSPENSION/STEERING


Install the fork damper into the fork pipe.

CB1000RA shown:



Apply a locking agent to the fork socket bolt threads.

Install the socket bolt with a new sealing washer.



Hold the axle holder in a vise with soft jaws or a shop towel.


Hold the fork damper with fork damper holder attachment then tighten the fork socket bolt to the specified torque.

### TOOL:

Fork damper holder attachment 07YMB-MCF0101

TORQUE: 34 N·m (3.5 kgf·m, 25 lbf·ft)

CB1000RA shown:



Pour the specified amount of recommended fork fluid into the fork slider.

### RECOMMENDED FORK FLUID:

Honda ULTRA CUSHION OIL 10W or equivalent

FORK FLUID CAPACITY (CB1000R):


$511 \pm 2.5 \text{ cm}^3$

( $17.3 \pm 0.08 \text{ US oz}$ ,  $18.0 \pm 0.09 \text{ Imp oz}$ )

FORK FLUID CAPACITY (CB1000RA):

$542 \pm 2.5 \text{ cm}^3$


( $18.4 \pm 0.08 \text{ US oz}$ ,  $19.1 \pm 0.09 \text{ Imp oz}$ )



Bleed the air from the fork leg as follows.

1. Extend the fork, cover the top of the fork slider with your hand and compress the fork leg slowly.
2. Remove your hand and extend the fork slowly.  
Repeat above procedure 2 or 3 times.
3. Pump the fork damper rod slowly 8 - 10 times.

CB1000RA shown:



*Be sure that the oil level is the same in the both forks.*

Slowly push the slider, gently seat the dust seal onto axle holder and leave it for 5 minutes.

After the oil level stabilizes, measure the oil level from top of the fork slider.


**FORK OIL LEVEL (CB1000R):**

**91 mm (3.6 in)**


**FORK OIL LEVEL (CB1000RA):**

**67 mm (2.6 in)**

FORK SLIDER TOP



Pull the fork damper rod up and install the fork spring into the fork pipe with the tapered end facing up.



Attach the fork damper holder to the fork damper.


**TOOL:**

**Fork damper holder 070MF-MBZC120**

Install the fork spring collar.


FORK DAMPER HOLDER

SPRING COLLAR



## FRONT WHEEL/SUSPENSION/STEERING

Set the lock nut to the damper rod by turning the lock nut clockwise fully.



Set the spring collar holder to the spring collar holes.

**TOOL:**

**Spring collar holder** 070MF-MBZC110



Compress the spring collar with the spring collar holder while pulling up the fork damper holder. Install the stopper plate between the lock nut and the spring collar.

**TOOL:**

**Stopper plate** 070MF-MBZC130

Remove the fork damper holder.

Install the spring seat stopper.




**NOTE:**

When installing the fork bolt, turn the rebound adjuster counterclockwise to the softest position.

Apply fork fluid to a new O-ring and install it to the fork bolt.

Install the fork bolt to the fork damper rod by turning the fork bolt clockwise fully.




Turn the lock nut counterclockwise until it stops against the fork bolt.

Tighten the lock nut to the specified torque while holding the fork bolt.


**TORQUE: 20 N·m (2.0 kgf·m, 15 lbf·ft)**

Remove the stopper plate and the spring collar holder tool.



*Tighten the fork bolt after installing the fork.*


Install the fork bolt to the fork slider.



**INSTALLATION**


Install the fork leg through the steering stem and top bridge.

Align the top end of the fork slider with the upper surface of the top bridge.



Tighten the bottom bridge pinch bolts to the specified torque.

**TORQUE: 27 N·m (2.8 kgf·m, 20 lbf·ft)**



## FRONT WHEEL/SUSPENSION/STEERING

Tighten the fork bolt to the specified torque if it was removed.

**TORQUE: 34 N·m (3.5 kgf·m, 25 lbf·ft)**


Tighten the top bridge pinch bolt to the specified torque.

**TORQUE: 22 N·m (2.2 kgf·m, 16 lbf·ft)**

Return the pre-load, rebound and compression damping adjusters to the original positions as noted during disassembly.

Install the following:

- Front fender (page 2-13)
- Front brake calipers
  - CB1000R (page 15-40)
  - CB1000RA (page 15-44)
- Front wheel (page 13-21)




## STEERING STEM

### REMOVAL

Remove the following:


- Headlight unit (page 20-6)
- Front wheel (page 13-16)

Release the immobilizer receiver 4P (Black) and ignition switch 2P (Blown) connectors from the guide on the ignition switch, then disconnect the connectors.



Release the right handlebar switch wire and left handlebar switch wire clamps from the ignition switch.


Release the right handlebar switch 6P (Black) and left handlebar switch 10P (Black) connectors from the guide on the headlight stay, then disconnect the connectors.



*CB1000R:* Release the front brake hose from the guide of the headlight stay.

Release the clutch hose from the guide of the headlight stay.

Remove the main wire harness clip from the headlight stay.






## FRONT WHEEL/SUSPENSION/STEERING

**CB1000RA:** Release the front brake hose from the guide of the headlight stay.

Release the clutch hose from the guide of the headlight stay.


Remove the main wire harness clip from the headlight stay.

BRAKE HOSE GUIDE CLUTCH HOSE GUIDE



Remove the handlebar (page 13-8).


**CB1000R:** Remove the bolt, clamp and the brake hose.




**CB1000RA:** Remove the front wheel speed sensor wire clip from the brake pipe joint.  
Remove the bolt and clamp, then separate the brake pipe joints.

**NOTE:**

Be careful not to bend or damage the brake pipes.




Remove the steering stem nut cap.




## FRONT WHEEL/SUSPENSION/STEERING

Remove the steering stem nut.


Loosen the fork top bridge pinch bolts and remove the forks (page 13-23).



Remove the fork top bridge from the steering stem and grommets on the headlight stay.




Remove the headlight stay from the steering stem.




Straighten the tabs of the lock washer.

Remove the steering stem adjusting lock nut and lock washer.




Remove the steering stem adjusting nut using the special tool.

**TOOL:**  
Steering stem socket 07916-3710101



Remove the following:

- Dust seal
- Upper bearing inner race
- Upper bearing
- Steering stem
- Lower bearing




**OUTER RACE REPLACEMENT**

*Always replace the bearings and races as a set.*

Replace the races using the special tools as described in the following procedure.

**TOOLS:**

(1) Driver attachment (upper)	070MF-MCJ0100
(2) Driver attachment (lower)	070MF-MCJ0200
(3) Driver shaft assembly	07946-KM90301
(4) Bearing remover, A	07946-KM90401
(5) Bearing remover, B	07NMF-MT70110
(6) Assembly base	07946-KM90600



## FRONT WHEEL/SUSPENSION/STEERING


Note the installation direction of the assembly base; the small I.D. side facing the upper attachment.

Install the special tools into the steering head as shown.

Align the bearing remover A with the grooves in the steering head.

Lightly tighten the nut B with a wrench.


Holding the driver shaft with a wrench, turn the nut A gradually to remove the upper outer race.



Note the installation direction of the assembly base; the large I.D. side facing the lower attachment.

Be careful not to bend or damage the brake pipes (CB1000RA only).


Install the special tools into the steering head as shown and remove the lower outer race using the same procedure as for the upper outer race.



Remove any burrs from the outer race installation surface of the steering head.


*Note the installation direction of the assembly base; the large I.D. side facing the lower attachment. Be careful not to bend or damage the brake pipes (CB1000RA only).*

Install a new upper outer race with the special tools as shown. Hold the driver shaft with a wrench and turn the nut A gradually until upper outer race is fully seated.



*Note the installation direction of the assembly base; the small I.D. side facing the upper attachment.*

Install a new lower outer race with the special tools as shown. Hold the driver shaft with a wrench and turn the nut A gradually until lower outer race is fully seated.




## LOWER INNER RACE REPLACEMENT

Temporarily install the steering stem nut onto the stem to prevent the threads from being damaged when removing the lower bearing inner race from the stem.

Remove the lower bearing inner race with a chisel or equivalent tool, being careful not to damage the stem.


Remove the dust seal.




Apply urea based multi-purpose grease to a new dust seal lips and install it over the steering stem. Install a new lower bearing inner race using a special tool and a hydraulic press.

### TOOL:


Steering stem driver 07946-MB00000



INSTALLATION




Apply urea based multi-purpose grease to upper and lower bearings and bearing races.  
Install the lower bearing onto the steering stem.  
Insert the steering stem into the steering head pipe.  
Install upper bearing, inner race and dust seal.



Apply engine oil to the steering stem adjusting nut threads.  
Install and tighten the steering stem adjusting nut to the initial torque.


**TOOL:**  
Steering stem socket 07916-3710101

**TORQUE:** 26 N·m (2.7 kgf·m, 19 lbf·ft)



## FRONT WHEEL/SUSPENSION/STEERING

Move the steering stem right and left, lock-to-lock, five times to seat the bearings.  
Make sure that the steering stem moves smoothly, without play or binding.




Retighten the steering stem adjusting nut to the specified torque.

**TOOL:**

**Steering stem socket 07916-3710101**


**TORQUE: 26 N·m (2.7 kgf·m, 19 lbf·ft)**

Recheck that the steering stem moves smoothly without play or binding.



Install a new lock washer onto the steering stem.


Align the tabs of the lock washer with the grooves in the steering adjusting nut and bend two opposite tabs (shorter) down into the adjusting nut groove.



*Do not over tightness adjusting lock nut until lock washer being flat.*


Install and finger tighten the adjusting lock nut, further finger tighten the lock nut within 1/4 turn (90°) enough to align its grooves with the lock washer tabs.

Bend the lock washer tabs up into the adjusting lock nut groove.







Install the headlight stay to the steering stem aligning the stay grommets with the holes on the steering stem.



Install the top bridge to the steering stem while aligning its holes to the grommets on the headlight stay.




Install the steering stem nut.  
Install the fork legs (page 13-33).



Tighten the steering stem nut to the specified torque.

**TORQUE: 103 N·m (10.5 kgf·m, 76 lbf·ft)**

Install the handlebar (page 13-11).




## FRONT WHEEL/SUSPENSION/STEERING

Install the steering stem nut cap to the steering stem nut.

Tighten the top bridge pinch bolts to the specified torque.


**TORQUE: 22 N·m (2.2 kgf·m, 16 lbf·ft)**

Install the handlebar (page 13-11).




**CB1000R:** Install the front brake hose clamp with a new bolt and tighten the bolt to the specified torque.

**TORQUE: 12 N·m (1.2 kgf·m, 9 lbf·ft)**



**CB1000RA:** Assemble the brake pipe joints and clamp, then install and tighten the bolt securely.  
*Be careful not to bend or damage the brake pipes.*


Install the front wheel speed sensor wire clip to the brake pipe joint securely.




**CB1000R:** Install the main wire harness clip to the headlight stay.

Install the clutch hose to the guide of the headlight stay.


Install the front brake hose to the guide of the headlight stay.



*CB1000RA:* Install the main wire harness clip to the headlight stay.  
 Install the clutch hose to the guide of the headlight stay.  
 Install the front brake hose to the guide of the headlight stay.




Connect the right handlebar switch 6P (Black) and left handlebar switch 10P (Black) connectors.  
 Install the right handlebar switch 6P (Black) and left handlebar switch 10P (Black) connectors to the guide on the headlight stay.  
 Install the right handlebar switch wire and left handlebar switch wire clips to the ignition switch.



Connect the immobilizer receiver 4P (Black) and ignition switch 2P (Blown) connectors.  
 Install the immobilizer receiver 4P (Black) and ignition switch 2P (Blown) connectors to the guide on the ignition switch.

- Remove the following:
- Front wheel (page 13-21)
  - Headlight unit (page 20-6)




**STEERING HEAD BEARING PRE-LOAD**

Support the motorcycle securely using safety stands or a hoist and raise the front wheel off the ground.  
 Position the steering stem straight ahead.  
 Hook a spring scale to the fork tube between the fork top and bottom bridges.  
 Make sure there is no cable, wire harness or hoses interference.  
 Pull the spring scale keeping it at a right angle to the steering stem.  
 Read the scale at the point where the steering stem just starts to move.

**STEERING BEARING PRE-LOAD:**  
 9.8 – 12.5 N (1.0 – 1.3 kgf, 2.2 – 2.9 lbf)

If the readings do not fall within the limits, readjust the steering bearing adjustment.



---

**MEMO**

---

# 14. REAR WHEEL/SUSPENSION


---

COMPONENT LOCATION .....	14-2	DRIVEN FLANGE .....	14-12
SERVICE INFORMATION .....	14-3	REAR AXLE/BRAKE DISC .....	14-16
TROUBLESHOOTING .....	14-5	REAR AXLE ASSEMBLY .....	14-17
REAR WHEEL .....	14-6	SHOCK ABSORBER .....	14-20
REAR AXLE DISASSEMBLY .....	14-7	SWINGARM .....	14-25
BEARING HOLDER .....	14-9		

# REAR WHEEL/SUSPENSION

## COMPONENT LOCATION

CB1000RA shown:



# SERVICE INFORMATION

## GENERAL

- A contaminated brake disc or pad reduces stopping power. Discard contaminated pads and clean a contaminated disc with a high quality brake degreasing agent.
- After the rear wheel installation, check the brake operation by applying the brake lever and pedal (CB1000RA).
- The shock absorber contains nitrogen under high pressure. Do not allow fire or heat near the shock absorber.
- Before disposal of the shock absorber, release the nitrogen (page 14-23).
- When servicing the rear wheel and suspension, support the motorcycle using a safety stand or hoist.
- Use only tires marked "TUBELESS" and tubeless valves on rim marked "TUBELESS TIRE APPLICABLE".
- Use genuine Honda replacement bolts and nuts for all suspension pivot and mounting point.
- Refer to the brake system information (page 15-4).

## SPECIFICATIONS

Unit: mm (in)













ITEM		STANDARD	SERVICE LIMIT
Minimum tire tread depth		—	2.0 (0.08)
Cold tire pressure	Driver only	290 kPa (2.90 kgf/cm <sup>2</sup> , 42 psi)	—
	Driver and passenger	290 kPa (2.90 kgf/cm <sup>2</sup> , 42 psi)	—
Axle runout		—	0.2 (0.01)
Wheel rim runout	Radial	—	2.0 (0.08)
	Axial	—	2.0 (0.08)
Wheel balance weight		—	60 g (2.1 oz) max.
Drive chain	Size/link	DID	DID50VA8-116YB
	Slack		25 – 35 (1 – 1-3/8)
Shock absorber	spring pre-load adjuster standard position		Position 3
	Rebound adjuster initial setting		1-1/2 turns out from full hard

## TOEQUE VALUES







Rear axle nut	201 N·m (20.5 kgf·m, 148 lbf·ft)	Stake
Rear wheel nut	108 N·m (11.0 kgf·m, 80 lbf·ft)	
Rear brake disc nut	34 N·m (3.5 kgf·m, 25 lbf·ft)	U-nut
Driven sprocket nut	64 N·m (6.5 kgf·m, 47 lbf·ft)	
Shock absorber mounting nut	42 N·m (4.3 kgf·m, 31 lbf·ft)	U-nut
Swingarm pivot nut	98 N·m (10.0 kgf·m, 72 lbf·ft)	U-nut
Footpeg holder mounting bolt	37 N·m (3.8 kgf·m, 27 lbf·ft)	
Axle bearing holder pinch bolt	74 N·m (7.5 kgf·m, 54 lbf·ft)	
Drive chain slider socket bolt	4.2 N·m (0.4 kgf·m, 3.0 lbf·ft)	ALOC bolt; replace with a new one.
Drive chain guide socket bolt	4.2 N·m (0.4 kgf·m, 3.0 lbf·ft)	ALOC bolt; replace with a new one.
Drive chain case A mounting bolt	4.2 N·m (0.4 kgf·m, 3.0 lbf·ft)	
Drive chain case B mounting bolt	1.7 N·m (0.2 kgf·m, 1.0 lbf·ft)	
Air guide mounting bolt	4.2 N·m (0.4 kgf·m, 3.0 lbf·ft)	ALOC bolt; replace with a new one.
Rear brake caliper mounting bolt	30 N·m (3.1 kgf·m, 22 lbf·ft)	ALOC bolt; replace with a new one.
Pivot bracket upper nut	69 N·m (7.0 kgf·m, 51 lbf·ft)	
Pivot bracket lower nut	69 N·m (7.0 kgf·m, 51 lbf·ft)	

# REAR WHEEL/SUSPENSION

## TOOLS

<p>Remover weight 07741-0010201</p> 	<p>Attachment, 32 X 35 mm 07746-0010100</p> 	<p>Attachment, 37 x 40 mm 07746-0010200</p> 
<p>Attachment, 42 x 47 mm 07746-0010300</p> 	<p>Attachment, 52 x 55 mm 07746-0010400</p> 	<p>Attachment, 62 x 68 mm 07746-0010500</p> 
<p>Attachment, 24 x 26 mm 07746-0010700</p> 	<p>Pilot, 17 mm 07746-0040400</p> 	<p>Pilot, 20 mm 07746-0040500</p> 
<p>Pilot, 35 mm 07746-0040800</p> 	<p>Pilot, 40 mm 07746-0040900</p> 	<p>Pilot, 28 mm 07746-0041100</p> 



<p>Driver 07749-0010000</p> 	<p>Bearing remover handle 07936-3710100</p> 	<p>Bearing remover head 07936-3710600</p> 
<p>Driver shaft 07946-MJ00100</p> 	<p>Needle bearing remover 07HMC-MR70100</p> 	<p>Socket wrench, 46 mm 07JMA-MN50100</p> 

## TROUBLESHOOTING

### Soft suspension

- Weak shock absorber spring
- Incorrect suspension adjustment
- Oil leakage from damper unit
- Insufficient tire pressure

### Hard suspension

- Incorrect suspension adjustment
- Damaged rear suspension pivot bearings
- Bent damper rod
- Incorrect swingarm pivot fasteners tightening
- Tire pressure too high

### Rear wheel wobbling

- Bent rim
- Worn or damaged rear axle bearings
- Faulty rear tire
- Unbalanced rear tire and wheel
- Insufficient rear tire pressure
- Faulty swingarm pivot bearings

### Steers to one side or does not track straight

- Bent rear axle

### REAR WHEEL


#### REMOVAL

Remove the muffler (page 2-19).

Loosen the wheel nuts.

Support the motorcycle securely using a hoist or equivalent and raise the rear wheel off the ground.

Remove the wheel nuts and rear wheel.



#### INSPECTION

##### Wheel rim runout

Check the rim runout by placing the wheel in a turning stand.

Spin the wheel slowly and read the runout using a dial indicator.

Actual runout is 1/2 the total indicator reading.


##### SERVICE LIMITS:

Radial: 2.0 mm (0.08 in)

Axial: 2.0 mm (0.08 in)

##### Wheel balance


Refer to the wheel balance servicing (page 13-18).



##### Wheel bolt hole

Check the wheel bolt holes for wear, clacks or other damage.

Clean the axle hub mating surface of the wheel.




**INSTALLATION**

Install the rear wheel in the reverse order of removal.

Tighten the wheel nut to the specified torque.


**TORQUE: 108 N·m (11.0 kgf·m, 80 lbf·ft)**

Install the muffler (page 2-19)



**REAR AXLE DISASSEMBLY**

Remove the rear axle nut cap.



Unstake the rear axle nut.


Loosen the axle nut while applying the rear brake.

**TOOL:**

**Socket wrench, 46 mm      07JMA-MN50100**


Remove the nut and cone washer.

Remove the rear wheel (page 14-6).




Loosen the axle bearing holder pinch bolt.

Turn the bearing holder to loosen the drive chain using a equipped pin spanner.




## REAR WHEEL/SUSPENSION

Remove the mounting bolts and the air guide.




Derail the drive chain from the driven sprocket.  
Remove the driven flange assembly from the axle.




Remove the rear brake caliper mounting bolts.  
Remove the caliper from the brake disc.


*Do not operate the  
brake pedal or lever  
(CB1000RA) after  
the brake caliper is  
removed.*




Remove the rear axle/brake disc assembly.




CB1000RA: Remove the mounting bolts and rear wheel speed sensor.



Remove the snap ring and brake caliper stay.



Remove the bearing holder from the swingarm.



## BEARING HOLDER

### BEARING REPLACEMENT

Turn the inner race of each radial bearing with your finger.

Bearings should turn smoothly and quietly. Also check that the bearing outer race fits tightly in the bearing holder.


Check the needle bearing for obvious signs of wear.

*Always replace the bearings in pairs.*

Remove and discard the radial ball bearings if the races do not turn smoothly and quietly, or if they fit loosely in the bearing holder.

Replace the needle bearing if it is wear or damaged.


Remove the collar and dust seals.



## REAR WHEEL/SUSPENSION

Remove the retaining rings from each side.

RETAINING RING



Press the ball bearing (6908LUX2) out of the bearing holder first using the special tools and a hydraulic press.

**TOOLS:**

Driver


07749-0010000

Attachment, 42 x 47 mm

07746-0010300

Pilot, 40 mm

07746-0040900



Press the needle bearing out from the bearing holder using the special tools and a hydraulic press.


**TOOLS:**

Driver


07749-0010000

Attachment, 52 x 55 mm


07746-0010400



BEARING HOLDER ILLUSTRATION



Fill the new needle bearing with multi-purpose grease.




Install the bearing with the marking facing out.

Press it into the bearing holder using the special tools and a hydraulic press.

**TOOLS:**

**Driver**  
**Attachment, 62 x 68 mm**

**07749-0010000**  
**07746-0010500**



## REAR WHEEL/SUSPENSION

Install the bearing with the marking facing out.

Press the new ball bearing (6908LUX2) into the bearing holder using the special tools and a hydraulic press.

### TOOLS:

Driver


07749-0010000

Attachment, 62 x 68 mm

07746-0010500


Pilot, 40 mm

07746-0040900



Install the retaining rings into the each holder groove securely.


RETAINING RING



Apply molybdenum disulfide grease to the new dust seal lips, then install them into the bearing holder.

Install the collar to the left side of the bearing holder.


COLLAR



## DRIVEN FLANGE

### DISASSEMBLY


Remove the driven sprocket nuts/bolts/washers and the driven sprocket.






## REAR WHEEL/SUSPENSION


Remove the collar and dust seal from the driven sprocket hub.



Separate the driven flange/O-ring from the driven sprocket hub.




Remove the distance collar.  
Remove the damper rubbers from the driven sprocket hub.



*Replace the damper rubber as a set.*

Check the damper rubbers for wear or damage, replace if necessary.

DAMPER RUBBER




## REAR WHEEL/SUSPENSION

Check the condition of the final driven sprocket teeth.

Replace the sprocket if it is worn or damaged.

- If the final driven sprocket requires replacement, inspect the drive chain and drive sprocket.
- Never install a new drive chain on a worn sprocket or a worn chain on new sprockets. Both chain and sprocket must be in good condition or the replacement chain or sprocket will wear rapidly.


DRIVEN SPROCKET



### DRIVEN SPROCKET HUB BEARING INSPECTION/REPLACEMENT

Turn the inner race of the bearing with your finger. The bearing should turn smoothly and quietly. Also check that the bearing outer race fits tightly in the driven sprocket hub.


Remove and discard the ball bearing if the races do not turn smoothly and quietly, or if they fit loosely in the driven sprocket hub.



Press the bearing out from the driven sprocket hub using the special tools and a hydraulic press.

#### TOOLS:


Driver	07749-0010000
Attachment, 42 x 47 mm	07746-0010300
Pilot, 35 mm	07746-0040800




Press the new bearing into the driven sprocket hub using the special tools and a hydraulic press.

#### TOOLS:


Driver	07749-0010000
Attachment, 52 x 55 mm	07746-0010400
Pilot, 35 mm	07746-0040800




ASSEMBLY



Install the damper rubbers and distance collar into the driven sprocket hub.




Apply molybdenum disulfide grease to a new O-ring and install it onto the driven flange. Install the driven flange onto the driven sprocket hub.



## REAR WHEEL/SUSPENSION

Apply grease to the dust seal lips, install it into the driven sprocket hub.  
Install the collar.




Install the driven sprocket onto the hub.

*Install the washers with their chamfered side facing the driven sprocket.*

Install the washers, driven sprocket bolts and nuts.  
Tighten the nut to the specified torque.

**TORQUE: 64 N·m (6.5 kgf·m, 47 lbf·ft)**




## REAR AXLE/BRAKE DISC

### BRAKE DISC REPLACEMENT

Remove the rear brake disc nuts.

**CB1000RA:** Remove the bolts, nuts, rear wheel pulser ring and rear brake disc from the rear axle flange.

**CB1000R:** Remove the bolts, nuts and rear brake disc from the axle flange.




### AXLE INSPECTION

Check the axle for runout or other damage.

**SERVICE LIMIT: 0.2 mm (0.01 in)**

Replace the axle if necessary.



## REAR WHEEL/SUSPENSION


Install the brake disc with its rotating direction mark facing out.

Install the rear brake disc bolts.


**CB1000RA:** Install the rear wheel pulser ring onto the axle flange.

Install the rear brake disc nuts and tighten the nuts to the specified torque.


**TORQUE: 34 N·m (3.5 kgf·m, 25 lbf·ft)**



## REAR AXLE ASSEMBLY




Clean the bearing holder mating surfaces of the swingarm.




## REAR WHEEL/SUSPENSION

Install the bearing holder into the swingarm.




Install the rear brake caliper stay onto the bearing holder while aligning the groove on the rear brake caliper stay with the guide pin on the swingarm.


Install the snap ring to the bearing holder groove securely.



CB1000RA: Install the rear wheel speed sensor onto the caliper bracket, tighten the mounting bolts securely.




Install the rear axle/brake disc assembly from the right side through the bearing holder.




Install the rear brake caliper over the brake disc, tighten the new mounting bolts to the specified torque.

**TORQUE: 30 N·m (3.1 kgf·m, 22 lbf·ft)**




Install the driven flange assembly onto the rear axle while aligning the splines. Install the drive chain over the driven sprocket.




Install the air guide to the swingarm, then tighten new mounting bolts to the specified torque.

**TORQUE: 4.2 N·m (0.40 kgf·m, 3.0 lbf·ft)**



Install the cone washer with its marking facing out. Install the rear wheel (page 14-7).



## REAR WHEEL/SUSPENSION

Install the axle nut.


Operate the brake pedal to seat the caliper piston against the pads.

Tighten the rear axle nut to the specified torque while applying the rear brake.


**TOOL:**

Socket wrench, 46 mm      07JMA-MN50100

**TORQUE:** 201 N·m (20.5 kgf·m, 148 lbf·ft)




*Be careful not to damage the rear axle threads.* Stake the rear axle nut against the rear axle groove.



Install the rear axle nut cap.

Adjust the drive chain slack by turning the bearing holder (page 3-21).



## SHOCK ABSORBER


### REMOVAL

Remove the side cover (page 2-5).

Remove the muffler (page 2-19)


Support the motorcycle securely using a hoist or equivalent and raise the rear wheel off the ground.

Remove the mounting bolts and the left footpeg holder.







Remove the mounting bolt and the drive chain case B.




*CB1000RA:* Remove the rear wheel speed sensor wire clamp from the rear fender B.



Remove the shock absorber lower mounting nut and bolt.




Remove the shock absorber upper mounting nut and bolt, then remove the shock absorber from the frame.




## REAR WHEEL/SUSPENSION

### INSPECTION

Check the damper unit for leakage or other damage.  
Check the upper joint bushing for wear or damage.  
Replace the shock absorber assembly if necessary.




Remove the pivot collar.  
Check the needle bearing, pivot collar and dust seals for wear or damage.



### NEEDLE BEARING REPLACEMENT


Remove the pivot collar and dust seals.




Press out the needle bearing out of the shock absorber lower mount using the special tools.

#### TOOLS:


Driver shaft	07946-MJ00100
Attachment, 24 x 26 mm	07746-0010700
Pilot, 17 mm	07746-0040400



Press the needle bearing into the lower mount so that the needle bearing surface is lower 5.0 – 5.5 mm (0.20 – 0.21 in) from the end of the lower mount using the same tools.



Apply grease (REPSOL MP2) to the new dust seal lips, install them into the lower mount. Install the pivot collar.




**SHOCK ABSORBER DISPOSAL PROCEDURE**

Center punch the damper case to mark the drilling point.

Wrap the shock absorber inside a plastic bag. Support the shock absorber upright in a vise as shown.

Through the open end of the bag, insert a drill motor with a sharp 2 - 3 mm (5/64 - 1/8 in) drill bit.

*Do not release the nitrogen unless the shock absorber is abandoned.* Hold the bag around the drill motor and briefly run the drill motor inside the bag; this will inflate the bag with air from the motor and help keep the bag from getting caught in the bit when you start.




## REAR WHEEL/SUSPENSION

### INSTALLATION

Install the shock absorber into the frame with the rebound damping adjuster facing to the right.


Install the lower mounting bolt and tighten the lower mounting nut to the specified torque.

**TORQUE: 42 N·m (4.3 kgf·m, 31 lbf·ft)**




Install the upper mounting bolt and tighten the upper mounting nut to the specified torque.

**TORQUE: 42 N·m (4.3 kgf·m, 31 lbf·ft)**




*CB1000RA:* Install the rear wheel speed sensor wire clamp to the rear fender B.



Install the drive chain case B with its groove to the pin on the swingarm and tighten the mounting bolt to the specified torque.


**TORQUE: 1.7 N·m (0.2 kgf·m, 1.0 lbf·ft)**



Install the left footpeg holder and tighten the mounting bolts to the specified torque.

**TORQUE: 37 N·m (3.8 kgf·m, 27 lbf·ft)**

Install the muffler (page 2-23).  
Install the side cover (page 2-5).



## SWINGARM

### REMOVAL

Remove the following:




- Side cover (page 2-5).
- Drive sprocket (page 7-4).
- Rear wheel (page 14-6)
- Rear axle (page 14-7)
- Rear axle bearing holder (page 14-9)

Remove the axle bearing holder pinch bolt and washer.

*CB1000RA:* Remove the rear wheel speed sensor wire clips from the drive chain case A.


Remove the clamp bolt, then remove the brake pipe from the guides on the drive chain case A.

Remove the mounting bolts and the drive chain case A.




## REAR WHEEL/SUSPENSION


Remove the clamp bolt, then remove the brake pipe from the swingarm.




Remove the mounting bolts and the left footpeg holder.




Remove the mounting bolt and the drive chain case B.



Remove the shock absorber lower mounting nut and bolt.




Remove the pivot bracket upper and lower nuts.  
Remove the washers.




Hold the swingarm pivot bolt and loose and remove the swingarm pivot nut and washer.

Remove the pivot bolt, then remove the swingarm assembly.




### DISASSEMBLY/INSPECTION

Remove the socket bolts and drive chain guide.  
Check the drive chain guide for wear or damage.




Remove the socket bolts and drive chain slider.  
Check the drive chain slider for wear or damage.




## REAR WHEEL/SUSPENSION

Remove the guide pin and O-ring from the swingarm.




Remove the pivot collar and dust seals from the swingarm left pivot.

Check the dust seals and pivot collar for damage or fatigue.



Remove the pivot collars and dust seals from the swingarm right pivot.


Check the dust seals and pivot collars for damage or fatigue.



Turn the inner race of right pivot bearings with your finger.

The bearings should turn smoothly and quietly. Also check that the bearing outer race fits tightly in the hub.


Remove and discard the bearings if the races do not turn smoothly and quietly, or if they fit loosely in the pivot.





**PIVOT BEARING REPLACEMENT**


Remove the snap ring.



Remove the right pivot radial ball bearings using the special tools.

**TOOLS:**


- Bearing remover handle                   07936-3710100
- Bearing remover head                   07936-3710600
- Remover weight                           07741-0010201



Press the left pivot needle bearing out using the special tools and a hydraulic press.

**TOOLS:**

- Needle bearing remover               07HMC-MR70100
- Driver shaft                               07946-MJ00100




Pack new needle bearing with molybdenum disulfide grease.

Press the needle bearing into the swingarm left pivot until the depth from the swingarm outer surface is 5.0 – 6.0 mm (0.20 – 0.34 in) using the special tools and a hydraulic press.

**TOOLS:**

- Driver                                       07749-0010000
- Attachment, 37 x 40 mm               07746-0010200
- Pilot, 28 mm                              07746-0041100




# REAR WHEEL/SUSPENSION

Press new right pivot bearings (radial ball bearing) in until it seat, using the special tools and a hydraulic press.


**TOOLS:**

- Driver
- Attachment, 32 x 35 mm
- Pilot, 20 mm


- 07749-0010000
- 07746-0010100
- 07746-0040500



Install the snap ring into the groove securely.



## ASSEMBLY




## REAR WHEEL/SUSPENSION


Apply molybdenum disulfide grease to the dust seal lips, then install the dust seals into the right swingarm pivot.

Install the pivot collar (long) into the outside of the right swingarm pivot.


Install the pivot collar (short) into the inside of the right swingarm pivot.




Apply molybdenum disulfide grease to the dust seal lips, then install the dust seals and pivot collar into the left swingarm pivot.



Install the guide pin and new O-ring to the swingarm.




Install the drive chain slider bosses into the hole in the swingarm while aligning the groove on the drive chain slider with the tab on the swingarm.



## REAR WHEEL/SUSPENSION

Install and tighten new drive chain slider socket bolts to the specified torque.


**TORQUE: 4.2 N·m (0.4 kgf·m, 3.0 lbf·ft)**



Install the drive chain guide.

Install and tighten new drive chain guide socket bolts to the specified torque.

**TORQUE: 4.2 N·m (0.4 kgf·m, 3.0 lbf·ft)**




## INSTALLATION

Install the swingarm onto the engine and pivot bracket.


Apply thin coat of grease to the swingarm pivot bolt surface.

Install the swingarm pivot bolt from the left side.



Install the washer and swingarm pivot nut, then tighten the pivot nut to the specified torque with the washer.


**TORQUE: 98 N·m (10.0 kgf·m, 72 lbf·ft)**



## REAR WHEEL/SUSPENSION


Install the pivot bracket upper and lower nuts with washers.  
Tighten the pivot bracket upper and lower nuts to the specified torque.

**TORQUE: 69 N·m (7.0 kgf·m, 51 lbf·ft)**




Install and tighten the shock absorber lower mounting bolt and nut.  
Tighten the shock absorber lower mounting nut to the specified torque.

**TORQUE: 42 N·m (4.3 kgf·m, 31 lbf·ft)**




Install the drive chain case B with its groove to the pin on the swingarm and tighten the mounting bolt to the specified torque.

**TORQUE: 1.7 N·m (0.2 kgf·m, 1.0 lbf·ft)**




Install the left footpeg holder and tighten the mounting bolts to the specified torque.

**TORQUE: 37 N·m (3.8 kgf·m, 27 lbf·ft)**




## REAR WHEEL/SUSPENSION

Install the brake pipe clamp to the swingarm.  
Install and tighten the clamp bolt securely.




Install the drive chain case A to the swingarm.  
Install and tighten the mounting bolts to the specified torque.

**TORQUE: 4.2 N-m (0.4 kgf-m, 3.0 lbf-ft)**



Install the brake pipe to the guides on the drive chain case A.  
Install and tighten the brake pipe clamp bolt securely.




*CB1000RA:* Install the rear wheel speed sensor wire clips to the drive chain case A.

Install the axle bearing holder pinch bolt and washer.

Install the following:

- Rear axle bearing holder (page 14-9)
- Rear axle (page 14-17)
- Rear wheel (page 14-7)
- Drive sprocket (page 7-4).
- Side cover (page 2-5).



# 15. HYDRAULIC BRAKE


---

COMPONENT LOCATION .....	15-2	FRONT MASTER CYLINDER.....	15-22
SERVICE INFORMATION .....	15-4	REAR MASTER CYLINDER/ BRAKE PEDAL .....	15-29
TROUBLESHOOTING .....	15-6	FRONT BRAKE CALIPER (CB1000R) .....	15-37
BRAKE FLUID REPLACEMENT/ AIR BLEEDING (CB1000R).....	15-7	FRONT BRAKE CALIPER (CB1000RA).....	15-41
BRAKE FLUID REPLACEMENT/ AIR BLEEDING (CB1000RA).....	15-10	REAR BRAKE CALIPER .....	15-45
BRAKE PAD/DISC.....	15-17		

# HYDRAULIC BRAKE

## COMPONENT LOCATION


FRONT:



CB1000R:


45 N·m (4.6 kgf·m, 33 lbf·ft)

34 N·m (3.5 kgf·m, 25 lbf·ft)



CB1000RA:

34 N·m (3.5 kgf·m, 25 lbf·ft)




17 N·m (1.7 kgf·m, 13 lbf·ft)

30 N·m (3.1 kgf·m, 22 lbf·ft)




REAR:

CB1000RA shown:



CB1000RA shown:



# HYDRAULIC BRAKE

## SERVICE INFORMATION

### GENERAL

#### ⚠ CAUTION

- Frequent inhalation of brake pad dust, regardless of material composition could be hazardous to your health.
- Avoid breathing dust particles.
  - Never use an air hose or brush to clean brake assemblies. Use an OSHA-approved vacuum cleaner.

#### NOTICE

*Spilled brake fluid will severely damage instrument lenses and painted surfaces. It is also harmful to some rubber parts. Be careful whenever you remove the reservoir cap; make sure the front reservoir is horizontal first.*

- This section covers service of the conventional brake components of the brake system. For Anti-lock Brake System (ABS) service, see page 16-4.
- A contaminated brake disc or pad reduces stopping power. Discard contaminated pads and clean a contaminated disc with a high quality brake degreasing agent.
- Never allow contaminants (e.g., dirt, water) to get into an open reservoir.
- Once the hydraulic system has been opened, or if the brake feels spongy, the system must be bled.
- Always use fresh DOT 4 brake fluid from a sealed container when servicing the system. Do not mix different types of fluid as they may not be compatible.
- Always check brake operation before riding the motorcycle.

### SPECIFICATIONS

Unit: mm (in)


ITEM		STANDARD	SERVICE LIMIT	
Front	Specified brake fluid	DOT 4 brake fluid	—	
	Brake disc thickness	4.5 (0.18)	3.5 (0.14)	
	Brake disc runout	—	0.30 (0.012)	
	Master cylinder I.D.	CB1000R	19.050 – 19.093 (0.7500 – 0.7517)	19.105 (0.7522)
		CB1000RA	17.460 – 17.503 (0.6874 – 0.6891)	17.515 (0.6896)
	Master piston O.D.	CB1000R	19.018 – 19.043 (0.7487 – 0.7497)	19.006 (0.7483)
		CB1000RA	17.321 – 17.367 (0.6819 – 0.6837)	17.309 (0.6815)
	Caliper cylinder I.D. (CB1000R)	Upper	32.080 – 32.130 (1.2630 – 1.2650)	32.140 (1.2654)
		Lower	30.280 – 30.330 (1.1921 – 1.1941)	30.340 (1.1945)
	Left caliper cylinder I.D. (CB1000RA)	Upper	25.400 – 25.450 (1.0000 – 1.0020)	25.460 (1.0024)
		Middle	22.650 – 22.700 (0.8917 – 0.8937)	22.712 (0.8942)
		Lower	25.400 – 25.450 (1.0000 – 1.0020)	25.460 (1.0024)
	Right caliper cylinder I.D. (CB1000RA)	Upper	27.000 – 27.050 (1.0630 – 1.0650)	27.062 (1.0654)
		Middle	22.650 – 22.700 (0.8917 – 0.8937)	22.712 (0.8942)
		Lower	27.000 – 27.050 (1.0630 – 1.0650)	27.062 (1.0654)
	Caliper piston O.D. (CB1000R)	Upper	31.967 – 32.000 (1.2585 – 1.2598)	31.957 (1.2581)
		Lower	30.167 – 30.200 (1.1877 – 1.1890)	30.157 (1.1873)
	Left caliper piston O.D. (CB1000RA)	Upper	25.318 – 25.368 (0.9968 – 0.9987)	25.310 (0.9965)
		Middle	22.585 – 22.618 (0.8892 – 0.8905)	22.560 (0.8882)
		Lower	25.318 – 25.368 (0.9968 – 0.9987)	25.310 (0.9965)
Right caliper piston O.D. (CB1000RA)	Upper	26.935 – 26.968 (1.0604 – 1.0617)	26.923 (1.0600)	
	Middle	22.585 – 22.618 (0.8892 – 0.8905)	22.560 (0.8882)	
	Lower	26.935 – 26.968 (1.0604 – 1.0617)	26.923 (1.0600)	
Rear	Specified brake fluid	DOT 4 brake fluid	—	
	Brake disk thickness	5.0 (0.20)	4.0 (0.16)	
	Brake disc runout	—	0.30 (0.012)	
	Master cylinder I.D.	CB1000R	15.870 – 15.913 (0.6248 – 0.6265)	15.925 (0.6270)
		CB1000RA	17.460 – 17.503 (0.6874 – 0.6891)	17.515 (0.6896)
	Master piston O.D.	CB1000R	15.827 – 15.854 (0.6231 – 0.6242)	15.815 (0.6226)
		CB1000RA	17.321 – 17.367 (0.6819 – 0.6837)	17.309 (0.6815)
	Caliper cylinder I.D.	27.000 – 27.050 (1.0630 – 1.0650)	27.060 (1.0654)	
	Caliper piston O.D.	26.918 – 26.968 (1.0598 – 1.0617)	26.910 (1.0594)	

**TORQUE VALUES**

Brake hose oil bolt	34 N·m (3.5 kgf·m, 25 lbf·ft)	
Front brake caliper mounting bolt (CB1000R)	45 N·m (4.6 kgf·m, 33 lbf·ft)	ALOC bolt; replace with a new one.
Front brake caliper mounting bolt (CB1000RA)	30 N·m (3.1 kgf·m, 22 lbf·ft)	ALOC bolt; replace with a new one.
Front caliper bleed valve (CB1000R)	7.9 N·m (0.8 kgf·m, 6.0 lbf·ft)	
Front caliper bleed valve (CB1000RA)	5.4 N·m (0.6 kgf·m, 4.0 lbf·ft)	
Rear caliper bleed valve	5.4 N·m (0.6 kgf·m, 4.0 lbf·ft)	
Front brake pad pin (CB1000R)	15.2 N·m (1.5 kgf·m, 11 lbf·ft)	
Front brake pad pin (CB1000RA)	17 N·m (1.7 kgf·m, 13 lbf·ft)	
Rear brake pad pin	17 N·m (1.7 kgf·m, 13 lbf·ft)	
Rear brake caliper mounting bolt	30 N·m (3.1 kgf·m, 22 lbf·ft)	ALOC bolt; replace with a new one.
Rear brake caliper pin bolt	27 N·m (2.8 kgf·m, 20 lbf·ft)	
Front master cylinder holder bolt	12 N·m (1.2 kgf·m, 9 lbf·ft)	
Front master cylinder reservoir cap stopper plate screw	1.2 N·m (0.1 kgf·m, 0.9 lbf·ft)	
Front master cylinder oil cup mounting screw	1.5 N·m (0.2 kgf·m, 1.1 lbf·ft)	Apply a locking agent to the threads.
Brake lever pivot bolt	1.0 N·m (0.1 kgf·m, 0.7 lbf·ft)	Apply silicone grease to the sliding surface.
Brake lever pivot nut	5.9 N·m (0.6 kgf·m, 4.4 lbf·ft)	
Front brake light switch screw	1.2 N·m (0.1 kgf·m, 0.9 lbf·ft)	
Rear master cylinder mounting bolt	12 N·m (1.2 kgf·m, 9 lbf·ft)	
Rear master cylinder reservoir cap stopper plate screw	1.2 N·m (0.1 kgf·m, 0.9 lbf·ft)	
Rear master cylinder reservoir hose joint screw	1.5 N·m (0.2 kgf·m, 1.1 lbf·ft)	Apply a locking agent to the threads.
Rear master cylinder push rod joint nut	17 N·m (1.7 kgf·m, 13 lbf·ft)	
Rear master cylinder reservoir mounting bolt	10 N·m (1.0 kgf·m, 7 lbf·ft)	
Front brake hose clamp bolt (CB1000R)	12 N·m (1.2 kgf·m, 9 lbf·ft)	
Front brake hose clamp bolt (CB1000RA)	10 N·m (1.0 kgf·m, 7 lbf·ft)	ALOC bolt; replace with a new one.
Muffler rear mounting nut	22 N·m (2.2 kgf·m, 16 lbf·ft)	
Footpeg holder mounting bolt	37 N·m (3.8 kgf·m, 27 lbf·ft)	

**TOOL**

Snap ring pliers  
07914-SA50001



## HYDRAULIC BRAKE

---

### TROUBLESHOOTING

#### Brake lever/pedal soft or spongy

- Air in hydraulic system
- Leaking hydraulic system
- Contaminated brake pad/disc
- Worn caliper piston seals
- Worn master cylinder piston cups
- Worn brake pad/disc
- Contaminated caliper
- Contaminated master cylinder
- Caliper not sliding properly
- Low brake fluid level
- Clogged fluid passage
- Warped/deformed brake disc
- Sticking/worn caliper piston
- Sticking/worn master piston
- Bent brake lever/pedal

#### Brake lever/pedal hard

- Clogged/restricted fluid passage
- Sticking/worn caliper piston
- Sticking/worn master piston
- Caliper not sliding properly
- Worn caliper piston seals
- Bent brake lever/pedal

#### Brake drag

- Contaminated brake pad/disc
- Misaligned wheel
- Warped/deformed brake disc
- Caliper not sliding properly
- Clogged/restricted fluid passage
- Sticking caliper piston

# BRAKE FLUID REPLACEMENT/AIR BLEEDING (CB1000R)

## BRAKE FLUID DRAINING


### NOTICE

Spilled fluid can damage painted, plastic or rubber parts. Place a rag over these parts whenever the system is serviced.


#### NOTE:

- Do not allow foreign material to enter the system when filling the reservoir.
- When using a commercially available brake bleeder, follow the manufacturer's operating instructions.

*Front brake:* Turn the handlebar to the left until the front master cylinder reservoir is level before removing the reservoir cap. Remove the screw, stopper plate, reservoir cap, set plate and diaphragm.




*Rear brake:* Remove the screw, stopper plate, reservoir cap, set plate and diaphragm.



*A contaminated brake disc or pads reduces stopping power. Discard contaminated pads and clean a contaminated disc with a high quality brake degreasing agent.*

Connect a bleed hose to the brake caliper bleed valve. Loosen the bleed valve and pump the brake lever/pedal until no more fluid flows out of the bleed valve.



# HYDRAULIC BRAKE

## BRAKE FLUID FILLING/AIR BLEEDING

Close the bleed valve.

Fill the reservoir with DOT 4 brake fluid from a sealed container.

Connect a commercially available brake bleeder to the bleed valve.

Operate the brake bleeder and loosen the bleed valve.

### NOTE:




- If an automatic refill system is not used, add brake fluid when the fluid level in the reservoir is low.
- Check the fluid level often while bleeding the brake to prevent air from being pumped into the system.
- When using a brake bleeding tool, follow the manufacturer's operating instructions.
- If air is entering the bleeder from around the bleed valve threads, seal the threads with teflon tape.

Perform the bleeding procedure until the system is completely flushed/bled.

Close the bleed valve and operate the brake lever/pedal. If it still feels spongy, bleed the system again.

If a brake bleeder is not available, use the following procedure:

Connect a bleed hose to the bleed valve.



Pressurize the system with the brake lever/pedal until resistance is felt.

1. Squeeze the brake lever (depress the brake pedal), open the bleed valve 1/4 of a turn and then close it.
2. Release the brake lever/pedal slowly and wait several seconds after it reaches the end of its travel.
3. Repeat steps 1. and 2. until air bubbles do not appear in the bleed hose.

After there are no more air bubbles in the fluid, repeat the air bleeding procedure about two or three times at each bleed valve.

Make sure the bleed valves are closed and operate the brake lever/pedal. If it still feels spongy, bleed the system again.



After bleeding the air completely, tighten the bleed valves to the specified torque.

**TORQUE:**

**Front: 7.9 N·m (0.8 kgf·m, 6.0 lbf·ft)**

**Rear: 5.4 N·m (0.6 kgf·m, 4.0 lbf·ft)**


Fill the front brake reservoir to the upper level line with DOT 4 brake fluid.



Install the diaphragm, set plate, reservoir cap and stopper plate.


Install and tighten the screw to the specified torque.

**TORQUE: 1.2 N·m (0.1 kgf·m, 0.9 lbf·ft)**



## HYDRAULIC BRAKE


Fill the rear brake reservoir to the upper level line with DOT 4 brake fluid.



Install the diaphragm, set plate and reservoir cap.

Install the reservoir onto the frame and tighten the mounting screw to the specified torque.

**TORQUE: 1.2 N-m (0.1 kgf-m, 0.9 lbf-ft)**



## BRAKE FLUID REPLACEMENT/AIR BLEEDING (CB1000RA)

### BRAKE FLUID DRAINING

#### NOTICE

*Spilled fluid can damage painted, plastic or rubber parts. Place a rag over these parts whenever the system is serviced.*


#### NOTE:

- Do not allow foreign material to enter the system when filling the reservoir.
- When using a commercially available brake bleeder, follow the manufacturer's operating instructions.

#### Lever Brake Line:


Turn the handlebar to the left until the front master cylinder reservoir is level before removing the reservoir cap.

Remove the screw, stopper plate, reservoir cap, set plate and diaphragm






Connect a bleed hose to the left caliper bleed valve. Loosen the bleed valve and pump the brake lever until no more fluid flows out of the bleed valve.




*A contaminated brake disc or pads reduces stopping power. Discard contaminated pads and clean a contaminated disc with a high quality brake degreasing agent.*

Connect a bleed hose to the right caliper upper bleed valve. Loosen the upper bleed valve and pump the brake lever until no more fluid flows out of the bleed valve.




### Pedal (Combined) Brake Line:

Remove the screw, stopper plate, reservoir cap, set plate and diaphragm.




Connect a bleed hose to the right front caliper center bleed valve. Loosen the center bleed valve and pump the brake pedal until no more fluid flows out of the bleed valve.



## HYDRAULIC BRAKE


Connect a bleed hose to the rear caliper bleed valve. Loosen the bleed valve and pump the brake pedal until no more fluid flows out of the bleed valve.



### FRONT BRAKE FLUID FILLING/AIR BLEEDING

Close the bleed valves.

Fill the reservoir with DOT 4 brake fluid from a sealed container.




Connect a commercially available brake bleeder to the left caliper bleed valve. Operate the brake bleeder and loosen the bleed valve.

#### NOTE:

- If an automatic refill system is not used, add brake fluid when the fluid level in the reservoir is low.
- Check the fluid level often while bleeding the brake to prevent air from being pumped into the system.
- When using a brake bleeding tool, follow the manufacturer's operating instructions.
- If air is entering the bleeder from around the bleed valve threads, seal the threads with teflon tape.

Close the bleed valve to the specified torque.

**TORQUE: 5.4 N·m (0.6 kgf·m, 4.0 lbf·ft)**




Connect a commercially available brake bleeder to the right caliper upper bleed valve.  
Operate the brake bleeder and loosen the bleed valve.

Close the bleed valve to the specified torque.

**TORQUE: 5.4 N·m (0.6 kgf·m, 4.0 lbf·ft)**

Perform the bleeding procedure until the system is completely flushed/bled.


Operate the brake lever. If it is still spongy, bleed the system again.




If a brake bleeder is not available, use the following procedure:

Fill the reservoir with DOT 4 brake fluid from a sealed container.

Connect a bleed hose to the left caliper bleed valve. Pressurize the system with the brake lever until lever resistance is felt.




1. Squeeze the brake lever, open the bleed valve 1/4 of a turn and then close it.
2. Release the brake lever slowly and wait several seconds after it reaches the end of its travel.
  - Do not release the lever until the bleed valve has been closed.



Repeat steps 1. and 2. until air bubbles do not appear in the bleed hose.

After bleeding the air completely, tighten the bleed valve to the specified torque.

**TORQUE: 5.4 N·m (0.6 kgf·m, 4.0 lbf·ft)**



## HYDRAULIC BRAKE

Fill the reservoir with DOT 4 brake fluid from a sealed container.

Connect a bleed hose to the right caliper upper bleed valve.



1. Squeeze the brake lever, open the bleed valve 1/4 of a turn and then close it.
  2. Release the brake lever slowly and wait several seconds after it reaches the end of its travel.
- Do not release the lever until the bleed valve has been closed.

Repeat steps 1. and 2. until air bubbles do not appear in the bleed hose.

After bleeding the air completely, tighten the bleed valve to the specified torque.


**TORQUE: 5.4 N·m (0.6 kgf·m, 4.0 lbf·ft)**

Fill the reservoir to the upper level line with DOT 4 brake fluid.



Install the diaphragm and set plate.  
Install the reservoir cap, stopper plate.  
Install and tighten the screws to the specified torque.

**TORQUE: 1.2 N·m (0.1 kgf·m, 0.9 lbf·ft)**



## REAR (COMBINED) BRAKE FLUID FILLING/AIR BLEEDING


### Brake Fluid Feeding:

Add fluid and bleed any air from the pedal brake line in the sequence as follow:

1. Right front brake caliper center bleed valve
2. Rear brake caliper bleed valve

Fill the reservoir with DOT 4 brake fluid from a sealed container.

Operate the brake pedal several times to bleed any air from the master cylinder.



Connect a commercially available brake bleeder to the right front caliper center bleed valve.

**NOTE:**



- If air is entering the bleeder from around the bleed valve threads, seal the threads with teflon tape.
1. Operate the brake bleeder and loosen the right front caliper center bleed valve. Add fluid when the fluid level in the master cylinder is low to prevent drawing air into the system.
  2. Repeat the above procedures until a sufficient amount of fluid flows out of the caliper center bleed valve.

It is not a problem if the fluid flowing out from the center bleed valve contains air bubbles because the lines will be bled later (page 15-16).

Connect a commercially available brake bleeder to the rear caliper bleed valve.

Repeat above step 1. and 2. for rear caliper bleed valve.

Bleed the hydraulic system (page 15-16).



If a brake bleeder is not available, perform the following procedure.



Connect a bleed hose to the right front caliper center bleed valve.

1. Pump the brake pedal several (5 – 10) times quickly, then push the brake pedal all the way down, loosen the right front caliper center bleed valve 1/4 of a turn. Wait several seconds and close the bleed valve. Release the brake pedal slowly and wait several seconds after it reaches the end of its travel.
2. Repeat the above procedures until a sufficient amount of the fluid flows out from the right front caliper center bleed valve.

It is not a problem if the fluid flowing out from the right front caliper center bleed valve contains air bubbles because the lines will be bled later (page 15-16).

Connect a bleed hose to the rear caliper bleed valve. Repeat above steps 1. and 2. for the rear caliper lower bleed valve.

Bleed the hydraulic system (page 15-16).



## HYDRAULIC BRAKE

### Air Bleeding:


Connect a bleed hose to the right front caliper center bleed valve.

1. Pump the brake pedal several (5 – 10) times quickly, then push the brake pedal all the way down, loosen the right front caliper center bleed valve 1/4 of a turn.

Wait several seconds and close the bleed valve.

Release the brake pedal slowly and wait several seconds after it reaches the end of its travel.


2. Repeat the above procedures until air bubbles do not appear in the transparent hose.



Connect a bleed hose to the rear caliper bleed valve.

Repeat above step 1. and 2. for the rear caliper bleed valve.

Note that you may feel strong resistance on the rear (combined) brake pedal during pumping when bleeding air from the caliper. This symptom is caused by the PCV function. Be sure to apply the brake pedal fully.




After there are no more air bubbles in the fluid, repeat the air bleeding procedure about two or three times at each bleed valve.

Make sure the bleed valves are closed and operate the brake pedal. If it still feels spongy, bleed the system again.

After bleeding the air completely, tighten the bleed valves to the specified torque.

**TORQUE: 5.4 N·m (0.6 kgf·m, 4.0 lbf·ft)**


Fill the reservoir to the "UPPER" level with DOT 4 brake fluid.



Install the diaphragm, set plate, reservoir cap and stopper plate.

Install and tighten the stopper plate screw to the specified torque.


**TORQUE: 1.2 N·m (0.1 kgf·m, 0.9 lbf·ft)**



## BRAKE PAD/DISC


### FRONT BRAKE PAD REPLACEMENT (CB1000R)

Loosen the pad pins.  
Remove the caliper mounting bolts and brake cali-  
per.




*Check the brake fluid level in the reservoir as this operation causes the level to rise.*


Push the caliper pistons all the way in to allow installation of new brake pads.



Remove the pad pins and brake pads.




Remove the pad spring.




## HYDRAULIC BRAKE

Clean the inside of the caliper especially around the caliper pistons.




Install the pad spring to the brake caliper with its direction as shown securely.



*Always replace the brake pads in pairs to assure even disc pressure.*

Install new brake pads to the brake caliper.


Install the pad pins while pushing in the brake pads against the pad spring.



Install the brake caliper to the fork leg so that the disc is positioned between the pads.

### NOTE:

- Make sure that the collars are installed into the caliper bracket properly.
- Be careful not to damage the brake pads.






Tighten new brake caliper mounting bolts to the specified torque.

**TORQUE: 45 N·m (4.6 kgf·m, 33 lbf·ft)**

Tighten the pad pins to the specified torque.

**TORQUE: 15.2 N·m (1.5 kgf·m, 11 lbf·ft)**

Check the brake operation by applying the brake lever.




**FRONT BRAKE PAD REPLACEMENT (CB1000RA)**

*Check the brake fluid level in the reservoir as this operation causes the level to rise.*

Push the caliper pistons all the way in to allow installation of new brake pads by pushing the caliper body inward.




Loosen the pad pin.  
Pull the pad pin out of the caliper body while holding the brake pads.



Remove the brake pads.  
Make sure that the pad spring is in place.

*Always replace the brake pads in pairs to ensure even disc pressure.*

Install new brake pads into the caliper so their ends rest into the pad retainer on the bracket properly.



## HYDRAULIC BRAKE


Coat the stopper ring on the pad pin end with the silicone-grease.

Install the pad pin by pushing in the pads against the pad spring to align the pad pin holes in the pads and caliper body.

Tighten the pad pin to the specified torque.

**TORQUE: 17 N·m (1.7 kgf·m, 13 lbf·ft)**


Operate the brake lever to seat the caliper pistons against the pads.



## REAR BRAKE PAD REPLACEMENT


*Check the brake fluid level in the reservoir as this operation causes the level to rise.*

Push the caliper pistons all the way in to allow installation of new brake pads by pushing the caliper body inward.



Loosen the pad pin.

Pull the pad pin out of the caliper body while holding the brake pads.




Remove the brake pads.


Make sure that the pad spring is in place.

*Always replace the brake pads in pairs to assure even disc pressure.*

Install new brake pads into the caliper so their ends rest into the pad retainer on the bracket properly.




Coat the stopper ring on the pad pin end with the silicone grease.  
 Install the pad pin by pushing in the pads against the pad spring to align the pad pin holes in the pads and caliper body.



Tighten the pad pin to the specified torque.

**TORQUE: 17 N·m (1.7 kgf·m, 13 lbf·ft)**

Operate the brake pedal to seat the caliper piston against the pads.




## BRAKE DISC INSPECTION

Visually inspect the disc for damage or cracks.

Measure the brake disc thickness at several points.

**SERVICE LIMITS: Front: 3.5 mm (0.14 in)**  
**Rear: 4.0 mm (0.16 in)**

Replace the brake disc if the smallest measurement is less than the service limit.




Measure the brake disc warp with a dial indicator.

**SERVICE LIMIT: Front/Rear: 0.30 mm (0.012 in)**

Check the wheel bearing for excessive play, if the warp exceeds the service limit.  
 Replace the brake disc if the bearings are normal.

Refer to brake disc replacement:

- Front brake disc (page 13-16)
- Rear brake disc (page 14-6)



# FRONT MASTER CYLINDER

## REMOVAL


**NOTE:**

- Avoid spilling fluid on painted, plastic or rubber parts. Place a rag over these parts whenever the system is serviced.


Drain the brake fluid from the front brake hydraulic system.

- CB1000R (page 15-7).
- CB1000RA (page 15-10).

Remove the boot and loosen the lock adaptor bolt, then remove the rearview mirror.




Disconnect the brake light switch wire connectors.




*When removing the oil bolt, cover the end of the hose to prevent contamination.*

Remove the brake hose oil bolt cover. Remove the brake hose oil bolt and sealing washers.




Remove the bolts from the master cylinder holder and remove the master cylinder assembly.




## DISASSEMBLY


Remove the screws and oil cup from the master cylinder body.



Remove the O-rings (large:1/small:2) from the master cylinder body.




Remove the pivot nut, bolt and brake lever assembly.




# HYDRAULIC BRAKE

Remove the screw and brake light switch.



*Be careful not to damage the boot.* Remove the boot and push rod.




Remove the snap ring from the master cylinder body using the special tool as shown.

**TOOL:**

**Snap ring pliers**


**07914-SA50001**

Remove the master piston, spring and spring guide from the master cylinder body.



## INSPECTION


- Clean the inside of the cylinder with clean brake fluid.
- Check the master cylinder and piston for abnormal scratches.
- Check the spring for fatigue or damage.



Measure the master cylinder I.D.

**SERVICE LIMITS:**


- CB1000R: 19.105 mm (0.7522 in)
- CB1000RA: 17.515 mm (0.6896 in)




Measure the master cylinder piston O.D.

**SERVICE LIMITS:**

- CB1000R: 19.006 mm (0.7483 in)
- CB1000RA: 17.309 mm (0.6815 in)



## ASSEMBLY




# HYDRAULIC BRAKE

- Keep the piston, cups, spring, snap ring and boot as a set; do not substitute individual parts.

Coat the master piston and piston cups with clean brake fluid.

*Do not allow the piston cup lips to turn inside out.*

Install the spring guide/spring and master piston into the master cylinder.




*Make sure the snap ring is firmly seated in the groove.*

Install the snap ring into the groove in the master cylinder.

**TOOL:**


**Snap ring pliers**

**07914-SA50001**



Apply silicone grease to contact surfaces of the push rod and master piston.


Install a new boot with the push rod.



Install the brake light switch by aligning its boss with the hole.


Install the brake light switch and tighten the screw.

**TORQUE: 1.2 N·m (0.1 kgf·m, 0.9 lbf·ft)**





Apply silicone grease to push rod tip.  
Install the brake lever by aligning the hole of the brake lever with the push rod.




Apply silicone grease to the brake lever pivot bolt sliding surface.  
Install the brake lever and pivot bolt, and tighten it to the specified torque.

**TORQUE: 1.0 N·m (0.1 kgf·m, 0.7 lbf·ft)**


Install the pivot nut and tighten it while holding the pivot bolt to the specified torque.

**TORQUE: 5.9 N·m (0.6 kgf·m, 4.4 lbf·ft)**




Apply brake fluid to new O-rings.  
Install the O-rings (large:1/small:2) to the master cylinder body.

Install the oil cup to the master cylinder body.



Clean and apply a locking agent to the oil cup mounting screw threads.  
Install and tighten the mounting screws to the specified torque.

**TORQUE: 1.5 N·m (0.2 kgf·m, 1.1 lbf·ft)**




# HYDRAULIC BRAKE

## INSTALLATION

Install the master cylinder holder with its "UP" mark facing up.

Install the master cylinder, holder and bolts. Align the edge of the master cylinder with the punch mark on the handlebar, and tighten the upper bolt first, then the lower bolt to the specified torque.


**TORQUE: 12 N·m (1.2 kgf·m, 9 lbf·ft)**



Connect the brake hose to the master cylinder with the oil bolt and new sealing washers. Tighten the oil bolt while holding the stopper on the hose eyelet against the stopper.

**TORQUE: 34 N·m (3.5 kgf·m, 25 lbf·ft)**


Install the brake hose oil bolt cover to the brake hose oil bolt securely.




Connect the brake light switch wire connectors to the brake light switch.

Fill and bleed the hydraulic system:

- CB1000R (page 15-7)
- CB1000RA (page 15-10)



Install the rearview mirror and tighten the adaptor bolt securely. Install the boot securely.



# REAR MASTER CYLINDER/BRAKE PEDAL

## REMOVAL

**NOTE:**

- Avoid spilling fluid on painted, plastic or rubber parts. Place a rag over these parts whenever the system is serviced.


Drain the fluid from the brake hydraulic system (page 15-10).

- CB1000R (page 15-7).
- CB1000RA (page 15-10).

Remove the seat (page 2-4).


Remove the side cover (page 2-5).

Disconnect the rear brake light switch 2P (black) connector.




Remove the oil bolt and sealing washers.

Remove the bolt, washer and rear reservoir.




Remove the muffler rear mounting bolt/nut, washers and collar.

Loosen the rear master cylinder mounting bolts. Remove the mounting bolts and right foot peg holder.




# HYDRAULIC BRAKE


Remove the rear master cylinder mounting bolts.




Remove the return springs.  
Remove the rear brake light switch.  
Remove the cotter pin.



Remove the joint pin and rear master cylinder.




Remove the snap ring, washer and brake pedal.



**MASTER CYLINDER DISASSEMBLY**

Remove the screw and reservoir hose joint.


CB1000RA shown:



Pull the boot out of the master cylinder and remove the snap ring using the special tool.

**TOOL:**  
**Snap ring pliers**                      **07914-SA50001**

Remove the push rod, master piston, primary cup and spring.



**INSPECTION**


Clean inside of the master cylinder and the master piston with clean brake fluid.

Check the piston cups and boot for wear, deterioration or damage.


Check the spring for damage.

Check the master cylinder and piston for scoring, scratches or damage.

CB1000R:




CB1000RA:




# HYDRAULIC BRAKE

CB1000R: Measure the master cylinder I.D.  
**SERVICE LIMIT: 15.925 mm (0.6270 in)**  
 Measure the master piston O.D.  
**SERVICE LIMIT: 15.815 mm (0.6226 in)**





CB1000RA: Measure the master cylinder I.D.  
**SERVICE LIMIT: 17.515 mm (0.6896 in)**  
 Measure the master piston O.D.  
**SERVICE LIMIT: 17.309 mm (0.6815 in)**




## MASTER CYLINDER ASSEMBLY

CB1000RA shown:




**CB1000R:** Apply silicone grease to the piston contacting surface of the push rod.




**CB1000R:** Coat the master piston and piston cups with clean brake fluid. Install the primary cup onto the spring.

*Do not allow the piston cup lips to turn inside out.* Install the spring/master piston with the push rod into the master cylinder.



**CB1000RA:** Coat the master piston and piston cups with clean brake fluid. Install the primary cup onto the spring.


*Do not allow the piston cup lips to turn inside out.* Install the spring/primary cup and master piston/push rod into the master cylinder.



*Make sure the snap ring is firmly seated in the groove.* Install the snap ring into the groove in the master cylinder.

**TOOL:**  
**Snap ring pliers                      07914-SA50001**

Apply silicone grease to the boot inside, and install the boot into the master cylinder.




## HYDRAULIC BRAKE

If the push rod joint is reinstalled, adjust the push rod length so that the distance between the centers of the master cylinder lower mounting bolt hole and joint pin hole is 67.5 mm (2.66 in).

After adjustment, tighten the joint nut to the specified torque.


**TORQUE: 17 N·m (1.7 kgf·m, 13 lbf·ft)**

CB1000RA shown:




Coat a new O-ring with brake fluid and install it onto the reservoir hose joint. Install the hose joint into the master cylinder.

CB1000RA shown:




Apply a locking agent to the hose joint screw threads. Install the screw and tighten it to the specified torque.

**TORQUE: 1.5 N·m (0.2 kgf·m, 1.1 lbf·ft)**




## INSTALLATION

Apply grease to the groove in the pedal pivot. Install the brake pedal and secure it with the washer and snap ring.







Install the master cylinder onto the pedal with the joint pin.



Secure the master cylinder with a new cotter pin.  
Install the rear brake light switch into the stay on the bracket.  
Install the switch spring and brake pedal return spring in the direction as shown.



Install the rear master cylinder mounting bolts.



Install the right footpeg holder and mounting bolts, then tighten the bolts to the specified torque.

**TORQUE: 37 N·m (3.8 kgf·m, 27 lbf·ft)**


Tighten the master cylinder mounting bolts to the specified torque.

**TORQUE: 12 N·m (1.2 kgf·m, 9 lbf·ft)**

Install the muffler rear mounting bolt/nut, washers and collar.

Tighten the muffler rear mounting nut to the specified torque.

**TORQUE: 22 N·m (2.2 kgf·m, 16 lbf·ft)**



## HYDRAULIC BRAKE

**CB1000R:** Connect the brake hose to the rear master cylinder with the oil bolt and new sealing washers.


Tighten the oil bolt while holding the stopper of the hose eyelet against the master cylinder.

**TORQUE: 34 N·m (3.5 kgf·m, 25 lbf·ft)**

Install the reservoir and washer.

Install and tighten the bolt to the specified torque.

**TORQUE: 10 N·m (1.0 kgf·m, 7 lbf·ft)**



**CB1000RA:** Connect the brake hose to the rear master cylinder with the oil bolt and new sealing washers.


Tighten the oil bolt while holding the hose eyelet against the master cylinder.

**TORQUE: 34 N·m (3.5 kgf·m, 25 lbf·ft)**

Install the reservoir and washer.

Install and tighten the bolt to the specified torque.

**TORQUE: 10 N·m (1.0 kgf·m, 7 lbf·ft)**




Connect the rear brake light switch 2P (black) connector.

Install the seat (page 2-4).

Fill and bleed the hydraulic system:

- CB1000R (page 15-7)
- CB1000RA (page 15-10)



## FRONT BRAKE CALIPER (CB1000R)


### NOTE:

- Avoid spilling fluid on painted, plastic or rubber parts. Place a rag over these parts whenever the system is serviced.

### REMOVAL


Drain the front brake hydraulic system (page 15-7).

Remove the brake hose oil bolt, sealing washers and brake hose eyelet joint.




Loosen the front brake pad pins, then remove the mounting bolts and the front brake caliper.

Remove the brake pads (page 15-17).



Remove the collars from the fork.



# HYDRAULIC BRAKE

## DISASSEMBLY

Place a shop towel between each piston.



Apply small squirts of air pressure to the fluid inlet to remove the pistons.

Remove the following:

- Upper caliper pistons
- Lower caliper pistons

### NOTE:


- Be careful not to damage each piston.
- Do not use high pressure air or bring the nozzle too close to the inlet.
- Mark the pistons to ensure correct reassembly.



*Be careful not to damage the piston sliding surface.*

Push the dust seals and piston seals in and lift them out. Clean the seal grooves with clean brake fluid.

PISTON SEAL



DUST SEAL

## INSPECTION


Check the caliper cylinders and pistons for scoring, scratches or damage.

Measure the caliper cylinder I.D.

### SERVICE LIMITS:

Upper: 32.140 mm (1.2654 in)


Lower: 30.340 mm (1.1945 in)




Measure the caliper piston O.D.

**SERVICE LIMITS:**

- Upper: 31.957 mm (1.2581 in)
- Lower: 30.157 mm (1.1873 in)



**ASSEMBLY**




Coat new piston seals with clean brake fluid.  
Coat new dust seals with silicone grease.

*Install each piston seal, dust seal and caliper piston in their proper locations.*

Install the piston and dust seals into the grooves of the caliper body.

Coat the caliper pistons with clean brake fluid and install them into the caliper cylinder with their open ends toward the pad.


- Upper piston: large O.D.
- Lower piston: small O.D.



## HYDRAULIC BRAKE

### INSTALLATION

Install the collars to the fork securely.




Install the brake pads (page 15-17).

Install the brake caliper with new mounting bolts. Tighten the mounting bolts to the specified torque.

**TORQUE: 45 N·m (4.6 kgf·m, 33 lbf·ft)**

Tighten the pad pins to the specified torque.

**TORQUE: 15.2 N·m (1.5 kgf·m, 11 lbf·ft)**




Install the brake hose eyelet joint to the caliper body with new sealing washers and oil bolt.

Push the brake hose eyelet joint to the stopper on the caliper, then tighten the oil bolt to the specified torque.

**TORQUE: 34 N·m (3.5 kgf·m, 25 lbf·ft)**

Fill and bleed the hydraulic system (page 15-7).



## FRONT BRAKE CALIPER (CB1000RA)

### REMOVAL

**NOTE:**

- Avoid spilling fluid on painted, plastic or rubber parts. Place a rag over these parts whenever the system is serviced.


#### RIGHT BRAKE CALIPER

Drain the brake fluid from the hydraulic system (page 15-10).


Remove the front wheel speed sensor (page 16-23).

Remove the oil bolts and sealing washers.

*When removing the oil bolt, cover the end of the hose to prevent contamination.*



Remove the mounting bolts and the right brake caliper.




#### LEFT BRAKE CALIPER

Drain the brake fluid from the hydraulic system (page 15-10).


Remove the oil bolt and sealing washers.

*When removing the oil bolt, cover the end of the hose to prevent contamination.*



# HYDRAULIC BRAKE

Remove the mounting bolts and the left brake caliper.




## DISASSEMBLY

Remove the brake pads (page 15-19).

Remove the caliper bracket from the caliper body. Remove the pad spring and bracket pin boot from the caliper body.

Remove the caliper pin boot from the caliper bracket.

If the caliper pin boot and bracket pin boot are hard, damaged or deteriorated, replace them with new ones.



Place a shop towel over the pistons.

Position the caliper body with the pistons facing down and apply small squirts of air pressure to the fluid inlet to remove the pistons.

### NOTE:

- Be careful not to damage each piston.
- Do not use high pressure air or bring the nozzle too close to the inlet.
- Mark the pistons to ensure correct reassembly.



*Be careful not to damage the piston sliding surface.*

Push the dust seals and piston seals in and lift them out.

Clean the seal grooves, caliper cylinders and pistons with clean brake fluid.

PISTON SEALS





**INSPECTION**

Check the caliper cylinders and pistons for scoring, scratches or damage.

Measure each caliper cylinder I.D.

**SERVICE LIMITS (Right caliper):**

- Upper: 27.062 mm (1.0654 in)
- Middle: 22.712 mm (0.8942 in)
- Lower: 27.062 mm (1.0654 in)

**SERVICE LIMITS (Left caliper):**

- Upper: 25.460 mm (1.0024 in)
- Middle: 22.712 mm (0.8942 in)
- Lower: 25.460 mm (1.0024 in)



Measure each caliper piston O.D.

**SERVICE LIMITS (Right caliper):**

- Upper: 26.923 mm (1.0600 in)
- Middle: 22.560 mm (0.8882 in)
- Lower: 26.923 mm (1.0600 in)

**SERVICE LIMITS (Left caliper):**

- Upper: 25.310 mm (0.9965 in)
- Middle: 22.560 mm (0.8882 in)
- Lower: 25.310 mm (0.9965 in)




**ASSEMBLY**

RIGHT CALIPER shown:

**BLEED VALVES**

5.4 N·m (0.6 kgf·m,  
4.0 lbf·ft)




# HYDRAULIC BRAKE

Coat new piston seals with clean brake fluid and install them into the seal grooves in the caliper.  
Coat new dust seals with silicone grease and install them into the seal grooves in the caliper.

*Install the shorter piston into the middle cylinder.*

Coat the caliper pistons with clean brake fluid and install them into the caliper cylinders with the opening toward the pads.



Install the boots into the caliper and bracket.


*Note the installation direction of the pad spring.*

Install the pad spring onto the caliper body properly. Check that the pad retainer is in place on the caliper bracket.

Apply silicone grease to the inside of the boots and the slide pins.

Install the caliper bracket over the caliper body.

Install the brake pads (page 15-19).




## INSTALLATION

### RIGHT BRAKE CALIPER

Install the brake caliper with new mounting bolts. Tighten the mounting bolts to the specified torque.

**TORQUE: 30 N·m (3.1 kgf·m, 22 lbf·ft)**



Connect the brake hoses to the caliper with the oil bolts and new sealing washers.

Push the stopper or the brake hose eyelet joint against the caliper body, then tighten the oil bolts to the specified torque.


**TORQUE: 34 N·m (3.5 kgf·m, 25 lbf·ft)**

Install the brake pads (page 15-19).

Install the front wheel speed sensor (page 16-23).

Fill and bleed the hydraulic system (page 15-10).


After installation, check the air gap (page 16-23).



**LEFT BRAKE CALIPER**

Install the brake caliper with new mounting bolts. Tighten the mounting bolts to the specified torque.

**TORQUE: 30 N·m (3.1 kgf·m, 22 lbf·ft)**



Connect the brake hoses to the caliper with the oil bolts and new sealing washers. Push the stopper of the brake hose eyelet joint against the caliper body, then tighten the oil bolts to the specified torque.

**TORQUE: 34 N·m (3.5 kgf·m, 25 lbf·ft)**

Install the brake pads (page 15-19).  
Fill and bleed the hydraulic system (page 15-10).




**REAR BRAKE CALIPER**

**REMOVAL**

Drain the brake fluid from the hydraulic system (page 15-10).  
Remove the rear wheel (page 14-6).


*When removing the oil bolt, cover the end of the hose to prevent contamination.*

Remove the brake hose oil bolt and sealing washers.



Remove the mounting bolts and the rear brake caliper.

Remove the rear brake pads (page 15-20).




# HYDRAULIC BRAKE

## DISASSEMBLY

Remove the caliper bracket from the caliper body.  
Remove the pad spring and bracket pin boot from the caliper body.  
Remove the caliper pin boot from the caliper bracket.


If the caliper pin boot and bracket pin boot are hard, damaged or deteriorated, replace them with new ones.



Place a shop towel over the piston.

*Do not use high pressure air or bring the nozzle too close the inlet.*


Position the caliper body with the pistons facing down and apply small squirts of air pressure to the fluid inlet to remove the pistons.



*Be careful not to damage the piston sliding surface.*

Push the dust seals and piston seals in and lift them out.

Clean the seal grooves, caliper cylinders and pistons with clean brake fluid.




## INSPECTION

Check the caliper cylinders and pistons for scoring, scratches or damage.


Measure each caliper cylinder I.D.

**SERVICE LIMIT: 27.060 mm (1.0654 in)**




Measure each caliper piston O.D.

**SERVICE LIMIT: 26.910 mm (1.0594 in)**




## ASSEMBLY



Coat new piston seals with clean brake fluid and install them in the seal grooves in the caliper body. Coat new dust seals with silicone grease and install them in the seal grooves in the caliper body.

Coat the caliper pistons with clean brake fluid and install them into the caliper cylinders with the opening toward the pads.



## HYDRAULIC BRAKE


Apply silicone grease to the inside of the caliper and bracket pin boots.

Install the boots into the caliper body and bracket.

Install the pad spring onto the caliper body properly as shown.

Check that the pad retainer is in place on the caliper bracket.

Install the caliper bracket over the caliper body.




### INSTALLATION

Install the brake pads (page 15-20).

Install the brake caliper to the caliper stay.

Install and tighten new mounting bolts to the specified torque.

**TORQUE: 30 N·m (3.1 kgf·m, 22 lbf·ft)**




Connect the brake hose to the caliper with the oil bolt and new sealing washers.

Push the stopper on the brake hose eyelet joint against the caliper body, then tighten the oil bolts to the specified torque.

**TORQUE: 34 N·m (3.5 kgf·m, 25 lbf·ft)**

Install the rear wheel (page 14-7).

Fill and bleed the brake hydraulic system (page 15-10).




# 16. ANTI-LOCK BRAKE SYSTEM (ABS/CBS; CB1000RA)

---


ABS SYSTEM LOCATION .....	16-2	ABS TROUBLESHOOTING .....	16-10
ABS SYSTEM DIAGRAM .....	16-3	ABS INDICATOR CIRCUIT TROUBLESHOOTING.....	16-20
SERVICE INFORMATION .....	16-4	WHEEL SPEED SENSOR.....	16-23
ABS CONNECTOR LOCATIONS .....	16-5	ABS MODULATOR/PCV .....	16-25
ABS TROUBLESHOOTING INFORMATION .....	16-6	DELAY VALVE .....	16-30
ABS PROBLEM CODE INDEX .....	16-9		

**ABS SYSTEM LOCATION**






ABS SYSTEM DIAGRAM



(ABS) ( ) = ABS Problem Code



ABS MODULATOR 25P CONNECTOR  
(Modulator side/male terminals)

## SERVICE INFORMATION

### GENERAL

- This section covers service of the Anti-lock Brake System (ABS). For conventional brake service, see page 15-2.
- When the ABS control unit detects a problem, it stops the ABS function and switches back to the conventional brake operation, and the ABS indicator blinks or stays on. Take care during the test ride.
- Troubles not resulting from a faulty ABS (e.g. brake disc squeak, unevenly worn brake pad) cannot be recognized by the ABS diagnosis system.
- Read "ABS Troubleshooting information" carefully, inspect and troubleshoot the ABS system according to the Diagnostic Troubleshooting. Observe each step of the procedures one by one. Write down the problem code and probable faulty part before starting diagnosis and troubleshooting.
- After troubleshooting, erase the problem code and perform the pre-start self-diagnosis to be sure that the ABS indicator is operating normally.
- When the wheel speed sensor and/or pulser ring is replaced, check the clearance (air gap) between both components.
- The ABS control unit (ECU) is mounted on the modulator (the modulator with the built-in ECU). Do not disassemble the ABS modulator. Replace the ABS modulator as an assembly when the it is faulty.
- The ABS modulator may be damaged if dropped. Also if a connector is disconnected when current is flowing, the excessive voltage may damage the control unit. Always turn off the ignition switch before servicing.
- Be careful not to damage the wheel speed sensor and pulser ring when removing and installing the wheel.
- The following color codes are used throughout this section.

Bu = Blue	G = Green	Lg = Light Green	R = Red
Bl = Black	Gr = Gray	O = Orange	W = White
Br = Brown	Lb = Light Blue	P = Pink	Y = Yellow

### TORQUE VALUES

Brake pipe joint nut	14 N·m (1.4 kgf·m, 10 lbf·ft)	Apply brake fluid to the threads.
PCV mounting bolt	12 N·m (1.2 kgf·m, 9 lbf·ft)	
Delay valve mounting bolt	12 N·m (1.2 kgf·m 9 lbf·ft)	
Brake hose oil bolt	34 N·m (3.5 kgf·m 25 lbf·ft)	


### TOOL

Test probe  
07ZAJ-RDJA110



# ABS CONNECTOR LOCATIONS


NOTE 1: Lift and support the fuel tank (page 3-5).



NOTE 2: Remove the seat (page 2-4).

NOTE 3: Remove the left seat rail cover (page 2-6).

ABS SERVICE CHECK 3P  
(Natural) CONNECTOR (NOTE 2)



**ABS TROUBLESHOOTING INFORMATION**

**SYSTEM DESCRIPTION**

**ABS PRE-START SELF-DIAGNOSIS SYSTEM**

The ABS pre-start self-diagnosis system diagnoses the electrical system as well as the operating status of the modulator. When there is any abnormality, the problem and the problematic part can be detected by outputting the problem code.


When the vehicle speed is approximately 6 km/h (4 mph) or more, the wheel speed sensor signal is sent to the ABS control unit, then the pre-start self-diagnosis system operates the pump motor (inside the modulator) and detects whether the hydraulic operation is normal, and it completes the pre-start self-diagnosis.

When the ABS is normal, the ABS indicator goes off just after a road speed of 10 km/h (6 mph) indicating that the diagnosis is completed.

If a problem is detected, the ABS indicator blinks or comes on and stays on to notify the rider of the problem. The self-diagnosis is also made while the motorcycle is running, and the indicator blinks when a problem is detected.


When the indicator blinks, the cause of the problem can be identified by retrieving the problem code following the specified retrieval procedure (page 16-7).

Pre-start self-diagnosis when normal:




**PRE-START SELF-DIAGNOSIS PROCEDURE (Daily check)**

1. Turn the ignition switch to "ON".
2. Make sure the ABS indicator comes on.
3. Start the engine.
4. Ride the motorcycle and increase the vehicle speed to approximately 10 km/h (6 mph).
5. The ABS is normal if the ABS indicator goes off.




## PROBLEM CODE INDICATION PATTERN

- The ABS indicator indicates the problem code by blinking a specified number of times. The indicator has two types of blinks, a long blink and short blink. The long blink lasts for 1.3 seconds, the short blink lasts for 0.3 seconds. When two long blinks occur, and three short blinks, that problem code is 23 (two long blinks = 20 blinks, three short blinks = 3 blinks). Then, go to the troubleshooting and see problem code 23.
- When the ABS control unit stores some problem codes, the ABS indicator shows the problem codes in the order from the lowest number to highest number. For example, when the indicator indicates code 12, then indicates code 23, two failures have occurred.



When the problem code is not stored:



## PROBLEM CODE READOUT

### NOTE:


- The problem code is not erased by turning the ignition switch to "OFF" while the problem code is being output. Note that turning the ignition switch to "ON" again does not indicate the problem code. To show the problem code again, repeat the problem code retrieval procedures from the beginning.
- After diagnostic troubleshooting, erase the problem code(s) and perform the pre-start self-diagnosis to be sure that there is no problem in the ABS indicator (indicator is operating normally).

1. Remove the seat (page 2-4).

Remove the dummy connector from the ABS service check 3P (Natural) connector.

Short the wire terminals of the service check connector with a jumper wire with the ignition switch turned to "OFF".

**CONNECTION: Brown/white – Green**




## ANTI-LOCK BRAKE SYSTEM (ABS/CBS; CB1000RA)

Do not apply the front or rear brake during retrieval.

2. Turn the ignition switch to "ON". The ABS indicator should come on 2 seconds (start signal) (then goes off 3.6 seconds) and starts problem code indication.

The problem code is indicated by the number of the times of the indicator blinking.


If the problem code is not stored, the ABS indicator stays on.



3. Turn the ignition switch to "OFF" and remove the jumper wire.

Connect the 3P (Natural) connector to the dummy connector.

Install the seat (page 2-4).




### CLEARING PROBLEM CODE

1. Remove the seat (page 2-4).

Short the wire terminals of the service check connector with a jumper wire with the ignition switch turned to "OFF" in the same manner as retrieval.

**CONNECTION: Brown/white – Green**



2. Turn the ignition switch to "ON" while squeezing the brake lever. The ABS indicator should come on 2 seconds and go off.
3. Release the brake lever immediately after the ABS indicator is off. The ABS indicator should come on.
4. Squeeze the brake lever immediately after the ABS indicator is on. The ABS indicator should go off.
5. Release the brake lever immediately after the ABS indicator is off. When code erasure is complete, the ABS indicator blinks 2 times and stays on.
6. Turn the ignition switch to "OFF".  
Install the seat (page 2-4).



## ABS PROBLEM CODE INDEX

**NOTE:**

- The ABS indicator might blink in the following cases. Correct the faulty part.
  - Incorrect tire pressure.
  - Tires not recommended for the motorcycle were installed (incorrect tire size).
  - Deformation of the wheel or tire.
- The ABS indicator might blink while riding under the following conditions. This is temporary failure. Erase the problem code and perform the pre-start self-diagnosis. The ABS is normal if the indicator goes off. Ask the rider for the riding conditions in detail when the motorcycle is brought in for inspection.
  - The motorcycle has continuously run bumpy roads.
  - The front wheel leaves the ground for a long time when riding (wheelie).
  - Only either the front or rear wheel rotates.
  - The ABS operates continuously.
  - The ABS control unit has been disrupted by an extremely powerful radio wave (electromagnetic interference).

Problem Code	Function failure	Detection		Symptom/Fail-safe function	Refer to
		A	B		
–	ABS indicator circuit malfunction • Indicator related wires			• ABS indicator never come ON at all	16-20
				• ABS indicator stays ON at all	16-20
11	Front wheel speed sensor circuit malfunction • Wheel speed sensor or related wires	○	○	• Stops ABS operation	16-10
12	Front wheel speed sensor malfunction • Wheel speed sensor or related wires • Electrical noise/intermittent interruption		○	• Stops ABS operation	16-10
13	Rear wheel speed sensor circuit malfunction • Wheel speed sensor or related wires	○	○	• Stops ABS operation	16-12
14	Rear wheel speed sensor • Wheel speed sensor or related wires • Electrical noise/intermittent interruption		○	• Stops ABS operation	16-12
21	Front speed sensor pulse • Pulser ring or wheel speed sensor		○	• Stops ABS operation	16-10
23	Rear speed sensor pulse • Pulser ring or wheel speed sensor		○	• Stops ABS operation	16-12
31	Solenoid valve malfunction			• Stops ABS operation	16-14
32					
33					
34		○	○		
37					
38					
41	Front wheel lock			• Stops ABS operation	16-10
42	• Riding condition • Wheel speed sensor or related wires		○		
43	Rear wheel lock • Riding condition • Wheel speed sensor or related wires		○	• Stops ABS operation	16-12
51	Motor lock	○	○	• Stops ABS operation	16-14
52	Motor stuck OFF	○	○	• Stops ABS operation	
53	Motor stuck ON	○	○	• Stops ABS operation	
54	Fail-safe relay circuit malfunction	○	○	• Stops ABS operation	16-16
61	Power supply voltage low	○	○	• Stops ABS operation	16-18
62	Power supply voltage high	○	○	• Stops ABS operation	
71	Incorrect tire size		○	• Stops ABS operation	16-19
81	CPU (ABS control unit)	○	○	• Stops ABS operation	16-19

(A) Pre-start self-diagnosis (page 16-6)

(B) Ordinary self-diagnosis: diagnoses while the motorcycle is running (after pre-start self-diagnosis)

## **ABS TROUBLESHOOTING**

**NOTE:**

- Perform inspection with the ignition switch turned to "OFF", unless otherwise specified.
- Refer to the ABS Connector Locations (page 16-5). All connector diagrams in the troubleshooting are viewed from the terminal side.
- Use a fully charged battery. Do not diagnose with a charger connected to the battery.
- When the ABS modulator assembly is detected to be faulty, recheck the wire harness and connector connections closely before replacing it.
- After troubleshooting, erase the problem code (page 16-8).  
Perform the pre-start self-diagnosis to be sure that the ABS indicator is operating normally (page 16-6).

### **PROBLEM CODE 11, 12, 21, 41 or 42 (Front Wheel Speed Sensor)**

**NOTE:**

- The ABS indicator might blink under unusual riding or conditions (page 16-9). This is temporary failure. Erase the problem code and perform the pre-start self-diagnosis before troubleshooting. The ABS is normal if the indicator goes off.
- If the problem code 41 is indicated, check the front brake for drag.


#### **1. Speed Sensor Air Gap Inspection**

Measure the air gap between the wheel speed sensor and pulser ring (page 16-23).

*Is the air gap correct?*

**YES** – GO TO STEP 2.

**NO** – Check each part for deformation and looseness and correct accordingly. Recheck the air gap.




#### **2. Speed Sensor Condition Inspection**

Inspect the area around the speed sensor: Check that there is iron or other magnetic deposits between the pulser ring and wheel speed sensor, and the pulser ring slots for obstructions. Check installation condition of the pulser ring or wheel speed sensor for looseness. Check the pulser ring and sensor tip for deformation or damage (e.g., chipped pulser ring teeth).

*Are the sensor and pulser ring in good condition?*

**YES** – GO TO STEP 3.

**NO** – Remove any deposits. Install properly or replace faulty part.





**3. Speed Sensor Line Short Circuit Inspection (at control unit side)**

Lift and support the fuel tank (page 3-5).

Disconnect the ABS modulator 25P connector and the speed sensor 2P (Blue) connector. Check for continuity between the Yellow/black wire terminal of the connector and ground, and between the Green/orange wire terminal of the connector and ground.

**TOOL:**


**Test probe** **07ZAJ-RDJA110**

**CONNECTION:** Yellow/black – Ground  
Green/orange – Ground

*Is there continuity?*

**YES** – Short circuit in wire between the ABS modulator and speed sensor.

**NO** – GO TO STEP 4.



**4. Speed Sensor Line Short Circuit Inspection (at sensor side)**


Check for continuity between each terminal (Blue and White) of the sensor side 2P (Blue) connector and ground in the same manner as the previous step.

**CONNECTION:** Blue – Ground  
White – Ground

*Is there continuity?*

**YES** – Faulty front wheel speed sensor.

**NO** – GO TO STEP 5.



**5. Speed Sensor Line Open Circuit Inspection**

Short the Yellow/black and Green/orange wire terminals of the 25P connector with a jumper wire.


Check for continuity between the terminals of the wire harness side sensor 2P (Blue) connector.

**CONNECTION:** Green/orange – Yellow/black

*Is there continuity?*

**YES** – GO TO STEP 6.

**NO** – Open circuit in wire between the ABS modulator and speed sensor.




## 6. Failure Reproduction with a New Speed Sensor

Replace the front wheel speed sensor with a new one (page 16-23).  
Connect the ABS modulator 25P connector.  
Erase the problem code (page 16-8).  
Perform the pre-start self-diagnosis and check the ABS indicator (page 16-6).

### *Dose the indicator blink?*

- YES** – Faulty ABS modulator.  
**NO** – Faulty removed wheel speed sensor.



## PROBLEM CODE 13, 14, 23 or 43 (Rear Wheel Speed Sensor)

### NOTE:


- The ABS indicator might blink under unusual riding or conditions (page 16-9). This is temporary failure. Erase the problem code and perform the pre-start self-diagnosis before troubleshooting. The ABS is normal if the indicator goes off.
- If the problem code 43 is indicated, check the rear brake for drag.

### 1. Speed Sensor Air Gap Inspection

Measure the air gap between the speed sensor and pulser ring (page 16-23).

#### *Is the air gap correct?*

- YES** – GO TO STEP 2.  
**NO** – Check each part for deformation and looseness and correct accordingly. Recheck the air gap.




### 2. Speed Sensor Condition Inspection

Inspect the area around the speed sensor:  
Check that there is iron or other magnetic deposits between the pulser ring and wheel speed sensor, and the pulser ring slots for obstructions.  
Check installation condition of the pulser ring or wheel speed sensor for looseness.  
Check the pulser ring and sensor tip for deformation or damage (e.g., chipped pulser ring teeth).

#### *Are the sensor and pulser ring in good condition?*

- YES** – GO TO STEP 3.  
**NO** – Remove any deposits. Install properly or replace faulty part.



**3. Speed Sensor Line Short Circuit Inspection (at control unit side)**

Remove the following:

- Seat (page 2-4)
- Left seat rail cover (page 2-6)


Disconnect the ABS modulator 25P connector and the speed sensor 2P (Blue) connector.

Check for continuity between the Pink/white wire terminal of the connector and ground, and between the Green/red wire terminal of the connector and ground.

**TOOL:**

**Test probe** **07ZAJ-RDJA110**

**CONNECTION:** Pink/white - Ground  
Green/red - Ground



*Is there continuity?*

**YES** - Short circuit in wire between the ABS modulator and speed sensor.

**NO** - GO TO STEP 4.

**4. Speed Sensor Line Short Circuit Inspection (at sensor side)**


Check for continuity between each terminal (Blue and White) of the sensor side 2P (Blue) connector and ground in the same manner as the previous step.

**CONNECTION:** Blue - Ground  
White - Ground

*Is there continuity?*

**YES** - Faulty rear wheel speed sensor.

**NO** - GO TO STEP 5.



**5. Speed Sensor Line Open Circuit Inspection**


Short the Pink/white and Green/red wire terminals of the 25P connector with a jumper wire. Check for continuity between the terminals of the wire harness side sensor 2P (Blue) connector.

**CONNECTION:** Green/red - Pink/white

*Is there continuity?*

**YES** - GO TO STEP 6.

**NO** - Open circuit in wire between the ABS modulator and speed sensor.



## 6. Failure Reproduction with a New Speed Sensor

Replace the rear wheel speed sensor with new one (page 16-23).

Connect the ABS modulator 25P connector.


Erase the problem code (page 16-8).

Perform the pre-start self-diagnosis and check the ABS indicator (page 16-6).

### *Dose the indicator blink?*

**YES** – Faulty ABS modulator.

**NO** – Faulty removed wheel speed sensor.



## PROBLEM CODE 31, 32, 33, 34, 37 or 38 (Solenoid Valve)

### 1. Failure Reproduction

Erase the problem code (page 16-8).


Perform the pre-start self-diagnosis (page 16-6).

Retrieve the problem code (page 16-7).

*Does the indicator indicate the code "31, 32, 33, 34, 37 or 38"?*

**YES** – Faulty ABS modulator.

**NO** – Normal (problem code is not stored; temporary failure).



## PROBLEM CODE 51, 52 or 53 (Pump Motor)

### 1. Fuse Inspection


Remove the seat (page 2-4).

Check the "ABS MOTOR" fuse (30A) in the fuse/relay box for blown.

*Is the fuse blown?*

**YES** – GO TO STEP 2.

**NO** – GO TO STEP 3.



**2. Motor Power Input Line Short Circuit Inspection**

Disconnect the ABS modulator 25P connector. Check for continuity between the Red wire terminal of the 25P connector and ground with "ABS MOTOR" fuse removed.

**TOOL:**

Test probe 07ZAJ-RDJA110


**CONNECTION:** Red – Ground

*Is there continuity?*

**YES** – Short circuit in Red wire between the fuse/relay box and ABS modulator.

**NO** – Temporary failure (install a spare fuse and recheck from the first step)

MODULATOR 25P CONNECTOR  
(Wire side/the female terminals)



**3. Motor Power Input Line Open Circuit Inspection (at control unit side)**

Install the "ABS MOTOR" fuse.

Disconnect the ABS modulator 25P connector. Measure the voltage between Red wire terminal (+) of the 25P connector and ground (-). There should be battery voltage at all times.

**TOOL:**

Test probe 07ZAJ-RDJA110


**CONNECTION:** Red (+) – Ground (-)

*Is there battery voltage?*

**YES** – GO TO STEP 5.

**NO** – GO TO STEP 4.

MODULATOR 25P CONNECTOR  
(Wire side/female terminals)



**4. Motor Power Input Line Open Circuit Inspection (at fuse box side)**

Disconnect the "ABS MOTOR" fuse.


Measure the voltage between Red/blue wire terminal (+) of the fuse/relay box and ground (-). There should be battery voltage at all times.

**CONNECTION:** Red/blue (+) – Ground (-)

*Is there battery voltage?*

**YES** – Open circuit in Red wire between the fuse/relay box and control unit.

**NO** – Open circuit in Red/blue wire between the battery and fuse/relay box.




## 5. Failure Reproduction

Connect the ABS modulator 25P connector.  
Erase the problem code (page 16-8).  
Perform the pre-start self-diagnosis (page 16-6).  
Retrieve the problem code (page 16-7).

**Does the indicator indicate the code "51, 52, or 53"?**

- YES** – Faulty ABS modulator.
- NO** – Normal (problem code is not stored; temporary failure).



## PROBLEM CODE 54 (Fail-safe Relay)


### 1. Fuse Inspection

Remove the seat (page 2-4).

Check the "ABS FAIL-SAFE RELAY" fuse (30A) in the fuse/relay box for blown.

**Is the fuse blown?**

- YES** – GO TO STEP 2.
- NO** – GO TO STEP 3.



### 2. Relay Power Input Line Short Circuit Inspection

Disconnect the ABS modulator 25P connector.  
Check for continuity between the Black wire terminal of the 25P connector and ground with "ABS FAIL-SAFE RELAY" fuse removed.


**TOOL:**

**Test probe** 07ZAJ-RDJA110

**CONNECTION:** Black – Ground

**Is there continuity?**

- YES** – Short circuit in Black wire between the fuse/relay box and ABS modulator.
- NO** – Temporary failure (install a spare fuse and recheck from the first step)



**3. Relay Power Input Line Open Circuit Inspection  
(at control unit side)**

Install the "ABS FAIL-SAFE RELAY" fuse.  
Disconnect the ABS modulator 25P connector.  
Measure the voltage between Black wire terminal (+) of the 25P connector and ground (-).  
There should be battery voltage at all times.

**TOOL:**


**Test probe** **07ZAJ-RDJA110**

**CONNECTION:** Black (+) – Ground (-)

*Is there battery voltage?*

**YES** – GO TO STEP 5.

**NO** – GO TO STEP 4.



**4. Relay Power Input Line Open Circuit Inspection  
(at fuse box side)**


Disconnect the "ABS FAIL-SAFE RELAY" fuse.  
Measure the voltage between Red/blue wire terminal (+) of the fuse box and ground (-).  
There should be battery voltage at all times.

**CONNECTION:** Red/blue (+) – Ground (-)

*Is there battery voltage?*

**YES** – Open circuit in Black wire between the fuse/relay box and control unit.

**NO** – Open circuit in Red/blue wire between the battery and fuse/relay box.




**5. Failure Reproduction**

Connect the ABS modulator 25P connector.  
Erase the problem code (page 16-8).  
Perform the pre-start self-diagnosis (page 16-6).  
Retrieve the problem code (page 16-7).

*Does the indicator indicate the code "54"?*

**YES** – Faulty ABS modulator.

**NO** – Normal (problem code is not stored; temporary failure).



## PROBLEM CODE 61 or 62 (Power Circuit)

### 1. Fuse Inspection


Remove the seat (page 2-4).

Check the "ABS MAIN" fuse (10A) in the fuse/relay box for blown.

*Is the fuse blown?*

**YES** – GO TO STEP 2.

**NO** – GO TO STEP 3.



### 2. Power Input Line Short Circuit Inspection

Disconnect the ABS modulator 25P connector. Check for continuity between the Red/brown wire terminal of the 25P connector and ground with "ABS MAIN" fuse removed.

**TOOL:**


Test probe **07ZAJ-RDJA110**

**CONNECTION:** Red/blown – Ground

*Is there continuity?*

**YES** – Short circuit in Red/brown wire between the fuse/relay box and ABS modulator.

**NO** – Temporary failure (install a spare fuse and recheck from the first step)



### 3. Power Input Line Open Circuit Inspection

Install the ABS main fuse.

Disconnect the ABS modulator 25P connector. Measure the voltage between the Red/brown wire terminal of 25P connector and ground. There should be battery voltage with the ignition switch turned to "ON".

**TOOL:**

Test probe **07ZAJ-RDJA110**


**CONNECTION:** Red/blown (+) – Ground (-)

*Is there battery voltage?*

**YES** – GO TO STEP 4.

**NO** –

- Open circuit in Red/brown or Red/black wire between the ignition switch and control unit.
- If the wire is OK, check the charging system (page 17-2).






**4. Failure Reproduction**

Connect the ABS modulator 25P connector.  
 Erase the problem code (page 16-8).  
 Perform the pre-start self-diagnosis (page 16-6).  
 Retrieve the problem code (page 16-7).

**Does the indicator indicate the code "61 or 62"?**

- YES** – Faulty ABS modulator.
- NO** – Normal (problem code is not stored; temporary failure).



**PROBLEM CODE 71 (Tire Size)**

NOTE:

- Check the following and correct the faulty part.
  - Incorrect tire pressure.
  - Tires not recommended for the motorcycle were installed (incorrect tire size).
  - Deformation of the wheel or tire.


**1. Failure Reproduction**

If the above items are normal, recheck the problem code indication:

Erase the problem code (page 16-8).  
 Perform the pre-start self-diagnosis (page 16-6).  
 Retrieve the problem code (page 16-7).

**Does the indicator indicate the code "71"?**

- YES** – Faulty ABS modulator.
- NO** – Normal (problem code is not stored; temporary failure).




**PROBLEM CODE 81 (CPU; ABS Control Unit)**

**1. Failure Reproduction**

Erase the problem code (page 16-8).  
 Perform the pre-start self-diagnosis (page 16-6).  
 Retrieve the problem code (page 16-7).

**Does the indicator indicate the code "81"?**

- YES** – Faulty ABS modulator.
- NO** – Normal (problem code is not stored; temporary failure).



## ABS INDICATOR CIRCUIT TROUBLESHOOTING

**ABS INDICATOR DOES NOT COME ON** (when the ignition switch turned to "ON")

### 1. Combination Meter Power/Ground Line Inspection

Check the combination meter power and ground lines (page 20-15).

*Are the wires normal?*

**YES** – GO TO STEP 2.

**NO** – Open circuit in related wires.

### 2. Indicator Operation Inspection

Remove the seat (page 2-4).


Pull the lock lever up and disconnect the ABS modulator 25P connector.

Turn the ignition switch to "ON" and check the ABS indicator.

*Does the indicator come on?*

**YES** – Faulty ABS modulator.

**NO** – GO TO STEP 3.



### 3. Indicator Signal Line Short Circuit Inspection

Remove the meter visor (page 2-8).

Remove the dust cover.


Disconnect the connector connected and check for continuity between the Red/black wire terminal of the harness side connector and ground.

**CONNECTION: Red/black – Ground**

*Is there continuity?*

**YES** – Short circuit in Red/black wire between the combination meter and ABS modulator.

**NO** – Faulty combination meter.



**ABS INDICATOR STAYS ON** (Indicator does not go off when the motorcycle is running, and Problem Code is not indicated by the retrieval procedure)

### 1. Fuse Inspection


Remove the seat (page 2-4).

Check the "ABS MAIN" fuse (10A) in the fuse/relay box for blown.

*Is the fuse blown?*

**YES** – GO TO STEP 2.

**NO** – GO TO STEP 3.



**2. Power Input Line Short Circuit Inspection**

Disconnect the ABS modulator 25P connector. Check for continuity between the Red/brown wire terminal of the 25P connector and body ground with "ABS MAIN" fuse removed.

**TOOL:**


**Test probe** **07ZAJ-RDJA110**

**CONNECTION:** Red/blown – Ground

*Is there continuity?*

**YES** – Short circuit in Red/brown wire.

**NO** – Temporary failure (install a spare fuse and recheck from the first step).



**3. Power Input Line Open Circuit Inspection**

Install the "ABS MAIN" fuse. Disconnect the ABS modulator 25P connector. Measure the voltage between the Red/brown wire terminal of the 25P connector and body ground. There should be battery voltage with the ignition switch turned to "ON".

**TOOL:**

**Test probe** **07ZAJ-RDJA110**


**CONNECTION:** Red/blown (+) – Ground (-)

*Is there battery voltage?*

**YES** – GO TO STEP 4.

**NO** –

- Open circuit in Red/brown wire between the ignition switch and ABS modulator.
- If the wire is OK, check the charging system (page 17-6).



**4. Service Check Line Short Circuit Inspection**

Check for continuity between the Brown/white wire terminal of the 25P connector and body ground.

**TOOL:**


**Test probe** **07ZAJ-RDJA110**

**CONNECTION:** Blown/white – Ground

*Is there continuity?*

**YES** – Short circuit in Brown/white wire between the service check connector and ABS modulator.

**NO** – GO TO STEP 5.



## 5. Indicator Operation Inspection

Remove the meter visor (page 2-8).


Remove the dust cover.

With the connector connected, short the Red/black wire terminal of the combination meter 20P connector and ground with a jumper wire. Check the ABS indicator with the ignition switch turned to "ON".

**Does it go off?**

**YES** - GO TO STEP 6.

**NO** - Faulty combination meter.



## 6. Indicator Signal Line Open Circuit Inspection

Remove the jumper wire from the combination meter 20P connector.


Short the Red/black wire terminal of the 25P connector and ground with a jumper wire.

Check the ABS indicator with the ignition switch turned to "ON".

**Does it go off?**

**YES** - GO TO STEP 7.

**NO** - Open circuit in Red/black wire between the combination meter and ABS modulator.



## 7. Logic Ground Line Open Circuit Inspection


Remove a jumper wire from the ABS modulator 25P connector.

Short the Red/black and Green/orange wire terminals of the 25P connector with a jumper wire. Check the ABS indicator with the ignition switch turned to "ON".

**Does it go off?**

**YES** - • Faulty ABS modulator.

**NO** - • Open circuit in Green/orange wire between the ABS modulator and body ground.



## WHEEL SPEED SENSOR

### AIR GAP INSPECTION



Support the motorcycle securely using a hoist or equivalent and raise the wheel off the ground.

Measure the clearance (air gap) between the sensor and pulser ring at several points by turning the wheel slowly.

It must be within specification.

**STANDARD: 0.2 – 1.2 mm (0.01 - 0.05 in)**

The sensor air gap cannot be adjusted. If it is not within specification, check each installation part for deformation, looseness and damage.




### REPLACEMENT

#### FRONT WHEEL SPEED SENSOR


Lift and support the fuel tank (page 3-5).

Disconnect the front wheel speed sensor 2P (Blue) connector.



*Be careful not to damage the brake pipes.*

Remove the wire clip and front wheel speed sensor wire.




## ANTI-LOCK BRAKE SYSTEM (ABS/CBS; CB1000RA)

Release the sensor wire clip from the fork.

Remove the bolt and release the sensor wire from the hose clamp.

Remove the mounting bolts and the wheel speed sensor from the caliper bracket.




Clean around the mounting area of the caliper bracket thoroughly, and be sure that no foreign material is allowed to enter the mounting hole.

*Route the sensor wire properly (page 1-22).*

Install a new speed sensor in the reverse order of removal.


After installation, check the air gap (page 16-23).



### REAR WHEEL SPEED SENSOR


Remove the left seat rail cover (page 2-6).

Disconnect the rear wheel speed sensor 2P (Blue) connector.




Remove the sensor wire clip from the rear fender B.


Release the sensor wire from the guides on the drive chain cover.



Release the sensor wire from the clips on the drive chain cover A.  
Release the sensor wire from the sensor wire guide.



Remove the mounting bolts and the wheel speed sensor from the caliper bracket.




Clean around the mounting area of the caliper bracket thoroughly, and be sure that no foreign material is allowed to enter the mounting hole.

*Route the sensor wire properly (page 1-22).*

Install a new speed sensor in the reverse order of removal.

After installation, check the air gap (page 16-23).




## **ABS MODULATOR/PCV**

### **REMOVAL**

Drain the brake fluid from the front and rear hydraulic systems (page 15-10).


Remove the seat rail cover (page 2-6).  
Remove the regulator/rectifier (page 16-30).

Pull the lock lever up and disconnect the ABS modulator 25P connector.




## ANTI-LOCK BRAKE SYSTEM (ABS/CBS; CB1000RA)


*When loosening the joint nuts, cover the end of the brake pipes to prevent contamination.* Loosen the brake pipe joint nuts and disconnect the brake pipes.



Remove the brake pipe joint bolt and the brake pipe joints.




Remove the oil bolt, sealing washers and the brake hose from the rear master cylinder.



Remove the modulator stay mounting bolts.

*Be careful not to bend or damage the brake pipes during removal.*


Remove the ABS modulator/PCV.






## ANTI-LOCK BRAKE SYSTEM (ABS/CBS; CB1000RA)


Loosen the brake pipe joint nuts and disconnect the brake pipe A and B.




Remove the mounting bolt and the PCV from the ABS modulator stay.




Remove the mounting bolts and the ABS modulator from the ABS modulator stay.



**INSTALLATION**




Install the ABS modulator to the ABS modulator stay.  
Install and tighten the mounting bolts securely.



Install the PCV to the ABS modulator stay.  
Install and tighten the mounting bolt to the specified torque.

**TORQUE: 12 N·m (1.2 kgf·m, 9 lbf·ft)**




**NOTE:**

- Apply brake fluid to the brake pipe joint nut threads.

Connect the brake pipes to the ABS modulator, PCV and brake pipe joint.

Tighten the brake pipe joint nuts to the specified torque.


**TORQUE: 14 N·m (1.4 kgf·m, 10 lbf·ft)**



*Be careful not to bend or damage the brake pipes during installation.*

Install the ABS modulator/PCV.


Install and tighten the modulator stay mounting bolts securely.




Connect the brake hose to the rear master cylinder with the oil bolt and new sealing washers.

Tighten the oil bolt while holding the hose eyelet against the master cylinder.

**TORQUE: 34 N·m (3.5 kgf·m, 25 lbf·ft)**



Assemble the brake pipe joints and tighten the bolt securely.



## ANTI-LOCK BRAKE SYSTEM (ABS/CBS; CB1000RA)


### NOTE:

- Apply brake fluid to the brake pipe joint nut threads.

Connect the brake pipes to the ABS modulator, PCV and brake pipe joint.

Tighten the brake pipe joint nuts to the specified torque.


**TORQUE: 14 N·m (1.4 kgf·m, 10 lbf·ft)**



Connect the ABS modulator 25P connector and push the lock lever down.

Install the regulator/rectifier (page 16-30).  
Install the seat rail cover (page 2-6).

Fill and bleed the hydraulic systems (page 15-10).



## DELAY VALVE

### REMOVAL/INSTALLATION

Drain the brake fluid from the front and rear hydraulic systems (page 15-10).

Remove the right side cover (page 2-5).  
Remove the fuel tank (page 5-60).


Remove the brake pipe joint nuts.  
Remove the mounting bolts and the delay valve.

Installation is in the reverse order of removal.

### TORQUE:

- Brake pipe joint nut:**  
14 N·m (1.4 kgf·m, 10 lbf·ft)
- Delay valve mounting bolt:**  
12 N·m (1.2 kgf·m, 9 lbf·ft)

*Apply brake fluid to the brake pipe joint nut threads.*



# 17. BATTERY/CHARGING SYSTEM



---

SYSTEM DIAGRAM.....	17-2	CHARGING SYSTEM INSPECTION.....	17-6
SERVICE INFORMATION .....	17-3	ALTERNATOR CHARGING COIL .....	17-7
TROUBLESHOOTING .....	17-5	REGULATOR/RECTIFIER .....	17-7
BATTERY .....	17-6		

# BATTERY/CHARGING SYSTEM

## SYSTEM DIAGRAM

CB1000RA shown:



## SERVICE INFORMATION

### GENERAL

#### ▲ WARNING

- The battery gives off explosive gases; keep sparks, flames and cigarettes away. Provide adequate ventilation when charging.
- The battery contains sulfuric acid (electrolyte). Contact with skin or eyes may cause severe burns. Wear protective clothing and a face shield.
  - If electrolyte gets on your skin, flush with water.
  - If electrolyte gets in your eyes, flush with water for at least 15 minutes and call a physician immediately.
- Electrolyte is poisonous.
  - If swallowed, drink large quantities of water or milk and call your local Poison Control Center or call a physician immediately.

#### NOTICE

- *Always turn OFF the ignition switch before disconnecting any electrical component.*
- *Some electrical components may be damaged if terminals or connectors are connected or disconnected while the ignition switch is ON and current is present.*
- For extended storage, remove the battery, give it a full charge, and store it in a cool, dry space. For maximum service life, charge the stored battery every two weeks.
- For a battery remaining in a stored motorcycle, disconnect the negative battery cable from the battery terminal.
- The maintenance free battery must be replaced when it reaches the end of its service life.
- The battery can be damaged if overcharged or undercharged, or if left to discharge for long period. These same conditions contribute to shortening the "life span" of the battery. Even under normal use, the performance of the battery deteriorates after 2-3 years.
- Battery voltage may recover after battery charging, but under heavy load, battery voltage will drop quickly and eventually die out. For this reason, the charging system is often suspected as the problem. Battery overcharge often results from problems in the battery itself, which may appear to be an overcharging symptom. If one of the battery cells is shorted and battery voltage does not increase, the regulator/rectifier supplies excess voltage to the battery. Under these conditions, the electrolyte level goes down quickly.
- Before troubleshooting the charging system, check for proper use and maintenance of the battery. Check if the battery is frequently under heavy load, such as having the headlight and taillight ON for long periods of time without riding the motorcycle.
- The battery will self-discharge when the motorcycle is not in use. For this reason, charge the battery every two weeks to prevent sulfation from occurring.
- When checking the charging system, always follow the steps in the troubleshooting flow chart (page 17-5).
- For battery charging, do not exceed the charging current and time specified on the battery. Use of excessive current or charging time may damage the battery.
- If the battery terminals were disconnected, the data showing the possible travel distance will be reset. After the connection of battery terminals, the data will be indicated in quotation marks ("-----").
- Refer to procedures for alternator removal and disassembly (page 10-4).

#### BATTERY CHARGING

- Turn power ON/OFF at the charger, not at the battery terminal.
- For battery charging, do not exceed the charging current and time specified on the battery. Using excessive current or extending the charging time may damage the battery.
- Quick charging should only be done in an emergency; slow charging is preferred.

#### BATTERY TESTING

Refer to the instructions in the Operation Manual for the recommended battery tester for details about battery testing. The recommended battery tester puts a "load" on the battery so that the actual battery condition can be measured.

**Recommended battery tester**    **BM-210 or BATTERY MATE or equivalent**

# BATTERY/CHARGING SYSTEM

## SPECIFICATIONS

ITEM		SPECIFICATIONS	
Battery	Capacity	12 V – 8.6 Ah	
	Current leakage	2.0 mA max.	
	Voltage (20°C/68°F)	Fully charged	13.0 – 13.2 V
		Needs charging	Below 12.3 V
	Charging current	Normal	0.9 A/5 – 10 h
Quick		4.5 A/1 h	
Alternator	Capacity	0.350 kW/5,000 min <sup>-1</sup> (rpm)	
	Charging coil resistance (20°C/68°F)	0.1 – 1.0 Ω	

## TORQUE VALUES

PCV mounting bolt

12 N·m (1.2 kgf·m, 9 lbf·ft)



---

## TROUBLESHOOTING

### BATTERY IS DAMAGED OR WEAK

#### 1. BATTERY TEST

Remove the battery (page 17-6).

Check the battery condition using the recommended battery tester.

**RECOMMENDED BATTERY TESTER:**  
**BM-210 or BATTERY MATE or equivalent**

*Is the battery in good condition?*

**YES** – GO TO STEP 2.

**NO** – Faulty battery

#### 2. CURRENT LEAKAGE TEST

Install the battery (page 17-6).

Check the battery current leakage test (Leak test; page 17-6).

*Is the current leakage below 2.0 mA?*

**YES** – GO TO STEP 4.

**NO** – GO TO STEP 3.

#### 3. CURRENT LEAKAGE TEST WITHOUT REGULATOR/RECTIFIER CONNECTOR

Disconnect the regulator/rectifier connector and recheck the battery current leakage.

*Is the current leakage below 2.0 mA?*

**YES** – Faulty regulator/rectifier

**NO** –

- Shorted wire harness
- Faulty ignition switch

#### 4. ALTERNATOR CHARGING COIL INSPECTION

Check the alternator charging coil (page 17-7).

*Is the alternator charging coil resistance within 0.1 – 1.0  $\Omega$  (20°C/68°F)?*

**YES** – GO TO STEP 5.

**NO** – Faulty charging coil

#### 5. CHARGING VOLTAGE INSPECTION

Measure and record the battery voltage using a digital multimeter (page 17-6).

Start the engine.

Measure the charging voltage (page 17-7).

Compare the measurement to result of the following calculation.

**STANDARD: Measured BV < Measured CV < 15.5 V**

• BV = Battery Voltage (page 17-6)

• CV = Charging Voltage

*Is the measured charging voltage within the standard voltage?*

**YES** – Faulty battery

**NO** – GO TO STEP 6.

#### 6. REGULATOR/RECTIFIER SYSTEM INSPECTION

Check the voltage and resistance at the regulator/rectifier connector (page 17-7).

*Are the results of checked voltage and resistance correct?*

**YES** – Faulty regulator/rectifier

**NO** –

- Open circuit in related wire
- Loose or poor contacts of related terminal
- Shorted wire harness

## BATTERY

### REMOVAL/INSTALLATION

Remove the seat (page 2-4).

Unhook the battery holder band.

Remove the negative terminal screw, then disconnect the negative cable from the battery negative terminal.

Remove the positive terminal cover.

Remove the positive terminal screw, then disconnect the positive cable from the battery positive terminal.

Remove the battery.

Installation is in the reverse order of removal.

#### NOTE:

Connect the positive cable first and then the negative cable.

### VOLTAGE INSPECTION

Measure the battery voltage using a digital multimeter.



#### VOLTAGE (20°C/68°F):

Fully charged: 13.0 – 13.2 V

Under charged: Below 12.3 V

#### TOOL:

Digital multimeter      Commercially available



## CHARGING SYSTEM INSPECTION

### CURRENT LEAKAGE INSPECTION

Remove the seat (page 2-4).

Turn the ignition switch OFF and disconnect the negative battery cable from the battery.

Connect the ammeter (+) probe to the negative cable and the ammeter (-) probe to the battery (-) terminal.


With the ignition switch OFF, check for current leakage.

- When measuring current using a tester, set it to a high range, and then bring the range down to an appropriate level. Current flow higher than the range selected may blow out the fuse in the tester.
- While measuring current, do not turn the ignition on. A sudden surge of current may blow out the fuse in the tester.

**SPECIFIED CURRENT LEAKAGE: 2.0 mA max.**

If current leakage exceeds the specified value, a shorted circuit is likely.

Locate the short by disconnecting connections one by one and measuring the current.



## CHARGING VOLTAGE INSPECTION

Be sure the battery is in good condition before performing this test.

Warm up the engine to normal operating temperature.

Stop the engine, and connect the multimeter between the positive and negative terminals of the battery.

**NOTE:**

To prevent a short, make absolutely certain which are the positive and negative terminals or cable.


Restart the engine.

With the headlight on Hi beam, measure the voltage on the multimeter when the engine runs at 5,000 min<sup>-1</sup> (rpm).

**STANDARD:**

Measured BV < Measured CV < 15.5 V

- BV = Battery Voltage (page 17-6)
- CV = Charging Voltage



## ALTERNATOR CHARGING COIL

### INSPECTION

*It is not necessary to remove the stator coil to make this test.*

Disconnect the alternator 3P (Black) connector (page 17-8).


Check the resistance between all three Yellow terminals.

**STANDARD:** 0.1 – 1.0 Ω (at 20°C/68°F)

Check for continuity between all three Yellow terminals and ground.

There should be no continuity.

If readings are far beyond the standard, or if any wire has continuity to ground, replace the alternator stator (page 10-7).




## REGULATOR/RECTIFIER

### SYSTEM INSPECTION

Disconnect the regulator/rectifier 2P (Black) and alternator 3P (Black) connectors (page 17-8).

Check connectors for loose contact or corroded terminals.



## BATTERY/CHARGING SYSTEM

If the regulated voltage reading (page 17-7) is out of the specification, measure the voltage between connector terminals (wire harness side) as follows:

Item	Terminal	Specification
Battery charging line	Red (+) and Green (-)	Battery voltage should register
Charging coil line	Yellow and Yellow	0.1 – 1.0 $\Omega$ at (20°C/68°F)
Ground line	Green and ground	Continuity should exist

If all components of the charging system are normal and there are no loose connections at the regulator/rectifier connectors, replace the regulator/rectifier unit.

### REMOVAL/INSTALLATION

Remove the seat (page 2-4).

Remove the wire band.

Disconnect the regulator/rectifier 2P (Black) and alternator 3P (Black) connectors.

Remove the regulator/rectifier stay bolts.

*CB1000RA only:* Remove the PCV mounting bolt.


Remove the mounting bolts, washers, collars, nuts and regulator/rectifier from the stay.

Install the regulator/rectifier in the reverse order of removal.


*CB1000RA only:* Tighten the PCV mounting bolt to the specified torque.

**TORQUE: 12 N·m (1.2 kgf·m, 9 lbf·ft)**


CB1000RA shown: 2P (Black) CONNECTOR




CB1000RA shown: 2P (Black) CONNECTOR



CB1000RA shown: STAY BOLTS



CB1000RA shown: REGULATOR/RECTIFIER



# 18. IGNITION SYSTEM



---

SYSTEM DIAGRAM.....	18-2	CKP SENSOR.....	18-7
SERVICE INFORMATION.....	18-3	IGNITION COIL.....	18-8
TROUBLESHOOTING.....	18-4	IGNITION TIMING.....	18-8
IGNITION SYSTEM INSPECTION.....	18-5		

# IGNITION SYSTEM

## SYSTEM DIAGRAM

CB1000RA shown



# SERVICE INFORMATION

## GENERAL

### NOTICE

- The ECM may be damaged if dropped. Also if the connector is disconnected when current is flowing, the excessive voltage may damage the module. Always turn off the ignition switch before servicing.
- Use spark plug of the correct heat range. Using spark plug with an incorrect heat range can damage the engine.
- Some electrical components may be damaged if terminals or connectors are connected or disconnected while the ignition switch is ON and current is present.
- When servicing the ignition system, always follow the steps in the troubleshooting sequence (page 18-4).
- This motorcycle's Ignition Control Module (ICM) is built into the ECM.
- The ignition timing does not normally need to be adjusted since the ECM is factory preset.
- A faulty ignition system is often related to poor connections. Check those connections before proceeding. Make sure the battery is adequately charged. Using the starter motor with a weak battery results in a slower engine cranking speed as well as no spark at the spark plug.
- Refer to the following components informations.
  - ECM (page 5-100).
  - Sidestand switch (page 20-30)
  - Engine stop relay (page 5-99)
  - Engine stop switch (page 20-26)
  - Ignition switch (page 20-25)
  - Clutch switch (page 20-29)

## SPECIFICATIONS

ITEM		SPECIFICATIONS
Spark plug	NGK	IMR9E-9HES
	DENSO	VUH27ES
Spark plug gap		0.80 – 0.90 mm (0.031 – 0.035 in)
Ignition coil peak voltage		100 V minimum
CKP sensor peak voltage		0.7 V minimum
Ignition timing ("F"mark)		5° BTDC at idle



## TORQUE VALUES

Timing hole cap  
Spark plug

18 N·m (1.8 kgf·m, 13 lbf·ft)  
16 N·m (1.6 kgf·m, 12 lbf·ft)

Apply grease to the threads.

## TOOLS

<p>Imrie diagnostic tester (model 625) or Peak voltage adaptor 07HGJ-0020100</p>  <p>with commercially available digital multimeter (impedance 10 MΩ/DCV minimum)</p>	<p>Test probe 07ZAJ-RDJA110</p> 
--	--

# IGNITION SYSTEM

## TROUBLESHOOTING

- Inspect the following before diagnosing the system.
  - Faulty spark plug
  - Loose spark plug cap connection
  - Loose ignition coil connectors
  - Water got into the spark plug cap (shorting the ignition coil secondary voltage)
- If there is no spark at any cylinder, temporarily exchange the ignition coil with the other good one and perform the spark test. If there is spark, the exchanged ignition coil is faulty.
- "Initial voltage" of the ignition primary coil is the battery voltage with the ignition switch turned ON and engine stop switch turned "○" (When the engine is not cranked by the starter motor).

### No spark at all plugs

	Unusual condition	Probable cause (Check in numerical order)
Ignition coil primary voltage	No initial voltage with the ignition ON and engine stop switch turned "○" (other electrical components are normal).	<ol style="list-style-type: none"> <li>1. Faulty engine stop relay.</li> <li>2. An open circuit in Black/white wire between the ignition coil and engine stop relay.</li> <li>3. Loose or poor connect of the ignition coil connectors, or an open circuit in primary coil (Check at the ECM connector).</li> <li>4. Faulty ECM (in case when the initial voltage is normal while disconnecting ECM connectors).</li> </ol>
	Initial voltage is normal, but it drops down to 2 – 4 V while cranking the engine.	<ol style="list-style-type: none"> <li>1. Incorrect peak voltage adaptor connections.</li> <li>2. Undercharged battery.</li> <li>3. No voltage between the Black/white (+) and body ground (–) at the ECM connector or loosen ECM connection.</li> <li>4. An open circuit or loose connection in Green wire.</li> <li>5. An open circuit or loose connection in Yellow/blue or Blue/yellow wires between the ignition coils and ECM.</li> <li>6. Short circuit in ignition primary coil.</li> <li>7. Faulty sidestand switch or neutral switch.</li> <li>8. An open circuit or loose connection in No.7 related circuit wires.               <ul style="list-style-type: none"> <li>– Sidestand switch line: Green/white wire</li> <li>– Neutral switch line: Light green or Green/red wires</li> </ul> </li> <li>9. Faulty CKP sensor (measure the peak voltage).</li> <li>10. Faulty ECM (in case when above No. 1 - 9 are normal).</li> </ol>
	Initial voltage is normal, but no peak voltage while cranking the engine.	<ol style="list-style-type: none"> <li>1. Faulty peak voltage adaptor connections.</li> <li>2. Faulty peak voltage adaptor.</li> <li>3. Faulty CKP sensor (Measure the peak voltage).</li> <li>4. Faulty ECM (in case when above No.1- 3 are normal).</li> </ol>
	Initial voltage is normal, but peak voltage is lower than standard value.	<ol style="list-style-type: none"> <li>1. The multimeter impedance is too low; below 10 MΩ/DCV.</li> <li>2. Faulty CKP sensor (Measure the peak voltage).</li> <li>3. Cranking speed is too low (battery under charged).</li> <li>4. The sampling timing of the tester and measured pulse were not synchronized (system is normal if measured voltage is over the standard voltage at least once).</li> <li>5. Faulty ECM (in case when above No. 1 – 4 are normal).</li> </ol>
	Initial and peak voltage are normal, but does not spark.	<ol style="list-style-type: none"> <li>1. Faulty spark plug or leaking ignition coil secondary current ampere.</li> <li>2. Faulty ignition coil (s).</li> </ol>
CKP sensor	Peak voltage is lower than standard value.	<ol style="list-style-type: none"> <li>1. The multimeter impedance is too low; below 10 MΩ/DCV.</li> <li>2. Cranking speed is too low (battery undercharged).</li> <li>3. The sampling timing of the tester and measured pulse were not synchronized (system is normal if measured voltage is over the standard voltage at least once).</li> <li>4. Faulty CKP sensor (in case when above No. 1 – 3 are normal).</li> </ol>
	No peak voltage.	<ol style="list-style-type: none"> <li>1. Faulty peak voltage adaptor.</li> <li>2. Faulty CKP sensor.</li> </ol>




## IGNITION SYSTEM INSPECTION

- If there is no spark at any plug, check all connections for loose or poor contact before measuring each peak voltage.
- Use recommended digital multimeter or commercially available digital multimeter with an impedance of 10 M $\Omega$ /DCV minimum.
- The display value differs depending upon the internal impedance of the multimeter.
- If the Imrie diagnostic tester (model 625) is used, follow the manufacture's instruction.

Connect the peak voltage tester or peak voltage adaptor to the digital multimeter.

### TOOLS:

Imrie diagnostic tester (model 625) or  
Peak voltage adaptor 07HGJ-0020100  
with commercially available digital multimeter  
(impedance 10 M $\Omega$ /DCV minimum)




## IGNITION COIL PRIMARY PEAK VOLTAGE

- Check all system connections before inspection. If the system is disconnected, incorrect peak voltage might be measured.
- Check cylinder compression and check that the spark plugs are installed correctly.

Disconnect the spark plug caps from the spark plugs (page 3-8).

Shift the transmission into neutral.

Connect a known-good spark plug to the spark plug cap and ground the spark plug to the cylinder head as done in a spark test.



With the ignition coil primary wire connected, connect the peak voltage adaptor or peak voltage tester to the ignition coil primary wire terminals.


### CONNECTION:

#1/#4 coil:

Yellow/blue (+) - body ground (-)

#2/#3 coil:

Blue/yellow (+) - body ground (-)



## IGNITION SYSTEM

Avoid touching the spark plugs and tester probes to prevent electric shock.

Turn the ignition switch ON and engine stop switch "O".

Check for initial voltage at this time.

The battery voltage should be measured.

If the initial voltage cannot be measured, check the power supply circuit (refer to the troubleshooting, page 18-4).

Shift the transmission into neutral.

Crank the engine with the starter motor and read ignition coil primary peak voltage.

### PEAK VOLTAGE: 100V minimum

If the peak voltage is abnormal, refer to the troubleshooting chart (page 18-4).

### CKP SENSOR PEAK VOLTAGE

- Check all system connection before inspection. If the system is disconnected, incorrect peak voltage might be measured.
- Check cylinder compression and check that the spark plugs are installed correctly.

Disconnect the ECM 33P (Black and Light gray) connectors from the ECM (page 5-100).

Connect the peak voltage tester or peak voltage adaptor probes to the ECM connector terminals of the wire harness side.

#### TOOLS:

Imrie diagnostic tester (model 625) or

Peak voltage adaptor 07HGJ-0020100

with commercially available digital multimeter (impedance 10 M $\Omega$ /DCV minimum)

Test probe 07ZAJ-RDJA110

#### CONNECTION:

Yellow (+) – White/yellow (-)

Crank the engine with the starter motor and read the peak voltage.

### PEAK VOLTAGE: 0.7 V minimum



If the peak voltage measured at ECM 33P connectors is abnormal, measure the peak voltage at the CKP sensor connector.

Disconnect the CKP sensor 2P (Red) connector and connect the tester probes to the terminal (Yellow and White/yellow).

In the same manner as at the ECM connectors, measure the peak voltage and compare it to the voltage measured at the ECM connectors.

- If the peak voltage measured at the ECM is abnormal and the one measured at the CKP sensor is normal, the wire harness has an open circuit or loose connection.
- If both peak voltage measured are abnormal, check each item in the troubleshooting chart (page 18-4).

If all items are normal, the CKP sensor is faulty. See following steps for CKP sensor replacement.




## CKP SENSOR

### REPLACEMENT

Remove the right side cover (page 2-5).


Disconnect the CKP sensor 2P (Red) connector.

Remove the air cleaner housing (page 5-62).



Remove the CKP wire from the wire clamp and guide.

Remove the right crankcase cover (page 9-16).



Remove the bolt/washer.

Remove the wire grommet from the cover.

Remove the mounting bolts and CKP sensor.


Install the new CKP sensor and tighten the mounting bolts securely.

Route the CKP sensor wire into the groove of the right crankcase cover.

Apply sealant to the grommet seating surface. Install the grommet into the cover groove properly. Install the bolt/washer to clamp the CKP sensor wire, then tighten the bolt securely.

Install the right crankcase cover (page 9-34).

Install the air cleaner housing (page 5-77).



## IGNITION SYSTEM

### IGNITION COIL

#### REMOVAL/INSTALLATION


Disconnect the spark plug caps from the spark plugs (page 3-8).

Disconnect the ignition coil primary wires from the ignition coil.

Remove the bolts and ignition coil.

*Route the spark plug wires properly (page 1-22).*

Installation is in the reverse order of removal.





### IGNITION TIMING

Warm up the engine.

Stop the engine and remove the timing hole cap.

*Read the instructions for timing light operation.*


Connect the timing light to the No.1 spark plug wire.




Start the engine and let it idle.

**IDLE SPEED:  $1,200 \pm 100 \text{ min}^{-1}$  (rpm)**

The ignition timing is correct if the "F" mark on the CKP sensor rotor aligns with the index notch on the right crankcase cover at idle.




Check the O-ring is in good condition, replace if necessary.  
Apply grease to the timing hole cap threads and install the O-ring and timing hole cap.



Tighten the timing hole cap to the specified torque.

**TORQUE: 18 N·m (1.8 kgf·m, 13 lbf·ft)**



---

**MEMO**

---


# 19. ELECTRIC STARTER

---


SYSTEM DIAGRAM.....	19-2	STARTER MOTOR.....	19-6
SERVICE INFORMATION.....	19-3	STARTER RELAY SWITCH.....	19-12
TROUBLESHOOTING.....	19-4	DIODE.....	19-14

# ELECTRIC STARTER SYSTEM DIAGRAM

CB1000RA shown:



R .... RED  
 W .... WHITE  
 Y .... YELLOW  
 G .... GREEN  
 BI .... BLACK  
 Lg.... LIGHT GREEN





## SERVICE INFORMATION

### GENERAL

#### NOTICE

If the current is kept flowing through the starter motor to turn it while the engine is not cranking over, the starter motor may be damaged.

- Always turn the ignition switch OFF before servicing the starter motor. The motor could suddenly start, causing serious injury.
- The starter motor can be serviced with the engine in the frame.
- When checking the starter system, always follow the steps in the troubleshooting flow chart (page 19-4).
- A weak battery may be unable to turn the starter motor quickly enough, or supply adequate ignition current.
- Refer to the procedure for starter clutch servicing (page 9-29).
- Refer to the following components informations.
  - Ignition switch (page 20-25)
  - Engine stop switch (page 20-26)
  - Starter switch (page 20-26)
  - Neutral switch (page 20-30)
  - Sidestand switch (page 20-30)
  - Clutch switch (page 20-29)

### SPECIFICATION

		Unit: mm (in)	
ITEM	STANDARD	SERVICE LIMIT	
Starter motor brush length	12.0 (0.47)	6.5 (0.26)	

### TORQUE VALUE

Starter motor terminal nut                      12 N·m (1.2 kgf·m, 9 lbf·ft)

## TROUBLESHOOTING

### Starter motor does not turn

#### 1. Fuse Inspection

Check for blown main fuse or sub fuse.

**Did the fuse blow?**

**YES** – Replace the fuse

**NO** – GO TO STEP 2.

#### 2. Battery Inspection

Make sure the battery is fully charged and in good condition.

**Is the battery in good condition?**

**YES** – GO TO STEP 3.

**NO** – Replace the battery (page 17-6)

#### 3. Starter Relay switch operation

Check the starter relay switch operation.

You should hear the relay "CLICK" when the starter switch button is depressed.

**Did the starter relay "CLICK"?**

**YES** – GO TO STEP 4.

**NO** – GO TO STEP 5.

#### 4. Starter Motor Inspection

Apply battery voltage to the starter motor directly and check the operation.

**Did the starter motor turn?**

**YES** – • Poorly connected starter motor cable  
• Faulty starter relay switch (page 19-12)

**NO** – Faulty starter motor (page 19-6)

#### 5. Relay Coil Ground Wire Lines Inspection

Disconnect the starter relay switch connector, and check the relay coil ground wire lines as below for continuity:

1. Green/red terminal-clutch switch diode – neutral switch line (with the transmission in neutral and clutch lever released).
2. Green/red terminal-clutch switch – sidestand switch line (in any gear except neutral, and with the clutch lever pulled in and the sidestand up).

**Is there continuity?**

**YES** – GO TO STEP 6.

**NO** – • Faulty neutral switch (page 20-30)  
• Faulty clutch diode (page 19-14)  
• Faulty clutch switch (page 20-29)  
• Faulty sidestand switch (page 20-30)  
• Loose or poor contact connector  
• Open circuit in wire harness

#### 6. Starter Relay Switch Continuity Inspection

Disconnect the starter relay switch 4P connector.

Connect a fully charged 12 V battery positive wire to the relay switch Yellow/red wire terminal and negative wire to the Green/red wire terminal.

Check the continuity between the starter relay switch large terminals while the battery connected.

**Is there continuity?**

**YES** – Loose or poor contact of the starter relay switch 4P connector

**NO** – Faulty starter relay switch

The starter motor turns when the transmission is in neutral, but does not turn with the transmission in any position except neutral, with the sidestand up and the clutch lever pulled in.

### 1. Clutch Switch Inspection

Check the clutch switch operation (page 20-29).

*Is the clutch switch operation normal?*

**YES** – GO TO STEP 2.

**NO** – Faulty clutch switch

### 2. Sidestand Switch Inspection

Check the sidestand switch operation (page 20-30).

*Is the sidestand switch operation normal?*

**YES** – • Open circuit in wire harness  
• Loose or poor contact connector

**NO** – Faulty sidestand switch

### Starter motor turns engine slowly

- Low battery voltage
- Poorly connected battery terminal cables
- Poorly connected starter motor cable
- Faulty starter motor
- Poor connected battery ground cable

### Starter motor turns, but engine does not turn

- Starter motor is running backwards
  - Starter motor assembled improperly
  - Terminals connected improperly
- Faulty starter clutch
- Damaged or faulty starter driven gear, idle gear and/or reduction gear

### Starter relay switch "Clicks", but engine does not turn over

- Crankshaft does not turn due to engine problems

**STARTER MOTOR**

**REMOVAL**


- With the ignition switch OFF, remove the negative cable at the battery before servicing the starter motor.

Remove the air cleaner housing (page 5-62)

Remove the rubber cap, then remove the terminal nut and starter motor cable from the starter motor.

Remove the starter motor mounting bolts and ground cable.


Pull the starter motor out of the crankcase.



**DISASSEMBLY**


Remove the following:

- Starter motor O-ring
- Starter motor case bolts/O-rings




*Record the location and number of shims.*

- Front cover
- Seal ring
- Lock washer
- Insulated washer
- Shim(s)




- Record the location  
and number of  
shims.
- Rear cover assembly
  - Seal ring
  - Shim(s)
  - Armature




## INSPECTION

Check the bushing in the rear cover for wear or damage.



Check the oil seal for deterioration or damage, and needle bearing for wear or damage.


OIL SEAL



NEEDLE BEARING

Do not use emery or sand paper on the commutator.

Check the commutator bars of the armature for discoloration.




## ELECTRIC STARTER

Check for continuity between pairs of commutator bars.

There should be continuity.


Should be CONTINUITY:



Check for continuity between each commutator bar and the armature shaft.

There should be no continuity.


Should NOT be CONTINUITY:



Check for continuity between the insulated brush and cable terminal.


There should be continuity.

INSULATED BRUSH



Check for continuity between the cable terminal and the rear cover.


There should be no continuity.




Record the location  
and number of  
insulators.

Remove the following:

- Nut
- Washer
- Insulators
- O-ring
- Brush holder assembly




Remove the brush springs and brushes from the brush holder.




Inspect the brushes for damage and measure the brush length.

**SERVICE LIMIT: 6.5 mm (0.26 in)**




# ELECTRIC STARTER


## ASSEMBLY



Install the brushes and brush springs to the brush holder.



Install the brush holder into the rear cover, aligning the holder tab with the rear cover groove.






Install the insulators properly as noted during removal.

Install the following:


- New O-ring
- Insulators
- Washer
- Nut



Install the armature in the motor case. When installing the armature into the motor case, hold the armature tightly to keep the magnet of the case from pulling the armature against it.


### NOTICE

The coil may be damaged if the magnet pulls the armature against the case.




Install the shims properly as noted during removal.

Install a new seal ring onto the motor case. Install the shim(s) onto the armature shaft. Apply thin coat of grease to the armature shaft end. Install the rear cover assembly, while pushing in the brushes into the brush holder and aligning with the index lines of the motor case and rear cover.




Install the shims properly as noted during removal.

Install the shim(s) and insulated washer onto the armature shaft. Install a new seal ring onto the motor case. Apply grease to the oil seal lip and needle bearing in the front cover. Install the lock washer to the front cover with the lock washer tabs facing to front cover, and install them onto the armature shaft.




## ELECTRIC STARTER

Align each index line of the front and rear cover with that of motor case.  
Install the new O-rings onto the motor case bolts.  
Install and tighten the case bolts securely.



### INSTALLATION

Apply engine oil to a new O-ring and install it to the starter motor groove.



Install the starter motor into the crankcase.

*Route the wires properly (page 1-22).*


Install the ground cable and mounting bolts, and tighten the bolts securely.  
Install the starter motor cable, then tighten the terminal nut to the specified torque.

**TORQUE: 12 N·m (1.2 kgf·m, 9 lbf·ft)**

Install the rubber cap securely.

Install the air cleaner housing (page 5-77).

Connect the battery negative cable.



## STARTER RELAY SWITCH

### OPERATION INSPECTION

Remove the seat (page 2-4).

Remove the starter relay switch cover (page 19-13).


Shift the transmission into neutral.

Turn the ignition switch ON and engine stop switch "O".

Press the starter switch button.

The coil is normal if the starter relay switch clicks.

If you don't hear the switch "click", inspect the starter relay switch (page 19-13).




### GROUND LINE INSPECTION

Disconnect the starter relay switch 4P (Black) connector.

Check for continuity between the Green/red wire (ground line) and ground.


If there is continuity when the transmission is in neutral and clutch lever released or when the clutch lever pulled and the side stand up, the ground circuit is normal (In neutral, there is a slight resistance due to the diode).



### INPUT LINE INSPECTION

Check for continuity between the Red terminal and Yellow/red terminal.

If there is continuity when the ignition switch ON and starter switch pushed, the input line is normal.




### CONTINUITY INSPECTION

Remove the starter relay switch (page 19-14).

Connect a fully charged 12 V battery positive wire to the relay switch Yellow/red wire terminal and negative wire to the Green/red wire terminal.

Connect an ohmmeter to the starter relay switch large terminals.

There should be continuity between the large terminals when the battery is connected, and no continuity when the battery is disconnected.



### REMOVAL/INSTALLATION

Remove the seat (page 2-4).

Remove the battery negative cable (page 17-6).


Remove the starter relay switch cover.

Disconnect the starter relay switch 4P (Black) connector.

Remove the terminal bolts and disconnect the starter relay switch cables.

Pull the starter relay switch out from the stay.

Installation is in the reverse order of removal.



**DIODE**


**REMOVAL/INSTALLATION**

Remove the seat (page 2-4).

Remove the fuse/relay box cover and remove the diode.

Install the diode in the reverse order of removal.


CB1000RA shown:



**INSPECTION**

Check for continuity between the diode terminals. When there is continuity, a small resistance value will register.

If there is continuity, in one direction, the diode is normal.



# 20. LIGHTS/METER/SWITCHES


---

SYSTEM LOCATION.....	20-2	ENGINE OIL PRESSURE INDICATOR/ EOP SWITCH .....	20-21
SERVICE INFORMATION .....	20-3	FUEL LEVEL INDICATOR .....	20-23
TROUBLESHOOTING .....	20-5	FUEL LEVEL SENSOR .....	20-24
HEADLIGHT.....	20-6	IGNITION SWITCH .....	20-25
POSITION LIGHT .....	20-10	HANDLEBAR SWITCHES .....	20-26
TURN SIGNAL LIGHT.....	20-11	BRAKE LIGHT SWITCH .....	20-28
BRAKE/TAILLIGHT .....	20-12	CLUTCH SWITCH .....	20-29
LICENSE LIGHT.....	20-13	NEUTRAL SWITCH.....	20-30
COMBINATION METER.....	20-13	SIDESTAND SWITCH.....	20-30
VS SENSOR .....	20-17	HORN .....	20-32
TACHOMETER .....	20-19	TURN SIGNAL RELAY .....	20-33
ENGINE COOLANT TEMPERATURE INDICATOR/ECT SENSOR .....	20-20		

# LIGHTS/METER/SWITCHES

## SYSTEM LOCATION

CB1000RA shown:



# SERVICE INFORMATION

## GENERAL

### NOTICE

- A halogen headlight bulb becomes very hot while the headlight is ON, and remain hot for a while after it is turned OFF. Be sure to let it cool down before servicing.
- Note the following when replacing the halogen headlight bulb.
  - Wear clean gloves while replacing the bulb. Do not put finger prints on the headlight bulb, as they may create hot spots on the bulb and cause it to fail.
  - If you touch the bulb with your bare hands, clean it with a cloth moistened with denatured alcohol to prevent its early failure.
  - Be sure to install the dust cover after replacing the bulb.
- Use an electric heating element to heat the water/coolant mixture for the ECT sensor inspection. Keep flammable materials away from the electric heating element. Wear protective clothing, insulated gloves and eye protection.
- Check the battery condition before performing any inspection that requires proper battery voltage.
- A continuity test can be made with the switches installed on the motorcycle.
- The following color codes are used throughout this section.

Bu: Blue	G: Green	Lg: Light Green	R: Red
Bl: Black	Gr: Gray	O: Orange	W: White
Br: Brown	Lb: Light Blue	P: Pink	Y: Yellow

## SPECIFICATIONS

ITEM		SPECIFICATIONS	
Bulbs	Headlight	Hi	12 V – 60 W
		Lo	12 V – 55 W
	Position light	LED	
	Brake/tail light	LED	
	License light	12 V – 5 W	
	Turn signal light	12 V – 21 W x 4	
	Instrument light	LED	
	Turn signal indicator	LED	
	High beam indicator	LED	
	Neutral indicator	LED	
	MIL	LED	
	Engine oil pressure indicator	LED	
	Engine coolant temperature indicator	LED	
	Immobilizer system (HISS) indicator	LED	
ABS indicator (CB1000RA)	LED		
Fuse	Main fuse	30 A	
	PGM-FI/IGN fuse	20 A	
	Sub fuse	10 A x 5, 20 A x 1	
	ABS main fuse (CB1000RA)	10 A	
	ABS fail-safe relay fuse (CB1000RA)	30 A	
	ABS motor fuse (CB1000RA)	30 A	
Tachometer peak voltage		10.5 V minimum	
ECT sensor resistance	80 °C (176 °F)	2.1 – 2.6 kΩ	
	120 °C (248 °F)	0.65 – 0.73 kΩ	


## LIGHTS/METER/SWITCHES

### TORQUE VALUES

EOP switch wire terminal bolt	2.0 N·m (0.2 kgf·m, 1.5 lbf·ft)	
EOP switch	12 N·m (1.2 kgf·m, 9 lbf·ft)	Apply sealant to the threads
Neutral switch	12 N·m (1.2 kgf·m, 9 lbf·ft)	
Ignition switch mounting bolt	25 N·m (2.5 kgf·m, 18 lbf·ft)	One-way bolt
License light case mounting screw	1.7 N·m (0.2 kgf·m, 1.3 lbf·ft)	
Clutch switch mounting screw	1.2 N·m (0.1 kgf·m, 0.9 lbf·ft)	
Sidestand switch bolt	10 N·m (1.0 kgf·m, 7 lbf·ft)	


### TOOLS

Imrie diagnostic tester (model 625)  
or  
Peak voltage adaptor  
07HGJ-0020100




with commercially available digital  
multimeter (impedance 10 M $\Omega$ /DCV  
minimum)

Test probe  
07ZAJ-RDJA110



Inspection adaptor  
07GMJ-ML80100





## TROUBLESHOOTING

### VS SENSOR/SPEEDOMETER

The speedometer does not indicate and the odometer/trip meter indicates "-----".

Faulty EEPROM in ECM

The odometer/trip meter operate normally, but the speedometer does not operate  
Faulty speedometer in combination meter

The speedometer operate normally, but the odometer/trip meter does not operate  
Faulty odometer/trip meter in combination meter

The speedometer operates abnormally

#### 1. Fuse Inspection

Check for blown main fuse or sub fuse.

*Is the fuse blown?*

**YES** – Replace the fuse

**NO** – GO TO STEP 2.

#### 2. Battery Inspection

Make sure the battery is fully charged and in good condition.

*Is the battery in good condition?*

**YES** – GO TO STEP 3.

**NO** – Replace the battery

#### 3. VS Sensor Power Input Voltage Inspection

Check for loose or poor contact of the VS sensor 3P (Natural) connector.

With the ignition switch ON, and measure the voltage at the VS sensor connector White/black terminal.

*Is there Battery Voltage?*

**YES** – GO TO STEP 4.

**NO** – • Loose or poor contact of related terminals  
• Open circuit in White/black wire

#### 4. Combination Meter Input Voltage Inspection

Check for loose or poor contact of the combination meter 20P (Black) connector.

With the ignition switch ON, and measure the voltage at bottom of the combination meter 20P (Black) connector Black/brown terminal.

*Is there Battery Voltage?*

**YES** – GO TO STEP 5.

**NO** – • Loose or poor contact of related terminals  
• Faulty combination meter

#### 5. VS Sensor Signal Line Inspection

With the ignition switch OFF, check for continuity of the Pink/blue wire between the terminals of the VS sensor and speedometer.

*Is there continuity?*

**YES** – GO TO STEP 6.

**NO** – Open circuit in Pink/blue wire

#### 6. VS Sensor Signal Inspection

Support the motorcycle using a hoist or other support to raise the rear wheel off the ground.

Measure the output voltage (sensor signal) at the combination meter with the ignition switch is ON while slowly turning the rear wheel by your hand (page 20-17).

**Standard: Repeat 0 to 5 V**

*Is the voltage as specified?*

**YES** – Faulty speedometer

**NO** – Faulty VS sensor

# HEADLIGHT

## REMOVAL/INSTALLATION

Remove the meter visor (page 2-8).

Disconnect the following connector:

- position light 2P (Natural)
- right front turn signal light 2P (Light blue)
- left front turn signal light 2P (Orange)

Remove the dust cover and disconnect the combination meter 20P (Black) connector.


Remove the mounting bolts and collars. Remove the grommets on the headlight unit from the pins on the headlight stay, then remove the headlight unit/position light/combination meter as an assembly.

Disconnect the headlight 3P connector.

Remove the screw and harness clamp.


Installation is in the reverse order of removal.

*Route the wires properly (page 1-26).*



## BULB REPLACEMENT



Remove the headlight mounting bolts and collars.




Raise lightly the headlight and pull forward carefully to remove the grommets from the pins on the headlight stay.

Put carefully headlight on the front fender. Place a shop towel between the headlight and front fender.


Disconnect the headlight 3P connector.



Remove the dust cover from the headlight unit.



Unlock the bulb retainer while turning it counter-clockwise, then remove the bulb retainer and headlight bulb.




## LIGHTS/METER/SWITCHES

Install the headlight bulb aligning its tabs with the grooves in the headlight unit.


If you touch the bulb with your bare hands, clean it with cloth moistened with denatured alcohol to prevent early bulb failure.

### NOTICE


*Avoid touching the halogen headlight bulb. Finger prints can create hot spots that cause a bulb to break.*



Install the bulb retainer to the headlight unit aligning its grooves with the tabs on the headlight unit. Lock the bulb retainer while turning it clockwise.




Install the dust cover with its "TOP" mark facing up. Install the headlight (page 20-6).



### DISASSEMBLY/ASSEMBLY


- Remove the headlight (page 20-6).
- Remove the combination meter (page 20-13).
- Remove the mounting screws.



*At removal, be careful not to damage the tabs on the headlight under cover.*

Remove the headlight lower cover while releasing its tabs from the holes on the headlight and right/left headlight cover.


Remove the position light wire from the headlight hole.



Remove the mounting screws, then disassemble the right and left headlight cover from the headlight unit.

Assemble the right and left headlight cover to the headlight unit.

Install and tighten the mounting screws securely.




## LIGHTS/METER/SWITCHES

*At installation, be careful not to damage the tabs on the headlight under cover.*


Install the headlight lower cover while aligning its tabs with the holes on the headlight and right/left headlight cover.

Route the position light wire properly.



Install and tighten the mounting screws securely.

Install the combination meter (page 20-13).  
Install the headlight (page 20-6).




## POSITION LIGHT

### INSPECTION

Turn the ignition switch ON, and check the position light operation.

Check that LED in the position light unit illuminate with the while ignition switch ON.

If any LED does not turn on, replace the position light assembly (page 20-11).



**REMOVAL/INSTALLATION**

Remove the headlight lower cover (page 20-8).

Remove the screws.


Release the tab on the position light unit from the groove on the position light ring, then remove the position light unit.

Remove hooks from the headlight lower cover, then remove the position light ring from the headlight lower cover.

Installation is in the reverse order of removal.

**NOTE:**


At installation, align the tab on the position light unit with the groove on the position light ring.



**TURN SIGNAL LIGHT**

**BULB REPLACEMENT**

Remove the screw.




Remove the turn signal light lens and seal rubber.

While pushing in, turn the bulb counterclockwise to remove it and replace with a new one.

Check the seal rubber for deterioration or damage and replace it if necessary.

At installation, align the tab of the turn signal light lens with the slit of the turn signal light unit.

Install the turn signal light lens in the reverse order of removal.



## REMOVAL/INSTALLATION

### NOTE:


For rear turn signal light unit removal/installation, refer to the rear fender/rear fender stay disassembly/assembly (page 2-10).

### FRONT TURN SIGNAL LIGHT UNIT

Remove the headlight (page 20-6).

Remove the mounting nut, setting plate and turn signal light unit.

Installation is in the reverse order of removal.




## BRAKE/TAILLIGHT

### INSPECTION

Turn the ignition switch ON, and check the taillight operation.

Check that all LED in the brake/taillight unit illuminate with the front brake lever and/or rear brake pedal applied.

If any LED does not turn on, replace the brake/taillight assembly (page 20-12).



### REMOVAL/INSTALLATION


Remove the rear cowl (page 2-9).

Remove the rear fender A/rear fender stay (page 2-9).

Disconnect the brake/taillight 3P (Natural) connector.

Remove the screw, mounting bolts and collars, then remove the brake/taillight.

Installation is in the reverse order of removal.






## LICENSE LIGHT

### BULB REPLACEMENT

Remove the screws and license light case.




*Do not turn the bulb while removing it.*

Pull out the license light bulb and replace it with a new one.

Install the license light case in the reverse order of removal.

Tighten the screws to the specified torque.

**TORQUE: 1.7 N·m (0.2 kgf·m, 1.3 lbf·ft)**




## COMBINATION METER

### REMOVAL/INSTALLATION

Remove the headlight (page 20-6)

Remove the mounting bolts and combination meter.


Install the combination meter in the reverse order of the removal.




# LIGHTS/METER/SWITCHES

## DISASSEMBLY


Remove the upper meter case screws.




Remove the upper case from the under case.




Remove the switch extension rods.



Disassemble the reflecting plate, under case and the circuit board.




Remove the screws and indicator lens the circuit board.



## ASSEMBLY

Assemble the combination meter in the reverse order of disassembly.



## POWER/GROUND LINE INSPECTION


If any indication in the combination meter is abnormal, check the following item.

Remove the meter visor (page 2-8).

Remove the dust cover.

Disconnect the combination meter 20P (Black) connector.


Check the following at the wire harness side connector terminals of the combination meter.



## LIGHTS/METER/SWITCHES


### Power input line

Measure the voltage between the Black/brown wire terminal (+) and body ground (-). There should be battery voltage with the ignition switch ON. If there is no voltage, check for open circuit in Black/brown wire.




### Back-up voltage line

Measure the voltage between the Red/green wire terminal (+) and body ground (-). There should be battery voltage at all times. If there is no voltage, check for open circuit in Red/green wire.



### Ground line

Measure the continuity between the Green/black wire terminal and body ground. There should be continuity. If there is no continuity, check for open circuit in Green/black wire.



# VS SENSOR


## SYSTEM INSPECTION

Check that the indicators function properly. If they do not function, perform the power and ground line inspection of the combination meter (page 20-15).

Remove the meter visor (page 2-8).

Remove the dust cover.

Support the motorcycle securely using a safety stand or hoist, and raise the rear wheel off the ground.



Shift the transmission into neutral and turn the ignition switch ON.


Measure the voltage between the Pink/blue (+) and Green/black (-) wire terminals of the wire harness side connector.

Slowly turn the rear wheel by hand.

There should be 0 to 5 V pulse voltage.

- If pulse voltage appears, replace the combination meter circuit board (page 20-14).
  - If pulse voltage does not appear, check for open or short circuit in the Pink/blue and Green/black wires.
- If the wires are OK, check the VS sensor (page 20-17).

Viewed from harness side/  
the 20P (Black) connector:



## VS SENSOR INSPECTION

Remove the air cleaner housing (page 5-62).


Disconnect the VS sensor 3P (Natural) connector. Turn the ignition switch to ON and measure the voltage between the White/black (+) and Green/black (-) wire terminals at the harness side 3P connector.

**CONNECTION: White/black (+) – Green/black (-)**  
**STANDARD: Battery voltage**

There should be battery voltage.

If there is no voltage, check for open circuit in related wires.

If there is voltage, check the VS sensor as follows.



## LIGHTS/METER/SWITCHES

Support the motorcycle securely using a safety stand or hoist, and raise the rear wheel off the ground.

Connect the inspection adaptor to the sensor VS sensor 3P (Natural) connectors.

### TOOL:

**Inspection adaptor** 07GMJ-ML80100


Shift the transmission into neutral and turn the ignition switch ON.

Measure the voltage between the Red clip (+) and White (-) wire terminals of the wire harness side connector.

Slowly turn the rear wheel by hand.

There should be 0 to 5 V pulse voltage.

If pulse voltage does not appear, replace the VS sensor (page 20-18).




## REMOVAL/INSTALLATION

Remove the air cleaner housing (page 5-62).


Disconnect the VS sensor 3P (Natural) connector.

Remove the bolt and VS sensor.



Check the O-ring is in good condition, replace if necessary.

Installation is in the reverse order of removal.




# TACHOMETER

## SYSTEM INSPECTION

When the ignition switch is turned ON, check that the tachometer indicates as shown in the illustration.


If the tachometer does not indicate as shown in the illustration, check for combination meter power input line (page 20-15).



Remove the meter visor (page 2-8).

Remove the dust cover.

Check for loose or poor contact terminals at the combination meter 20P (Black) connector.



Connect the peak voltage adaptor or Imrie diagnostic tester probes to the combination meter 20P (Black) connector Yellow/green (+) and Green/black (-) terminals.

### TOOLS:

Imrie diagnostic tester (model 625) or  
 Peak voltage adaptor 07HGJ-0020100  
 with commercially available digital multimedia  
 (impedance 10 MΩ/DCV minimum)

**CONNECTION:** Yellow/green (+) – Green/black (-)


Start the engine and measure the tachometer input peak voltage.

**PEAK VOLTAGE: 10.5 V minimum**

If the peak voltage is normal, replace the combination meter circuit board (page 20-14).

If the measured value is below 10.5 V, replace the ECM (page 5-100).

Viewed from harness side/  
 the 20P (Black) connector:



## LIGHTS/METER/SWITCHES

If the value is 0 V, disconnect the combination meter 20P (Black) connector and check for continuity between the combination meter 20P (Black) connector and ECM 33P (Light gray) connector Yellow/green terminals.


### TOOL:

Test probe

07ZAJ-RDJA110

If there is no continuity, check the wire harness for an open circuit.

If there is continuity, replace the ECM (page 5-100).




## ENGINE COOLANT TEMPERATURE INDICATOR/ECT SENSOR

### SYSTEM INSPECTION

Lift and support the fuel tank (page 3-5).


Disconnect the ECT sensor 3P (Black) connector from the sensor.

Ground the Green/blue wire terminal of the ECT sensor 3P (Black) connector wire harness side with a jumper wire.



Turn the ignition switch to "ON" and check the engine coolant temperature indicator.

- If the engine coolant temperature indicator light, inspect the ECT sensor (page 20-21).
- If the engine coolant temperature indicator do not light, check the following.
  - Open circuit in the ECT sensor (Green/blue) wire
  - Faulty combination meter





### ECT SENSOR INSPECTION

Remove the ECT sensor (page 5-96).


Suspend the ECT sensor in a pan of coolant (1:1 mixture) an electric heating element and measure the resistance between the sensor terminal and body as the coolant heats up.

- Soak the ECT sensor in coolant up to its threads with at least 40 mm (1.6 in) from the bottom of the pan to the bottom of the sensor.
- Keep the temperature constant for 3 minutes before testing. A sudden change of temperature will result in incorrect readings. Do not let the thermometer or ECT sensor touch the pan.

Replace the sensor if it is out of specification by more than 10% at any temperature listed.

Temperature	80°C (68°F)	120°C (248°F)
Resistance	2.1 – 2.6 kΩ	0.65 – 0.73 kΩ


Install the ECT sensor (page 5-96).




### ENGINE OIL PRESSURE INDICATOR/ EOP SWITCH

#### INSPECTION

If the engine oil pressure indicators stay on while the engine running, check the engine oil level before inspection (page 3-16).



Remove the rubber cap, and disconnect the EOP switch wire by removing the terminal bolt.



## LIGHTS/METER/SWITCHES

Short the EOP switch wire terminal with the ground using a jumper wire.


The oil pressure indicator comes on with the ignition switch is ON.

If the light does not come on, check the sub-fuse (10A) and wire for a loose connection or an open circuit.

Start the engine and make sure that the light goes out.

If the light does not go out, check the oil pressure (page 4-5).


If the oil pressure is normal, replace the EOP switch (page 4-5).



Connect the EOP switch wire to the EOP switch. Install and tighten the terminal bolt to the specified torque.

**TORQUE: 2.0 N·m (0.2 kgf·m, 1.5 lbf·ft)**


Install the rubber cap to the EOP switch securely.



### EOP SWITCH REMOVAL/ INSTALLATION


Remove the rubber cap, and disconnect the EOP switch wire by removing the terminal bolt.

Remove the EOP switch.



Clean and apply a sealant (Three Bond 1207B) to the EOP switch threads as shown.

Do not apply sealant to the thread head 3 – 4 mm (0.1 – 0.2 in)




Install and tighten the EOP switch to the specified torque.

**TORQUE: 12 N·m (1.2 kgf·m, 9 lbf·ft)**

Connect the EOP switch wire to the EOP switch. Install and tighten the terminal bolt to the specified torque.

**TORQUE: 2.0 N·m (0.2 kgf·m, 1.5 lbf·ft)**

Install the rubber cap to the EOP switch securely.




## FUEL LEVEL INDICATOR

### SYSTEM INSPECTION

#### OPEN CIRCUIT IN THE FUEL LEVEL SYSTEM

If the fuel level indicator indicates as shown, there are some open circuits in the fuel level indicator system. Check the open circuit as follows.




Open and support the fuel tank (page 3-5).

Jump the Gray/black and Green wire terminals of the fuel level sensor 2P (Natural) connector with harness side using a jumper wire.


Turn the ignition switch to "ON" and check the fuel level indicator.

- If the fuel level indicator still indicates as open circuit indication, check the following.
  - Open circuit in the Gray/black and Green wires between the combination meter and the fuel level sensor
  - Faulty combination meter circuit board (page 20-14)
- If the indicator indicates as "FULL", inspect the fuel level sensor.



### SHORT CIRCUIT IN THE FUEL LEVEL SYSTEM

If the fuel level indicator indicates the right illustration (full fuel level) in spite of an empty fuel level, check the related wires of the fuel level system for short circuit.




Open and support the fuel tank (page 3-5).

Disconnect the fuel level sensor 2P (Natural) connector.

Turn the ignition switch to "ON".

- If the fuel level indicator indicates as open circuit indication, inspect the fuel level sensor (page 20-25).
- If the indicator indicates as "FULL", check the following.
  - Short circuit in the Gray/black wire between the combination meter and the fuel level sensor
  - Faulty combination meter circuit board (page 20-14)




## FUEL LEVEL SENSOR

### REMOVAL/INSTALLATION

Remove the fuel tank (page 5-60).

*Be careful not to damage or bend the level sensor arm.*


Remove the nuts, fuel level sensor and O-ring.



Check the O-ring is in good condition and replace if necessary.

*Be careful not to damage or bend the level sensor arm.*

Install the fuel level sensor into the fuel tank. Installation is in the reverse order of removal.




**INSPECTION**

Check the fuel level sensor and arm for damage.

Measure the resistance at the fuel level sensor 2P (Natural) connector terminal with moving the float at the top "F" and bottom "E" position.

	TOP "F"	BOTTOM "E"
Resistance	8 - 12 Ω	182 - 188 Ω




**IGNITION SWITCH**

**INSPECTION**

Remove the headlight (page 20-6).

Release the ignition switch 2P (Blown) connector from the ignition switch.

Disconnect the ignition switch 2P (Brown) connector.




Check for continuity between the wire terminals of the ignition switch connector in each switch position.

Continuity should exist between the color coded wires as follows:

**IGNITION SWITCH:**

POSITION \ COLOR	R	R/BI
	ON	○ — ○
OFF		
LOCK		




## LIGHTS/METER/SWITCHES

### REMOVAL/INSTALLATION

Remove the headlight (page 20-6).

Release the immobilizer receiver 4P (Black) and ignition switch 2P (Brown) connectors from the ignition switch.

Disconnect the ignition switch 2P (Brown) connector.




Remove the mounting bolts and ignition switch.

Install the ignition switch to the top bridge. Tighten new ignition switch mounting bolts to the specified torque.

**TORQUE: 25 N·m (2.5 kgf·m, 18 lbf·ft)**

Install the removed parts in the reverse order of removal.




## HANDLEBAR SWITCHES

### RIGHT HANDLEBAR SWITCH


Remove the headlight (page 20-6).

Release the right handlebar switch 6P (Black) connector from the guide on the headlight stay, then disconnect the connector.



Check for continuity between the wire terminals of the right handlebar switch connector.

Continuity should exist between the terminals as follows:



**RIGHT HANDLEBAR SWITCH:**

ENGINE STOP SWITCH:

COLOR \ POSITION	BI	W/BI


STARTER SWITCH:

COLOR \ POSITION	BI	Y/R
FREE		
PUSH		

**LEFT HANDLEBAR SWITCH**

Remove the headlight (page 20-6).


Release the left handlebar switch 10P (Black) connector from the guide on the headlight stay, then disconnect the connector.



## LIGHTS/METER/SWITCHES

Check for continuity between the wire terminals of the left handlebar switch connector.

Continuity should exist between the terminals as follows:



### LEFT HANDLEBAR SWITCH:

#### DIMMER SWITCH:

COLOR POSITION	Bl/R	W	Bu
	○	○	
(N)	○	○	○
	○		○

#### TURN SIGNAL SWITCH:

COLOR POSITION	Gr	Lb	O
	○	○	○
N			
	○	○	

#### HAZARD SWITCH:

COLOR POSITION	Gr	Lb	O
OFF			
ON	○	○	○

#### PASSING SWITCH:

COLOR POSITION	Bl/R	Bu
FREE		
PUSH	○	○

#### HORN SWITCH:


COLOR POSITION	Bl/Gr	W/G
FREE		
PUSH	○	○

## BRAKE LIGHT SWITCH

### FRONT

Disconnect the front brake light switch connectors and check for continuity between the terminals.

There should be continuity with the brake lever applied, and there should be no continuity with the brake lever is released.






**REAR**

Remove the seat (page 2-4).

Disconnect the rear brake light switch 2P (Black) connector and check for continuity between the terminals.

There should be continuity with the brake pedal applied, and there should be no continuity with the brake pedal is released.

CB1000RA shown: 2P (Black) CONNECTOR




**CLUTCH SWITCH**

**INSPECTION**

Disconnect the clutch switch connectors and check for continuity between the terminals.

There should be continuity with the clutch lever applied, and there should be no continuity with the clutch lever is released.

CLUTCH SWITCH



**REMOVAL/INSTALLATION**

Disconnect the clutch switch connectors from the clutch switch terminals.


Remove the screw and clutch switch from the clutch master cylinder.

Install the clutch switch to the clutch master cylinder aligning the its tab with the hole in the clutch master cylinder.

Install and tighten the screw to the specified torque.

**TORQUE: 1.2 N·m (0.1 kgf·m, 0.9 lbf·ft)**

Connect the clutch switch connectors to the clutch switch terminals.



## NEUTRAL SWITCH

### INSPECTION


Remove the engine (page 7-4).

Remove the dust cover, terminal nut and disconnect the neutral switch terminal eyelet from the neutral switch.

Shift the transmission into neutral and check for continuity between the neutral switch terminal and ground.

There should be continuity with the transmission is in neutral, and no continuity when the transmission is into gear.

Install the engine (page 7-8).



### REMOVAL/INSTALLATION

Remove the engine (page 7-4).

Remove the dust cover and terminal nut, then disconnect the neutral switch terminal eyelet from the switch.


Remove the neutral switch and sealing washer.

Install the neutral switch with a new sealing washer. Tighten the neutral switch to the specified torque.

**TORQUE: 12 N·m (1.2 kgf·m, 9 lbf·ft)**

Connect the neutral switch connector to the switch.

Install the engine (page 7-8).




## SIDESTAND SWITCH

### INSPECTION


Remove the left side cover (page 2-5).

Remove the air cleaner duct cover (page 3-7).

Disconnect the sidestand switch 2P (Black) connector.




Check for continuity between the wire terminals of the sidestand switch 2P (Black) connector. Continuity should exist only when the sidestand is retracted.




**REMOVAL/INSTALLATION**


Remove the left side cover (page 2-5).  
 Remove the air cleaner duct cover (page 3-7).  
 Disconnect the sidestand switch 2P (Black) connector.



Remove the bolt and sidestand switch.



Install the sidestand switch by aligning the switch pin with the sidestand hole and the switch groove with the holding pin. Secure the sidestand switch with a new bolt.



*Route the sidestand wire properly (page 1-22).*

Install the removed parts in the reverse order of removal.

**TORQUE:**


Sidestand switch bolt 10 N·m (1.0 kgf·m, 7 lbf·ft)

## HORN

### INSPECTION

Disconnect the wire connectors from the horn.

Connect the 12V battery to the horn terminal directly and check the horn sound.




### REMOVAL/INSTALLATION

Disconnect the wire connectors from the horn.

Remove the bolt and horn.

Installation is in the reverse order of removal.



## TURN SIGNAL RELAY

### INSPECTION

#### 1. Related Circuit Inspection

Check the following:

- burned or non-specified wattage bulb
- blown fuse
- ignition switch and turn signal light switch function
- loose connectors

Check for the above items.

**Are the above items in good condition?**

**YES** - GO TO STEP 2.

**NO** - Replace or repair the malfunction part(s)

#### 2. Turn Signal Circuit Inspection

Remove the seat (page 2-4).

Disconnect the turn signal relay 4P (Natural) connector and short the Gray and White/green terminals of the wire harness side connector with a jumper wire.

Turn the ignition switch ON and check the turn signal lights by turning the turn signal switch on.

**Does the light come on?**

**YES** - GO TO STEP 3.

**NO** - Open circuit in related wires

#### 3. Ground Line Inspection


Check the continuity between the 4P (Natural) connector Green terminal and ground.

**Is there continuity?**

**YES** -

- Faulty turn signal relay
- Loose or poor contact of the connector terminals

**NO** - Open circuit in Green wire



---

**MEMO**

# 21. IMMOBILIZER SYSTEM (HISS)



---

SYSTEM DIAGRAM.....	21-2	TROUBLESHOOTING.....	21-9
SERVICE INFORMATION .....	21-3	IMMOBILIZER INDICATOR .....	21-12
KEY REGISTRATION PROCEDURES .....	21-4	ECM.....	21-13
HISS DIAGNOSTIC INFORMATION .....	21-7	IMMOBILIZER RECEIVER.....	21-14

# IMMOBILIZER SYSTEM (HISS)

## SYSTEM DIAGRAM

CB1000RA shown:








## SERVICE INFORMATION

### GENERAL

- HISS is the abbreviation of Honda Ignition Security System.
- When checking the immobilizer system (HISS), follow the steps in the troubleshooting (page 21-9).
- Keep the immobilizer key away from the other vehicle's immobilizer key when using it. The jamming of the key code signal may occur and the proper operation of the system will be obstructed.
- The key has built-in electronic part (transponder). Do not drop and strike the key against a hard material object, and do not leave the key on the dashboard in the car, etc. where the temperature will rise. Do not leave the key in the water for a prolonged time such as by washing the clothes.
- The ECM as well as the transponder keys must be replaced if all transponder keys have been lost.
- The system does not function with a duplicated key unless the code is registered into the transponder with the immobilizer system (HISS).
- The ECM can store up to four key codes. (The four keys can be registered.)
- Do not modify the immobilizer system as it can cause the system failure. (The engine cannot be started.)
- For ignition system inspection (page 18-5).
- For ignition switch servicing (page 20-25).


### TOOLS

<p>Inspection harness 07XMZ-MBW0101</p> 	<p>Test harness adaptor 070MZ-MEC0101</p> 	<p>Test probe 07ZAJ-RDJA110</p> 
--	---	--

# KEY REGISTRATION PROCEDURES

### When the key has been lost, or additional spare key is required:


1. Obtain a new transponder key.
2. Grind the key in accordance with the shape of the original key.
3. Apply 12 V battery voltage to the CKP sensor lines of the ECM using the special tool (page 21-7).
4. Turn the ignition switch to "ON" with the original key. The immobilizer indicator comes on and it remains on.
  - The code of the original key recognized by the ECM.
  - If there is any problem in the immobilizer system (HISS), the system will enter the diagnostic mode and the indicator will remain on for approx. ten seconds, then it will indicate the diagnostic code (page 21-7).
5. Disconnect the red clip of the inspection adaptor from the battery positive (+) terminal for two seconds or more, then connect it again. The indicator remains on for approx. two seconds, then it blinks four times repeatedly.



- The immobilizer system (HISS) enters the registration mode. Registrations of all key except the original key inserted in the ignition switch are cancelled. (Registration of the lost key or spare key is cancelled.)

#### NOTE:

- The spare key must be registered again.
6. Turn the ignition switch to "OFF" and remove the key.
  7. Turn the ignition switch to "ON" with a new key or the spare key. (Never use the key registered in previous steps.) The indicator comes on for two seconds then it blinks four times repeatedly.



- The new key or spare key is registered in the ECM.
- If there is any problem in the registration, the system will enter the diagnostic mode and the indicator will remain for approx. ten seconds, then it will indicate the diagnostic code (page 21-8).

#### NOTE:

- Keep the other transponder key away from the immobilizer receiver more than 50 mm (2.0 in).


8. Repeat the steps 6 and 7 when you continuously register an other new key.

#### NOTE:


- The ECM can store up to four key codes. (The four keys can be registered.)
9. Turn the ignition switch to "OFF", remove the inspection adaptor and connect the CKP sensor 2P (Red) connector.
  10. Turn the ignition switch to "ON" with the registered key.
    - The immobilizer system (HISS) returns to the normal mode.
  11. Check that the engine can be started using all registered key.

**When the ignition switch is faulty (ignition switch replacement):**

1. Obtain a new ignition switch and two new transponder keys.
2. Remove the ignition switch (page 20-25).
3. Apply 12 V battery voltage to the CKP sensor lines of the ECM using the special tool (page 21-7).
4. Set the original (registered) key near the immobilizer receiver so that the transponder in the key can communicate with the receiver.
5. Connect a new ignition switch to the wire harness. Turn the ignition switch to "ON" with a new transponder key. (keep the ignition switch away from the receiver.) The immobilizer indicator comes on and it remains on.
  - The code of the original key recognized by the ECM.
  - If there is any problem in the immobilizer system (HISS), the system will enter the diagnostic mode and the indicator will remain on for approx. ten seconds, then it will indicate the diagnostic code (page 21-7).
6. Disconnect the red clip of the inspection adaptor from the battery positive (+) terminal for two seconds or more, then connect it again. The indicator remains on for approx. two seconds then it blinks four times repeatedly.



- The immobilizer system (HISS) enters the registration mode. Registrations of all key except the original key set near the receiver are cancelled.
7. Turn the ignition switch to "OFF" and remove the key.
  8. Install the ignition switch (page 20-25).
  9. Turn the ignition switch to "ON" with a first new key. The indicator comes on for two seconds then it blinks four times repeatedly.



- The first key is registered in the ECM.
  - If there is any problem in the registration, the system will enter the diagnostic mode and the indicator will remain for approx. ten seconds, then it will indicate the diagnostic code (page 21-8).
10. Turn the ignition switch to "OFF" and disconnect the red clip of the inspection adaptor from the battery positive (+) terminal.
  11. Turn the ignition switch to "ON" (with the first key registered in step 9). The immobilizer indicator comes on for two seconds then it goes off.
    - The immobilizer system (HISS) returns to the normal mode.
  12. Turn the ignition switch to "OFF" and connect the red clip of the inspection adaptor to the battery positive (+) terminal.
  13. Turn the ignition switch to "ON" (with the first key registered in step 9). The immobilizer indicator comes on and it remains on.
    - The code of the first key is recognized by the ECM.
    - If there is any problem in the immobilizer system (HISS), the system will enter the diagnostic mode and the indicator will remain on for approx. ten seconds, then it will indicate the diagnostic code (page 21-7).
  14. Disconnect the red clip of the inspection adaptor from the battery positive (+) terminal for two seconds or more, then connect it again. The indicator remains on for approx. two seconds then it blinks four times repeatedly.
    - The immobilizer system (HISS) enters the registration mode. Registration of the original key used in step 4 is cancelled.
  15. Turn the ignition switch to "OFF" and remove the key.

## IMMOBILIZER SYSTEM (HISS)

16. Turn the ignition switch to "ON" with a second new key. (Never use the key registered in step 9.) The indicator comes on for two seconds then it blinks four times repeatedly.

- The second key is registered in the ECM.
- If there is any problem in the registration, the system will enter the diagnostic mode and the indicator will remain for approx. ten seconds, then it will indicate the diagnostic code (page 21-8).

### NOTE:

- Keep the other transponder key away from the immobilizer receiver more than 50 mm (2.0 in).

17. Repeat the steps 15 and 16 when you continuously register the other new key.

### NOTE:

- The ECM can store up to four key codes. (The four keys can be registered.)

18. Turn the ignition switch to "OFF", remove the inspection adaptor and connect the CKP sensor 2P (Red) connector.


19. Turn the ignition switch to "ON" with the registered key.

- The immobilizer system (HISS) returns to the normal mode.

20. Check that the engine can be started using all registered keys.

### When all keys have been lost, or the ECM is faulty:

1. Obtain a new ECM and two new transponder keys.
2. Grind the keys in accordance with the shape of the original key (or use the key number plate when all keys have been lost).
3. Replace the ECM with a new one (page 5-100).
4. Turn the ignition switch to "ON" with a first new key. The immobilizer indicator comes on for two seconds, then it blinks four times repeatedly.



- The first key is registered in the ECM.
  - If there is any problem in the registration, the system will enter the diagnostic mode and the indicator will remain for approx. ten seconds, then it will indicate the diagnostic code (page 21-8).
5. Turn the ignition switch to "OFF" and remove the first key.
  6. Turn the ignition switch to "ON" with a second new key. The immobilizer indicator comes on for two seconds, then it blinks four times repeatedly.
    - The second key is registered in the ECM.
    - If there is any problem in the registration, the system will enter the diagnostic mode and the indicator will remain for approx. ten seconds, then it will indicate the diagnostic code (page 21-8).
  7. Turn the ignition switch to "OFF" and remove the second key.
    - The system (ECM) will not enter the normal mode unless the two keys are registered in ECM.
    - The third new key cannot be continuously registered. When it is necessary to register the third key, follow the procedures "When the key has been lost, or additional key is required" (page 21-4).
  8. Check that the engine can be started using all registered keys.

# HISS DIAGNOSTIC INFORMATION

Remove the right side cover (page 2-5).

Disconnect the CKP sensor 2P (Red) connector.


Connect the inspection harness and test harness adaptor to the wire harness side connector.

**TOOLS:**

**Inspection harness** 07XMZ-MBW0101

**Test harness adaptor** 070MZ-MEC0101

Connect the Red clip of the adaptor to the 12 V battery positive (+) terminal and green clip to the negative (-) terminal.




Turn the ignition switch to "ON" with the properly registered key.

The immobilizer indicator will come on for approx. ten seconds then it will start blinking to indicate the diagnostic code if the system is abnormal.

The blinking frequency is repeated.

**NOTE:**

- The immobilizer indicator remains on when the system is normal. (The system is in the normal mode and the diagnostic code does not appear.)






## HISS DIAGNOSTIC CODE

When the system (ECM) enters the diagnostic mode from the normal mode:

BLINKING PATTERN	SYMPTOM	PROBLEM	PROCEDURE
	ECM data is abnormal.	Faulty ECM	Replace the ECM.
	Code signals cannot send or receive.	Faulty immobilizer receiver or wire harness	Follow the troubleshooting (page 21-9).
	Identification code is disagree.	Jamming by the other transponder	Keep the other vehicle's transponder key away from the immobilizer receiver more than 50 mm (2.0 in).
	Secret code is disagree.		

# IMMOBILIZER SYSTEM (HISS)

When the system (ECM) enters the diagnostic mode from the registration mode:

BLINKING PATTERN	SYMPTOM	PROBLEM	PROCEDURE
 <p>ON ..... OFF ..... 10 sec.</p>	Registration is overlapped.	The key is already registered properly.	Use a new key or cancelled key.
	Code signals cannot send or receive.	Communication fails.	Follow the troubleshooting (page 21-9).
	Registration is impossible.	The key is already registered on the other system.	Use a new key.

## TROUBLESHOOTING

The immobilizer indicator comes on for approx. two seconds then it goes off, when the ignition switch is turned to "ON" with the properly registered key and the immobilizer system (HISS) functions normally. If there is any problem or the properly registered key is not used, the indicator will remain on.

**Immobilizer indicator does not come on when the ignition switch is turned to "ON"**

### 1. Fuse Inspection

Check the sub-fuse (10 A).

*Is the fuse blown?*

**YES** – Replace the fuse.

**NO** – GO TO STEP 2.

### 2. Combination Meter Inspection

Check that the neutral indicator comes on with the ignition switch ON.

*Does the indicator come on?*

**YES** – GO TO STEP 4.

**NO** – GO TO STEP 3.

### 3. Combination Meter Power Input line Inspection

Check the power input line (Black/brown wire) at the combination meter connector (page 21-12).

*Is the voltage specified value?*

**YES** – Faulty combination meter

**NO** – • Open circuit in Black/brown wire  
• Open circuit in Green/black wire

### 4. Immobilizer Indicator Line Inspection At The ECM Connector

Check the immobilizer indicator line (White/red wire) at the ECM connector (page 21-13).

*Is the voltage specified value?*

**YES** – GO TO STEP 6.

**NO** – GO TO STEP 5.

### 5. Immobilizer Indicator Line Inspection At The Combination Meter Connector

Check the immobilizer indicator line (White/red wire) at the combination meter connector (page 21-12).

*Is the voltage specified value?*

**YES** – Faulty combination meter

**NO** – Open circuit in White/red wire

### 6. Power Input Line Inspection At The ECM Connector

Check the power input line (Black/white wire) at the ECM connector (page 21-13).

*Is the voltage specified value?*

**YES** – GO TO STEP 7.

**NO** – • Open circuit in Black/white wire  
• Faulty engine stop relay  
• Blown FI fuse (20 A)  
• Open circuit in Red/yellow or Red/white wire between the battery and engine stop relay

### 7. Ground Line Inspection At The ECM Connector

Check the ground lines (Green and Green/white wires) at the ECM connector (page 21-14).

*Is there continuity?*

**YES** – • Loose or poor ECM connector contact  
• Faulty ECM

**NO** – Open circuit in Green or Green/white wire

## IMMOBILIZER SYSTEM (HISS)

---

Immobilizer indicator remains on with the ignition switch to "ON"

### 1. Immobilizer Receiver Jamming Inspection

Check that there is any metal obstruction or the other vehicle's transponder key near the immobilizer receiver and key.

**Is there any metal obstruction or the other transponder key?**

**YES** – Remove it and recheck.

**NO** – GO TO STEP 2.

### 2. First Transponder Key Inspection

Turn the ignition switch to "ON" with the spare transponder key and check the immobilizer indicator. The indicator should come on for 2 seconds then go off.

**Is there indicator go off?**

**YES** – Faulty first transponder key

**NO** – GO TO STEP 3.

### 3. Diagnostic Code Inspection

Perform the diagnostic code indication procedure (page 21-7) and check that the immobilizer indicator comes on then it starts blinking.

**Is there indicator Blinks or Stay Lit?**

**BLINKS**—Read the diagnostic code (page 21-7).

**STAY LIT**—GO TO STEP 4.

### 4. Immobilizer Indicator Line Inspection At The ECM Connector

Check the immobilizer indicator line (White/red wire) at the ECM connector (page 21-13).

**Is the voltage specified?**

**YES** – GO TO STEP 5.

**NO** – Short circuit in the White/red wire.

### 5. CKP Sensor Line Inspection

Check the CKP sensor lines (Yellow and White/yellow wires) between the ECM and CKP sensor connectors (page 21-14).

**Is there continuity?**

**YES** – Faulty the ECM.

**NO** –

- Open circuit in the Yellow wire.
- Open circuit in the White/yellow wire



Diagnostic code  is indicated (Code signals cannot send or receive)

### 1. Immobilizer Receiver Power Input Line Inspection

Check the power input line (Yellow/red) at the immobilizer receiver connector (page 21-14).

**Is there approx. 5 V?**

**YES** – GO TO STEP 2.

**NO** – Open or short circuit in the Yellow/red wire.

### 2. Immobilizer Receiver Ground Line Inspection

Check the ground line (Green/orange) at the immobilizer receiver connector (page 21-15).

**Is there continuity?**

**YES** – GO TO STEP 3.

**NO** – Open circuit in the Green/orange wire.

### 3. Immobilizer Receiver Signal Line Inspection

Check the signal lines (Pink and Yellow/blue) between the immobilizer receiver and ECM connectors (page 21-15).

**Are the wires normal?**

**YES** – Faulty the immobilizer receiver.

**NO** –


- Open or short circuit in Pink wire.
- Open or short circuit in Yellow/blue wire.

## IMMOBILIZER SYSTEM (HISS)

### IMMOBILIZER INDICATOR


Remove the meter visor (page 2-8).

Perform the following inspections with the combination meter 20P (Black) connector connected.



#### POWER INPUT LINE INSPECTION

Measure the voltage between the Black/brown (+) and Green/black (-) wire terminals. There should be battery voltage when the ignition switch is turned to "ON".




#### IMMOBILIZER INDICATOR LINE INSPECTION

Measure the voltage between the White/red wire terminal (+) and ground (-).

There should be battery voltage when the ignition switch is turned to "ON".

**NOTE:**

- There should be no voltage for approx. two seconds after the ignition switch is turned to "ON", then the battery voltage should appear, if the system is normal.



**ECM**

Open and support the fuel tank (page 3-5).  
Pull out the ECM from the stay (page 5-100).


Disconnect the ECM 33P (Black and Light gray) connectors.

Perform the following inspections at the wire harness side connector.

**TOOL:**

Test probe

07ZAJ-RDJA110



**IMMOBILIZER INDICATOR LINE INSPECTION**


Measure the voltage between the B12 (White/red) wire terminal (+) and ground (-).

There should be battery voltage when the ignition switch is turned to "ON".

**TOOL:**

Test probe

07ZAJ-RDJA110



**POWER INPUT LINE INSPECTION**


Measure the voltage between the A4 (Black/white) wire terminal (+) and ground (-).

There should be battery voltage when the ignition switch is turned to "ON".

**TOOL:**

Test probe

07ZAJ-RDJA110



# IMMOBILIZER SYSTEM (HISS)


## GROUND LINE INSPECTION

Check the continuity between the B4 (Green) wire terminal and ground.  
Also check the continuity between the A23 and A24 (Green/white) wire terminals and ground.  
There should be continuity at all times.

**TOOL:**

Test probe

07ZAJ-RDJA110



## CKP SENSOR LINE INSPECTION


Disconnect the CKP sensor 2P (Red) connector.  
Check the Yellow wire for continuity between the ECM and CKP sensor connectors.  
Also check the White/yellow wire for continuity between the ECM and CKP sensor connectors.

**TOOL:**

Test probe

07ZAJ-RDJA110

There should be continuity between the same color wire terminals.




# IMMOBILIZER RECEIVER

Remove the headlight (page 20-6).

Release the immobilizer receiver 4P (Black) connector from the ignition switch.


Disconnect the immobilizer receiver 4P (Black) connector.

Perform the following inspections at the wire harness side connector.




## POWER INPUT LINE INSPECTION

Measure the voltage between the Yellow/red wire terminal (+) and ground (-).  
There should be approx. 5 V when the ignition switch is turned to "ON".




**GROUND LINE INSPECTION**

Check for continuity between the Green/orange wire terminal and ground.  
There should be continuity at all times.



**SIGNAL LINE INSPECTION**

Measure the voltage between the Pink wire terminal (+) and ground (-).  
There should be approx. 5 V when the ignition switch is turned to "ON".




Disconnect the ECM 33P (Light gray) connector (page 21-13).  
Check the Yellow/blue wire for continuity between the immobilizer receiver and ECM connectors.

**TOOL:**

**Test probe** 07ZAJ-RDJA110

There should be continuity.


Check for continuity between the Yellow/blue wire terminal and ground.  
There should be no continuity.



**REPLACEMENT**

Remove the headlight (page 20-6).

Release the immobilizer receiver 4P (Black) connector from the ignition switch.  
Disconnect the immobilizer receiver 4P (Black) connector.




## IMMOBILIZER SYSTEM (HISS)

Remove the screws and the immobilizer receiver.

Install a new receiver and tighten the screws securely.

*Route the receiver wire properly (page 1-22).*

Install the removed parts in the reverse order of removal.



### REQUIRED PARTS FOR PROBLEM

Problem	Replacement parts				
	Transponder Key	Immobilizer receiver	ECM	Ignition switch	*Accessory lock and key
One key has been lost, or additional spare key is required	○				
All key have been lost, or ECM is faulty	○		○		
Immobilizer receiver is faulty		○			
Ignition switch is faulty	○			○	
*Accessory lock is faulty					○

\*Accessory lock means the seat lock and fuel fill cap.

# 22. WIRING DIAGRAMS

---


CB1000R ..... 22-3


CB1000RA ..... 22-4






CB1000R





- FUSE BOX
- A 10A HEADLIGHT · PASSING
  - B 10A METER · INDICATOR · TAIL · (POSITION) · LICENSE · HORN
  - C 10A FRONT · REAR BRAKE · HORN · TURN SIGNAL RELAY
  - D 10A STARTER · BANK ANGLE SENSOR
  - E 20A FAN MOTOR
  - F 10A ABS MAIN
  - G 10A TURN SIGNAL · CLOCK · ODOMETER
  - H 30A ABS FAIL SAFE RELAY
  - I 30A ABS MOTOR



- BI BLACK
- Y YELLOW
- Bu BLUE
- G GREEN
- R RED
- W WHITE
- Br BROWN
- O ORANGE
- Lb LIGHT BLUE
- P PINK
- Gr GRAY

# 23. TROUBLESHOOTING

---

ENGINE DOES NOT START OR IS  
HARD TO START ..... 23-2

ENGINE LACKS POWER ..... 23-3

POOR PERFORMANCE AT LOW AND  
IDLE SPEED ..... 23-5

POOR PERFORMANCE AT  
HIGH SPEED ..... 23-6

POOR HANDLING ..... 23-6

# ENGINE DOES NOT START OR IS HARD TO START

### 1. Spark Plug Inspection

Remove and inspect spark plugs.

***Are the spark plugs in good condition?***

**YES** – GO TO STEP 2.

**NO** –

- Incorrect spark plug heat range
- Incorrect spark plug gap
- Dirty air cleaner

### 2. Spark Test

Perform spark test.

***Are there good sparks?***

**YES** – GO TO STEP 3.

**NO** –

- Loose or disconnected ignition system wires
- Faulty ignition coil
- Broken or shorted spark plug wire
- Faulty CKP sensor
- Faulty engine stop switch
- Faulty ignition switch
- Faulty ECM

### 3. Fuel Pump Inspection

Check for operation of the fuel pump and inspect the fuel flow.

***Is the fuel pump unit normal?***

**YES** – GO TO STEP 4.

**NO** – Faulty fuel pump unit (page 5-57).

### 4. PGM-FI System Inspection

Check the PGM-FI system.

***Is the PGM-FI system normal?***

**YES** – GO TO STEP 5.

**NO** – Faulty PGM-FI system (page 5-12).

### 5. Cylinder compression Inspection

Test the cylinder compression (page 8-6).

***Is the compression as specified?***

**YES** – GO TO STEP 6.

**NO** –

- Improper valve clearance
- Valve stuck open
- Worn cylinder and piston rings
- Damaged cylinder head gasket
- Seized valve
- Improper valve timing

### 6. Engine Start Condition

Start by following normal procedure.

***Did the engine start but stops?***

**Yes** –

- Leaking insulators or air cleaner housing
- Faulty starter valves
- Improper ignition timing (Faulty ECM or CKP sensor)
- Contaminated fuel

---

## ENGINE LACKS POWER

### 1. Drive Train Inspection

Raise wheel off the ground and spin by hand.

*Did the wheel spin freely?*

**YES** – GO TO STEP 2.

**NO** – • Brake dragging  
• Worn or damaged wheel bearings

### 2. Tire Pressure Inspection

Check the tire pressure.

*Are the tire pressures correct?*

**YES** – GO TO STEP 3.

**NO** – • Faulty tire valve  
• Punctured tire

### 3. Clutch Inspection

Accelerate rapidly, shift from first to second.

*Did the engine speed change accordingly when clutch is released?*

**YES** – GO TO STEP 4.

**NO** – • Clutch slipping  
• Worn clutch discs/plates  
• Warped clutch discs/plates  
• Weak clutch spring  
• Additive in engine oil

### 4. Engine Performance Inspection

Accelerate lightly.

*Did the Engine speed increase?*

**YES** – GO TO STEP 5.

**NO** – • Dirty air cleaner  
• Restricted fuel flow  
• Clogged muffler

### 5. Spark Plug Inspection

Remove and inspect spark plugs.

*Are the spark plugs in good condition?*

**YES** – GO TO STEP 6.

**NO** – • Plugs not serviced frequently enough  
• Incorrect spark plug heat range  
• Incorrect spark plug gap

### 6. Engine Oil Inspection

Check the oil level and condition.

*Is the engine oil good condition?*

**YES** – GO TO STEP 7.

**NO** – • Oil level too high  
• Oil level too low  
• Contaminated oil

### 7. Ignition Timing Inspection

Check the ignition timing.

*Is the ignition timing as specified?*

**YES** – GO TO STEP 8.

**NO** – • Faulty ECM  
• Faulty CKP sensor  
• Improper valve timing

### 8. Cylinder compression Inspection

Test the cylinder compression (page 8-6).

**Is the compression as specified?**

**YES** – GO TO STEP 9.

**NO** –

- Valve clearance too small
- Worn cylinder and piston rings
- Damaged cylinder head gasket
- Improper valve timing

### 9. Fuel Pump Inspection

Inspect the fuel flow.

**Is the fuel pump unit normal?**

**YES** – GO TO STEP 10.

**NO** – Faulty fuel pump unit (page 5-57).

### 10. PGM-FI System Inspection

Check the PGM-FI system.

**Is the PGM-FI system normal?**

**YES** – GO TO STEP 11.

**NO** – Faulty PGM-FI system (page 5-12).

### 11. Lubrication Inspection

Remove cylinder head cover and inspect lubrication.

**Is the Valve train lubricated properly?**

**YES** – GO TO STEP 12.

**NO** –

- Faulty oil pump
- Faulty pressure relief valve
- Clogged oil strainer
- Clogged oil passage

### 12. Over Heating Inspection

Check for engine over heating.

**Is the engine over heating?**

**YES** –

- Coolant level too low
- Fan motor not working
- Thermostat stuck closed
- Excessive carbon build-up in combustion chamber
- Use of poor quality fuel
- Wrong type of fuel
- Clutch slipping

**NO** – GO TO STEP 13.

### 13. Engine Knocking Inspection

Accelerate or run at high speed.

**Is the engine knocking?**

**YES** –

- Worn piston and cylinder
- Wrong type of fuel
- Thermostat stuck closed
- Excessive carbon build-up in combustion chamber
- Ignition timing too advance (Faulty ECM)
- Faulty CKP sensor

**NO** –

- Engine does not knock

---

**POOR PERFORMANCE AT LOW AND IDLE SPEED****1. Spark Plug Inspection**

Remove and inspect spark plugs.

***Are the spark plugs in good condition?***

**YES** – GO TO STEP 2.

**NO** –

- Plugs not serviced frequently enough
- Incorrect spark plug heat range
- Incorrect spark plug gap

**2. Ignition Timing Inspection**

Check the ignition timing.

***Is the ignition timing as specified?***

**YES** – GO TO STEP 3.

**NO** –

- Faulty ECM
- Faulty CKP sensor
- Faulty VS sensor
- Improper valve timing

**3. Fuel Pump Inspection**

Inspect the fuel flow.

***Is the fuel pump unit normal?***

**YES** – GO TO STEP 4.

**NO** – Faulty fuel pump unit (page 5-57).

**4. PGM-FI System Inspection**

Check the PGM-FI system.

***Is the PGM-FI system normal?***

**YES** – GO TO STEP 5.

**NO** – Faulty PGM-FI system (page 5-12).

**5. IACV Inspection**

Check the IACV operation (page 5-94).

***Does the IACV operate normally?***

**YES** – GO TO STEP 6.

**NO** – Faulty IACV.

**6. Intake Pipes Leaking Inspection**

Check for leaks at the insulators or air cleaner housing.

***Are there leaks?***

**YES** –

- Loose insulator
- Damaged insulator
- Damaged air cleaner housing

### POOR PERFORMANCE AT HIGH SPEED

#### 1. Ignition Timing Inspection

Check the ignition timing.

*Is the ignition timing as specified?*

**YES** – GO TO STEP 2.

**NO** –

- Faulty ECM
- Faulty CKP sensor
- Faulty VS sensor
- Improper valve timing

#### 2. Fuel Pump Inspection

Inspect the fuel flow.

*Is the fuel pump unit operation normal?*

**YES** – GO TO STEP 3.

**NO** – Faulty fuel pump unit (page 5-57).

#### 3. PGM-FI System Inspection

Check the PGM-FI system.

*Is the PGM-FI system normally?*

**YES** – GO TO STEP 4.

**NO** – Faulty PGM-FI system (page 5-12).

#### 4. Valve Timing Inspection

Check the valve timing (page 8-27).

*Is the valve timing correct?*

**YES** – GO TO STEP 5.

**NO** – Camshafts not installed properly

#### 5. Valve Spring Inspection

Check the valve springs.

*Is the valve spring free length as specified?*

**YES** – Not weak

**NO** – Faulty valve springs

### POOR HANDLING

#### Steering is heavy

- Steering stem adjusting nut too tight
- Damaged steering head bearings
- Insufficient tire pressure

#### Either wheel is wobbling

- Excessive wheel bearing play
- Bent rim
- Swingarm pivot bearing excessively worn
- Bent frame

#### The motorcycle pulls to one side

- Front and rear wheel not aligned
- Faulty shock absorber
- Bent fork
- Bent swingarm
- Bent axle
- Bent frame



ABS CONNECTOR LOCATIONS (CB1000RA).....	16-5	CRANKCASE/CRANKSHAFT/BALANCER/ PISTON/CYLINDER SPECIFICATIONS .....	1-8
ABS INDICATOR CIRCUIT TROUBLESHOOTING (CB1000RA) .....	16-20	CRANKPIN BEARING .....	12-14
ABS MODULATOR/PCV (CB1000RA) .....	16-25	CRANKSHAFT .....	12-8
ABS PROBLEM CODE INDEX (CB1000RA) .....	16-9	CYLINDER COMPRESSION TEST .....	8-6
ABS SYSTEM DIAGRAM .....	16-3	CYLINDER HEAD ASSEMBLY .....	8-21
ABS SYSTEM LOCATION .....	16-2	CYLINDER HEAD COVER ASSEMBLY .....	8-30
ABS TROUBLESHOOTING (CB1000RA) .....	16-10	CYLINDER HEAD COVER DISASSEMBLY .....	8-7
ABS TROUBLESHOOTING INFORMATION (CB1000RA) .....	16-6	CYLINDER HEAD COVER INSTALLATION .....	8-31
AIR CLEANER .....	3-7	CYLINDER HEAD COVER REMOVAL .....	8-6
AIR CLEANER HOUSING .....	5-62	CYLINDER HEAD DISASSEMBLY .....	8-13
ALTERNATOR CHARGING COIL .....	17-7	CYLINDER HEAD INSPECTION .....	8-14
ALTERNATOR COVER .....	10-4	CYLINDER HEAD INSTALLATION .....	8-23
BALANCER .....	12-31	CYLINDER HEAD REMOVAL .....	8-12
BANK ANGLE SENSOR .....	5-97	CYLINDER HEAD/VALVES SPECIFICATIONS .....	1-7
BATTERY .....	17-6	DELAY VALVE (CB1000RA) .....	16-30
BATTERY/CHARGING SYSTEM SPECIFICATIONS .....	1-10	DIODE .....	19-14
BEARING HOLDER .....	14-9	DRIVE CHAIN .....	3-21
BODY PANEL LOCATIONS .....	2-2	DRIVE CHAIN SLIDER .....	3-26
BRAKE FLUID .....	3-27	DRIVEN FLANGE .....	14-12
BRAKE FLUID REPLACEMENT/AIR BLEEDING (CB1000R) .....	15-7	DTC INDEX .....	5-17
BRAKE FLUID REPLACEMENT/AIR BLEEDING (CB1000RA) .....	15-10	DTC TROUBLESHOOTING .....	5-18
BRAKE LIGHT SWITCH LIGHTS/METER/SWITCHES .....	20-28	ECM IMMOBILIZER SYSTEM (HISS) .....	21-13
MAINTENANCE .....	3-30	ECT SENSOR .....	5-96
BRAKE PAD WEAR .....	3-28	ELECTRIC STARTER SPECIFICATION .....	1-11
BRAKE PAD/DISC .....	15-17	EMISSION CONTROL SYSTEMS .....	1-41
BRAKE SYSTEM .....	3-29	ENGINE & FRAME TORQUE VALUES .....	1-12
BRAKE/TAILLIGHT .....	20-12	ENGINE CONTROL MODULE (ECM) FUEL SYSTEM (PGM-FI) .....	5-100
CABLE & HARNESS ROUTING .....	1-22	ENGINE COOLANT TEMPERATURE INDICATOR/ ECT SENSOR .....	20-20
CAMSHAFT INSTALLATION .....	8-25	ENGINE IDLE SPEED .....	5-93
CAMSHAFT REMOVAL .....	8-8	ENGINE INSTALLATION .....	7-8
CHARGING SYSTEM INSPECTION .....	17-6	ENGINE OIL PRESSURE INDICATOR/ EOP SWITCH .....	20-21
CKP SENSOR .....	18-7	ENGINE OIL/OIL FILTER .....	3-16
CLUTCH .....	9-18	ENGINE REMOVAL .....	7-4
CLUTCH FLUID .....	3-31	ENGINE STOP RELAY .....	5-99
CLUTCH FLUID DRAINING .....	9-6	EXHAUST SYSTEM .....	2-19
CLUTCH FLUID FILLING/BLEEDING .....	9-6	FAN CONTROL RELAY .....	6-20
CLUTCH FLUID REPLACEMENT/AIR BLEEDING .....	9-6	FLYWHEEL .....	10-8
CLUTCH MASTER CYLINDER .....	9-8	FORK .....	13-23
CLUTCH SLAVE CYLINDER .....	9-14	FRONT BRAKE CALIPER (CB1000R) .....	15-37
CLUTCH SWITCH .....	20-29	FRONT BRAKE CALIPER (CB1000RA) .....	15-41
CLUTCH SYSTEM .....	3-30	FRONT FENDER .....	2-13
CLUTCH/STARTER CLUTCH SPECIFICATIONS .....	1-7	FRONT MASTER CYLINDER .....	15-22
COMBINATION METER .....	20-13	FRONT WHEEL .....	13-16
COMPONENT LOCATION ALTERNATOR .....	10-2	FRONT WHEEL/SUSPENSION/STEERING SPECIFICATIONS .....	1-9
CLUTCH/STARTER CLUTCH/GEARSHIFT LINKAGE .....	9-2	FUEL CUT-OFF RELAY .....	5-59
CRANKCASE/CRANKSHAFT/BALANCER/ PISTON/CYLINDER .....	12-2	FUEL LEVEL INDICATOR .....	20-23
CYLINDER HEAD/VALVES .....	8-2	FUEL LEVEL SENSOR .....	20-24
ENGINE REMOVAL/INSTALLATION .....	7-2	FUEL LINE .....	3-5
FRONT WHEEL/SUSPENSION/STEERING .....	13-2	FUEL LINE INSPECTION .....	5-52
FUEL SYSTEM (PGM-FI) .....	5-2	FUEL PUMP .....	5-57
HYDRAULIC BRAKE .....	15-2	FUEL SYSTEM (PGM-FI) SPECIFICATIONS .....	1-6
REAR WHEEL SUSPENSION .....	14-2	FUEL TANK .....	5-60
TRANSMISSION/GEARSHIFT LINKAGE .....	11-2	GEARSHIFT SPINDLE .....	11-7
COOLANT REPLACEMENT .....	6-6	GENERAL SPECIFICATIONS .....	1-5
COOLING SYSTEM .....	3-19	HANDLEBAR .....	13-8
COOLING SYSTEM SPECIFICATIONS .....	1-6	HANDLEBAR SWITCHES .....	20-26
CRANKCASE ASSEMBLY .....	12-24	HEADLIGHT .....	20-6
CRANKCASE BEARING REPLACEMENT .....	12-23	HEADLIGHT AIM .....	3-30
CRANKCASE BREATHER .....	3-8	HISS DIAGNOSTIC CODE INDICATION .....	21-7
CRANKCASE SEPARATION .....	12-6	HORN .....	20-32
		HYDRAULIC BRAKE SPECIFICATIONS .....	1-10
		IACV .....	5-94
		IAT SENSOR .....	5-96

# INDEX

IGNITION COIL .....	18-8	CRANKCASE/CRANKSHAFT/BALANCER/ PISTON/CYLINDER .....	12-3
IGNITION SWITCH .....	20-25	CRANKCASE/TRANSMISSION .....	11-4
IGNITION SYSTEM INSPECTION .....	18-5	CYLINDER HEAD/VALVES .....	8-3
IGNITION SYSTEM SPECIFICATIONS .....	1-10	ELECTRIC STARTER .....	19-3
IGNITION TIMING .....	18-8	ENGINE REMOVAL/INSTALLATION .....	7-3
IMMOBILIZER INDICATOR .....	21-12	FRAME/BODY PANELS/EXHAUST SYSTEM .....	2-3
IMMOBILIZER RECEIVER .....	21-14	FRONT WHEEL/SUSPENSION/STEERING .....	13-4
INJECTOR .....	5-88	FUEL SYSTEM (PGM-FI) .....	5-3
INTAKE AIR DUCT .....	5-105	HYDRAULIC BRAKE .....	15-4
KEY REGISTRATION PROCEDURES .....	21-4	IGNITION SYSTEM .....	18-3
LICENSE LIGHT .....	20-13	IMMOBILIZER SYSTEM (HISS) .....	21-3
LIGHTS/METERS/SWITCHES SPECIFICATIONS .....	1-11	LIGHTS/METERS/SWITCHES .....	20-3
LUBRICATION & SEAL POINTS .....	1-19	LUBRICATION SYSTEM .....	4-3
LUBRICATION SYSTEM DIAGRAM .....	4-2	MAINTENANCE .....	3-2
LUBRICATION SYSTEM SPECIFICATIONS .....	1-6	REAR WHEEL SUSPENSION .....	14-3
MAIN JOURNAL BEARING .....	12-11	SERVICE RULES .....	1-2
MAINTENANCE SCHEDULE .....	3-4	SHOCK ABSORBER .....	14-20
MAP SENSOR .....	5-96	SIDE COVER .....	2-5
METER VISOR .....	2-8	SIDESTAND .....	2-27,3-31
MIL CIRCUIT TROUBLESHOOTING .....	5-52	SIDESTAND SWITCH .....	20-30
MIL TROUBLESHOOTING .....	5-36	SPARK PLUG .....	3-8
MODEL IDENTIFICATION .....	1-3	STANDARD TORQUE VALUES .....	1-12
NEUTRAL SWITCH .....	20-30	STARTER CLUTCH .....	9-29
NUTS, BOLTS, FASTENERS .....	3-35	STARTER MOTOR .....	19-6
O <sub>2</sub> SENSOR .....	5-104	STARTER RELAY SWITCH .....	19-12
OIL COOLER .....	4-13	STATOR .....	10-7
OIL PRESSURE INSPECTION .....	4-5	STEERING HEAD BEARINGS .....	3-36
OIL PUMP .....	4-8	STEERING STEM .....	13-34
OIL STRAINER/PRESSURE RELIEF VALVE .....	4-6	SUSPENSION .....	3-32
PGM-FI CONNECTOR LOCATIONS .....	5-9	SWINGARM .....	14-25
PGM-FI SYMPTOM TROUBLESHOOTING .....	5-6	SYSTEM DIAGRAM	
PGM-FI SYSTEM DIAGRAM .....	5-8	BATTERY/CHARGING SYSTEM .....	17-2
PGM-FI SYSTEM LOCATION .....	5-7	ELECTRIC STARTER .....	19-2
PGM-FI TROUBLESHOOTING INFORMATION .....	5-12	IGNITION SYSTEM .....	18-2
PISTON/CYLINDER .....	12-17	IMMOBILIZER SYSTEM (HISS) .....	21-2
POSITION LIGHT .....	20-10	SYSTEM FLOW PATTERN .....	6-2
PROTECTION GRILL .....	2-4	SYSTEM LOCATION	
RADIATOR .....	6-10	LIGHTS/METER/SWITCHES .....	20-2
RADIATOR COOLANT .....	3-19	SYSTEM TESTING	
RADIATOR RESERVE TANK .....	6-19	COOLING SYSTEM .....	6-5
RADIATOR SHROUD .....	2-7	TACHOMETER .....	20-19
REAR AXLE ASSEMBLY .....	14-17	THERMOSTAT .....	6-8
REAR AXLE DISASSEMBLY .....	14-7	THROTTLE BODY .....	5-85
REAR AXLE/BRAKE DISC .....	14-16	THROTTLE OPERATION .....	3-6
REAR BRAKE CALIPER .....	15-45	TRANSMISSION .....	11-12
REAR COWL .....	2-9	TRANSMISSION/GEARSHIFT	
REAR FENDER A/REAR FENDER STAY .....	2-9	LINKAGE SPECIFICATIONS .....	1-8
REAR FENDER A/REAR FENDER STAY/ MUD GUARD (U type) .....	2-11	TROUBLESHOOTING	
REAR MASTER CYLINDER/BRAKE PEDAL .....	15-29	BATTERY/CHARGING SYSTEM .....	17-5
REAR WHEEL .....	14-6	CLUTCH/GEARSHIFT LINKAGE .....	9-5
REAR WHEEL/SUSPENSION SPECIFICATIONS .....	1-9	COOLING SYSTEM .....	6-4
REGULATOR/RECTIFIER .....	17-7	CRANKCASE/CRANKSHAFT/BALANCER/ PISTON/CYLINDER .....	12-5
RIGHT CRANKCASE COVER INSTALLATION .....	9-34	CRANKCASE/TRANSMISSION .....	11-6
RIGHT CRANKCASE COVER REMOVAL .....	9-16	CYLINDER HEAD/VALVES .....	8-5
SEAT .....	2-4	ELECTRIC STARTER .....	19-4
SEAT RAIL COVER .....	2-6	ENGINE DOES NOT START OR IS HARD TO START .....	23-2
SEAT RAIL/REAR FENDER B .....	2-14	ENGINE LACKS POWER .....	23-3
SECONDARY AIR SUPPLY SYSTEM		FRAME/BODY PANELS/EXHAUST SYSTEM .....	2-3
FUEL SYSTEM (PGM-FI) .....	5-102	FRONT WHEEL/SUSPENSION/STEERING .....	13-7
MAINTENANCE .....	3-20	HYDRAULIC BRAKE .....	15-6
SERVICE INFORMATION		IGNITION SYSTEM .....	18-4
ALTERNATOR .....	10-3	IMMOBILIZER SYSTEM (HISS) .....	21-9
ANTI-LOCK BRAKE SYSTEM (CB1000RA) .....	16-4	LIGHTS/METERS/SWITCHES .....	20-5
BATTERY/CHARGING SYSTEM .....	17-3	LUBRICATION SYSTEM .....	4-4
CLUTCH/STARTER CLUTCH/GEARSHIFT		POOR HANDLING .....	23-6
LINKAGE .....	9-4	POOR PERFORMANCE AT HIGH SPEED .....	23-6
COOLING SYSTEM .....	6-3		

---

POOR PERFORMANCE AT LOW AND IDLE SPEED .....	23-5	VALVE SEAT INSPECTION/REFACING.....	8-18
REAR WHEEL SUSPENSION.....	14-5	VS SENSOR.....	20-17
TURN SIGNAL LIGHT.....	20-11	WATER PUMP.....	6-16
TURN SIGNAL RELAY.....	20-33	WHEEL SPEED SENSOR (CB1000RA).....	16-23
VALVE CLEARANCE.....	3-11	WHEELS/TIRES.....	3-35
VALVE GUIDE REPLACEMENT.....	8-17	WIRING DIAGRAM (CB1000R).....	22-3
		WIRING DIAGRAM (CB1000RA).....	22-4

